

NASA  
Technical Memorandum 100940

AVSCOM  
Technical Report 88-C-025

# Documentation of the Benson Diesel Engine Simulation Program

(NASA-TM-100940) DOCUMENTATION OF THE  
BENSON DIESEL ENGINE SIMULATION PROGRAM  
(NASA) 136 p CSCL 212

N88-27201

Unclas  
G3/07 0157418

Jon Van Gerpen  
*Propulsion Directorate*  
*U.S. Army Aviation Research and Technology Activity—AVSCOM*  
*Lewis Research Center*  
*Cleveland, Ohio*

August 1988

**NASA**





## TABLE OF CONTENTS

	Page
1.0 INTRODUCTION . . . . .	1
2.0 OVERVIEW OF PROGRAM . . . . .	2
2.1 Energy Balance - Benson Model . . . . .	2
2.2 Change in Internal Energy . . . . .	6
2.3 Combustion . . . . .	6
2.3.1 Wiebe Model . . . . .	6
2.3.2 The AVL Model . . . . .	7
2.3.3 The Whitehouse-Way Model . . . . .	7
2.3.4 The Watson Model . . . . .	9
2.3.5 User Supplied Model . . . . .	10
2.4 Heat Transfer . . . . .	10
2.5 Work . . . . .	13
2.6 Mass Flow Terms . . . . .	13
3.0 STEADY STATE HEAT TRANSFER ANALYSIS . . . . .	14
3.1 Introduction . . . . .	14
3.2 Definition of Temperature . . . . .	15
3.3 Network Diagram . . . . .	15
3.4 Definition of Heat Generation Terms . . . . .	22
3.4.1 Friction Submodel . . . . .	22
3.4.2 Crevice Volume Heat Transfer Submodel . . . . .	23
3.5 Node Equations . . . . .	27
3.6 Solution Technique . . . . .	28
4.0 INPUT DATA . . . . .	29
4.1 Subroutine INPUT . . . . .	29
4.2 Subroutine INPUT2 . . . . .	31
5.0 OUTPUT . . . . .	33
6.0 SAMPLE CASES . . . . .	34
6.1 Napier Nomad . . . . .	34
6.2 Garrett CCE . . . . .	36
7.0 DOCUMENTATION OF SUBROUTINES . . . . .	38
7.1 Subroutine BENSON . . . . .	38
7.2 Subroutine BAL . . . . .	38
7.3 Subroutine CYLNR . . . . .	40
7.4 Subroutine CYLVOL . . . . .	41
7.5 Subroutine ELIM . . . . .	43
7.6 Subroutine FCLOSE . . . . .	43
7.7 Subroutine FOPEN . . . . .	44
7.8 Subroutine HEADER . . . . .	44

7.9	Subroutine HTRANS	44
7.10	Subroutine INITLZ	45
7.11	Subroutine INPUT	45
7.12	Subroutine INPUT2	46
7.13	Subroutine MASSFL	46
7.14	Subroutine POWER	49
7.15	Subroutine SPLFIT	50
7.16	Subroutine SREA	50
7.17	Subroutine STROK	52
7.18	Subroutine UNITP	54
7.19	Subroutine UNITT	55
7.20	Subroutine UNITW	55
8.0	CONCLUSION	57
8.1	Suggestions for Future Work	57
8.2	Summary	58
9.0	REFERENCES	59
10.0	APPENDIX	60
10.1	Variable Name List	60
10.2	Napier Nomad program listing	64
10.3	Garrett CCE program listing	69
10.4	Benson Program Listing	75

# DOCUMENTATION OF THE BENSON DIESEL ENGINE SIMULATION PROGRAM

Jon Van Gerpen\*  
Propulsion Directorate  
U.S. Army Aviation Research and Technology Activity - AVSCOM  
Lewis Research Center  
Cleveland, Ohio 44135

## 1.0 INTRODUCTION

This report documents the Benson Diesel Engine Simulation Program and explains how it can be used to predict the performance of diesel engines. This program was obtained from the Garrett Turbine Engine Company but has been extensively modified since that time. The program is a thermodynamic simulation of the diesel engine cycle which uses a single zone combustion model. It can be used to predict the effect of changes in engine design and operating parameters such as valve timing, speed and boost pressure. The most significant change made to this program is the addition of a more detailed heat transfer model to predict metal part temperatures.

This report contains a description of the sub-models used in the Benson program, a description of the input parameters and sample program runs.

---


\*Iowa State University, Mechanical Engineering Dept., Ames, Iowa 50010  
and Summer Faculty Fellow at Lewis Research Center.

## 2.0 OVERVIEW OF PROGRAM

As shown in Figure 2.1, the Benson program uses a large number of subroutines to accomplish specialized tasks during the calculation procedure. However, most of the cycle calculations are performed in two subroutines: CYLNDR, which calculates the gas exchange processes and POWER which takes care of compression, combustion and expansion. The development of the energy balance and a discussion of how it is evaluated is given below.

### 2.1 Energy Balance - Benson Model

The chemical equation for the combustion process in the diesel engine can be simplified to the following expression.



where  $n$  and  $m$  are stoichiometric coefficients and  $\phi$  is the equivalence ratio.

The first law of thermodynamics must be satisfied at all times as this reaction occurs in the engine. For the period when the intake and exhaust ports are closed, the first law can be written for an interval of time from  $t$  to  $t+dt$ ,

$$E_2 - E_1 = \delta Q - \delta W$$

where  $E_2$  and  $E_1$  are given by

$$E_2 = a_{\text{N}_2} e_{\text{N}_2}(T_2) + a_{\text{O}_2} e_{\text{O}_2}(T_2) + a_{\text{CO}_2} e_{\text{CO}_2}(T_2) + a_{\text{H}_2\text{O}} e_{\text{H}_2\text{O}}(T_2) + a_{\text{C}_n\text{H}_m} e_{\text{C}_n\text{H}_m}(T_2)$$

$$E_1 = b_{\text{N}_2} e_{\text{N}_2}(T_1) + b_{\text{O}_2} e_{\text{O}_2}(T_1) + b_{\text{CO}_2} e_{\text{CO}_2}(T_1) + b_{\text{H}_2\text{O}} e_{\text{H}_2\text{O}}(T_1) + b_{\text{C}_n\text{H}_m} e_{\text{C}_n\text{H}_m}(T_1)$$

The coefficients,  $a_i$  and  $b_i$ , are the number of moles of species  $i$  present in the cylinder and

$$e_i(T) = e_i(0) + [e_i(T) - e_i(0)]$$




Figure 2.1 Flow Chart for Benson Program

where  $e_i(0)$  is the partial molar internal energy of species  $i$  at absolute zero and  $[e_i(T) - e_i(0)]$  is the sensible internal energy difference between absolute zero and  $T$ .

For convenience, the sum of the sensible terms can be defined as  $E^*$

$$E^*(T) = a_{N_2}[e_{N_2}(T) - e_{N_2}(0)] + a_{O_2}[e_{O_2}(T) - e_{O_2}(0)] \\ + a_{CO_2}[e_{CO_2}(T) - e_{CO_2}(0)] + a_{H_2O}[e_{H_2O}(T) - e_{H_2O}(0)]$$

Thus  $E_2 - E_1$  can be written as

$$E_2 - E_1 = (E_2^* - E_1^*) + (a_{N_2} - b_{N_2})e_{N_2}(0) + (a_{O_2} - b_{O_2})e_{O_2}(0) \\ + (a_{CO_2} - b_{CO_2})e_{CO_2}(0) + (a_{H_2O} - b_{H_2O})e_{H_2O}(0) \\ + (a_{C_nH_m} - b_{C_nH_m})e_{C_nH_m}(0)$$

If  $dM_f$  moles of fuel are burned as the reaction progresses from  $t$  to  $t+dt$ , atom balances can be used to fix relations between the  $a_i$  and  $b_i$  coefficients.

$$a_{N_2} = b_{N_2} \\ a_{O_2} = b_{O_2} - [n + \frac{m}{4}] dM_f \\ a_{CO_2} = b_{CO_2} + n dM_f \\ a_{H_2O} = b_{H_2O} + \frac{m}{2} dM_f \\ a_{C_nH_m} = b_{C_nH_m} - dM_f$$

The constant volume heat of combustion with the water in the products present as vapor can be defined as

$$Q_v \equiv E_{\text{prod}}(T_s) - E_{\text{reac}}(T_s)$$

where  $E_{\text{prod}} = n e_{CO_2}(T_s) + \frac{m}{2} e_{H_2O}(T_s)$

$$E_{\text{reac}} = [n + m/2] e_{O_2}(T_s) + e_{C_nH_m}(T_s)$$

$T_s$  = reference temperature where  $Q_v$  is defined.



By combining the definition of the constant volume heat of combustion and the definition of the constant volume heat of combustion at absolute zero

$$\Delta E_o \equiv E_{\text{prod}}(0) - E_{\text{reac}}(0)$$

we can obtain

$$Q_v = \Delta E_o + n[e_{\text{CO}_2}(T_s) - e_{\text{CO}_2}(0)] + \frac{m}{2}[e_{\text{H}_2\text{O}}(T_s) - e_{\text{H}_2\text{O}}(0)] \\ - (n + \frac{m}{4})[e_{\text{O}_2}(T_s) - e_{\text{O}_2}(0)] - [e_{\text{C}_n\text{H}_m}(T_s) - e_{\text{C}_n\text{H}_m}(0)]$$

Substituting this into the equation for  $(E_2 - E_1)$  gives

$$E_2 - E_1 = E_2^* - E_1^* - Q_v dM_f - (a_{\text{CO}_2} - b_{\text{CO}_2})[e_{\text{CO}_2}(T_s) - e_{\text{CO}_2}(0)] \\ - (a_{\text{H}_2\text{O}} - b_{\text{H}_2\text{O}})[e_{\text{H}_2\text{O}}(T_s) - e_{\text{H}_2\text{O}}(0)] \\ + (a_{\text{O}_2} - b_{\text{O}_2})[e_{\text{O}_2}(T_s) - e_{\text{O}_2}(0)] \\ + a_{\text{C}_n\text{H}_m}[e_{\text{C}_n\text{H}_m}(T_2) - e_{\text{C}_n\text{H}_m}(T_s)] \\ - b_{\text{C}_n\text{H}_m}[e_{\text{C}_n\text{H}_m}(T_1) - e_{\text{C}_n\text{H}_m}(T_s)]$$

Since the fuel is such a small fraction of the total mass in the cylinder, the fuel internal energy terms can be neglected and the terms evaluated at  $T_s$  can be written as

$$E_2 - E_1 = [E_2^* - E_2^*(T_s)] - [E_1^* - E_1^*(T_s)] - Q_v dM_f$$

where  $E_1^*(T_s)$  designates the sum of the sensible internal energy terms using the composition at state 1 and evaluating the partial molar internal energies at  $T_s$ .

Finally, the first law of thermodynamics can be written as

$$[E_2^* - E_2^*(T_s)] - [E_1^* - E_1^*(T_s)] - Q_v dM_f = \delta Q - \delta W$$

for the period where the intake and exhaust ports are closed and when the ports are open the first law becomes

$$[E_2^* - E_2^*(T_s)] - [E_1^* - E_1^*(T_s)] - Q_v dM_f = \delta Q - \delta W + m_{\text{in}} h_{\text{in}} - m_{\text{out}} h_{\text{out}}$$

Each of the terms in this equation will be discussed in turn.

## 2.2 Change in Internal Energy

The internal energy is calculated using fourth order polynomial curve fits of the JANAF tables [1]. These curve fits provide the sensible enthalpy change between absolute zero and some temperature T. The values of internal energy are obtained from  $e = h - RT$ .

## 2.3 Combustion

The rate at which fuel is burned, and its energy released, is determined by the choice of combustion model. Currently, four combustion models may be selected for use in the Benson Program along with one user supplied model. The choice of model is determined by the values of the input parameters, NPCWF and DEL3. The values of these parameters corresponding to each model are given below.

NPCWF = 0 and DEL3 > 0.	Wiebe combustion model
NPCWF = 0 and DEL3 = 0.	AVL combustion model
NPCWF = -1	Whitehouse-Way combustion model
NPCWF = 1	Watson combustion model
NPCWF = 2	User supplied model

Each of the combustion models will be discussed in turn.

### 2.3.1 Wiebe Model

The Wiebe model is a simple functional model consisting of a two parameter exponential function which has the flexibility to assume the shape of known burning rate curves in supercharged diesel engines. The following

expression is used to calculate the fraction of fuel burned.

$$\% \text{ Fuel Burned} = 100. \times [1 - \exp(-\delta_1 \tau^{\delta_2})]$$

where  $\delta_1$  and  $\delta_2$  are parameters which determine the shape of the function

$$\tau \text{ is a dimensionless time parameter} = \frac{CA - ACB}{HRD}$$

CA is the current crank angle

ACB is the crank angle at which combustion begins

HRD is the combustion duration, equal to (ACF - ACB)

### 2.3.2 The AVL Model

The AVL model is the same as the Wiebe model except that AVL has recommended a way to specify the combustion duration. AVL suggests that the combustion duration parameter be chosen so that it is a linear function of the equivalence ratio.

$$HRD = 15 + 115 (\phi)$$

where  $\phi$  is the fuel-air equivalence ratio.

### 2.3.3 The Whitehouse-Way Model

Of the models supplied with the Benson Program, the Whitehouse-Way [2,3] model is the only one that attempts to model the physics of the combustion event. The fuel injection rate is supplied as an input and the model relates the burning rate to this injection rate. The injection rate is specified by two parameters: the initial injection rate and the timing at which the maximum injection rate occurs. The injection rate is defined by the following function.

$$\begin{aligned}\text{Injection Rate} &= \text{AAN}(1) + \left[ \frac{\text{AA2} - \text{AAN}(1)}{\text{AAN}(2)} \right] \tau & 0 < \tau < \text{AAN}(2) \\ &= \frac{\text{AA2}}{\text{AAN}(2) - 1} (\tau - 1) & \text{AAN}(2) < \tau < 1\end{aligned}$$

where AAN(1) and AAN(2) are user specified injection rate parameters

$$\text{AA2} = 2 - \left[ \text{AAN}(2) \cdot \text{AAN}(1) \right]$$

$\tau$  = defined same as above under Wiebe

Fuel is assumed to be prepared for combustion according to a relation of the form

$$P = K M_1^{1-x} M_u^x P_{O_2}^m$$

where x and m are empirical parameters which should be constant for a given problem.

K is a parameter which needs to be determined for each individual problem.

P is the fuel preparation rate.

$M_1$  is the mass of fuel injected.

$M_u$  is the mass of fuel unburnt.

The burning rate is calculated from an exponential expression of the form:

$$R = \frac{K}{N} \frac{P_{O_2}}{\sqrt{T}} \int (P - R) dx \cdot \exp\left(\frac{-act}{T}\right)$$

where R is the burning rate

"act" is an effective activation energy which must be specified

$P_{O_2}$  is the partial pressure of oxygen

N is the engine speed, Rev/min

The integral is evaluated in the Benson program as a summation

$$\Sigma(P-R)\Delta CA$$

and R is calculated using the value of the summation calculated up to the beginning of the time step.

Although the authors of this model have attempted to incorporate combustion theory into this model, it should be recognized that it is based on an understanding of diesel combustion that assumes droplet effects are important. Current understanding of diesel combustion assumes that the fuel vaporizes very soon after it is injected and that the combustion has more in common with a turbulent gaseous diffusion flame than droplet combustion.

#### 2.3.4 The Watson Model

The Watson model [4] is a functional model, like the Wiebe model, which uses simple algebraic functions chosen for their ability to produce burning curves similar to those observed in diesel engines. The Watson model was developed to reproduce the "premixed spike" at the start of typical diesel heat release curve. Instead of a single exponential curve like the Wiebe model, the Watson model uses two curves which are superimposed. The first curve has a very high rate of combustion and simulates the premixed combustion. This curve dies out very quickly after the start of combustion and the second curve, which is an exponential exactly like the Wiebe model, becomes dominant. A weighting factor is used to determine how much emphasis is given to each of the curves. The Watson model is as follows.

$$\% \text{ Fuel Burned} = 100 \cdot \left[ \beta \left[ 1 - [1 - \tau^{C_{P1}}]^{C_{P2}} \right] + (1 - \beta) \left[ 1 - \exp[-C_{d1} \tau^{C_{d2}}] \right] \right]$$

where  $\beta = \text{weighting factor} = 1. - \delta_1 \phi^{\delta_2} \text{actr}^{-\delta_3}$

$$C_{P1} = 2. + 1.25 \times 10^{-8} (\text{actr} \cdot \text{Nr} \cdot 60.)^{2.4}$$

$$C_{P2} = 5000.$$

$$C_{d1} = 14.2 \phi^{-0.644}$$

$$C_{d_2} = 0.79 \cdot C_{d_1}^{0.25}$$

actr = ignition delay period, which may be estimated from

$$\text{actr} = 3.45 \exp(2100./T_m) P_m^{-1.02}$$

where  $T_m$  and  $P_m$  are the mean temperature and pressure during the ignition delay period.

$\phi$  = equivalence ratio

Nr = engine speed, rev/sec

$\delta_1, \delta_2, \delta_3$  = parameters chosen to vary shape of the model.

(Watson suggests  $\delta_1 = 0.926$ ,  $\delta_2 = 0.37$  and  $\delta_3 = -0.26$ )

The Watson model, because it can simulate premixed combustion, is appropriate for conditions where premixed combustion is important such as light loads and cold starting with naturally aspirated engines. This model is also appropriate when running on low cetane fuels. Under highly supercharged conditions the amount of premixed combustion will be small ( $\beta \cong 0$ ) so the Watson model reduces to the Wiebe model.

#### 2.3.5 User supplied model

The user may provide a mass burning rate function of any arbitrary shape through the subroutine BURNRT. The subroutine should be written so that at a given value of crank position, designated by ANGLA, the amount of fuel burned in a one degree time step is returned as DWFUEL.

## 2.4 Heat Transfer

Two correlations are available for use in calculating the heat transfer in the Benson Program: The Annand [5] correlation and the Woschni [6] correlation. The Annand correlation takes the following form.

$$q/A = \frac{a}{D} (Re)^b (T - T_w) + c (T^4 - T_w^4)$$

where  $q$  = heat transfer

$A$  = Area of surface exposed to heat transfer

$k$  = Thermal conductivity

$$Re = \text{Reynolds number} = \frac{\rho \bar{U}_p D}{\mu}$$

$T$  = Gas Temperature

$T_w$  = Wall Temperature

$\bar{U}_p$  = Mean Piston speed

$\rho$  = gas density

$\mu$  = gas viscosity

$D$  = Bore of engine

$a, b, c$  = User supplied constants, called ANNA, ANNB and ANNC in the Benson Program.

The constant,  $a$ , depends on the intensity of gas motion in the cylinder and Annand recommends a value between 0.35 and 0.8, with higher values corresponding to more intense motion. The constant,  $b$ , should be 0.7 and the constant  $c$  should be:

during compression,  $c = 0$ .

during combustion and expansion,

$$c = 3.266 \times 10^{-11} \frac{\text{kW}}{\text{m}^2 - \text{K}^4} \text{ for diesel engine}$$

$$c = 4.286 \times 10^{-12} \frac{\text{kW}}{\text{m}^2 - \text{K}^4} \text{ for spark ignition engine}$$

Woschni's correlation is of the following form.

$$q/A = a \frac{k}{D} (Re)^b (T - T_w)$$

where  $Re = \text{Reynolds Number} = \frac{\rho w D}{\mu}$

$w = \text{in-cylinder gas velocity}$

$$= 6.18 \bar{U}_p \text{ during scavenging period, m/s.}$$

$$= 2.28 \bar{U}_p \text{ during compression, m/s}$$

$$= 2.28 \bar{U}_p + 3.24 \times 10^{-3} \frac{V_s T_1}{p_1 V_1} (p - p_o) \text{ during combustion}$$

and expansion, m/s

$V_s = \text{displacement volume.}$

$p_1, V_1, T_1 = \text{pressure, volume and temperature at some point when the cylinder is closed for use in estimating the trapped mass.}$

$p = \text{instantaneous cylinder pressure}$

$p_o = \text{cylinder pressure for an unfired cycle at the same crank position and under the same conditions as } p.$

$a, b = \text{User supplied constants, called ANNA and ANNB in the Benson program. Woschni recommends a value of 0.035 for constant } a \text{ and } 0.8 \text{ for constant } b.$

The principal difference between these two correlations is that Annand's correlation separates the convective and radiative terms while Woschni's correlation combines the convection and radiation in a single term. The user supplied parameters ANNA, ANNB and ANNC are used to select which correlation will be used in the program and to adjust the significance of heat transfer in the energy balance. When ANNC is equal to 0.0, the Woschni correlation will be used, and when ANNC is equal to a non-zero number, the Annand correlation will be used. ANNB is normally set to the respective author's suggested value. ANNA is also normally set to the author's values unless data is available which indicate the total amount of heat loss for the cycle in which



case ANNA can be adjusted to obtain this amount.

## 2.5 Work

The work term is calculated from time step to time step by taking the average pressure for the time step multiplied by the volume change for the time step.

$$\delta W = \frac{P_1 + P_2}{2} \cdot (V_2 - V_1)$$

## 2.6 Mass Flow Terms

The mass flow terms are calculated using subroutine MASSFL which calculates the mass entering or leaving the cylinder through the intake or exhaust ports. The techniques involved in this calculation are explained later in the discussion of that subroutine. After calculating the mass flow rates, the enthalpy is calculated using the polynomial curve-fits to the JANAF tables.

### 3.0 STEADY STATE HEAT TRANSFER ANALYSIS

#### 3.1 Introduction

The original version of the Benson Program received from Garrett contains a simple heat transfer analysis which calculates convective heat transfer coefficients using either the Annand or the Woschni correlations as described in section 2.4. The analysis described in this section has been added to the Benson program to allow prediction of the effect of varying engine design parameters and operating conditions on metal part temperatures. The analysis provides an estimate of the gas and coolant side wall temperatures for the piston crown, the cylinder wall, the head and the exhaust valve along with the top compression ring temperature.

The model is one-dimensional and assumes the temperatures of the various components do not change during the cycle. The model has been developed for a single cylinder engine and can not distinguish between end cylinders or internal cylinders of a multi-cylinder engine. Submodels for the heat generated by piston/ring friction and for crevice volume heat transfer are included.

The analysis requires that a number of critical engine dimensions be specified along with heat transfer path lengths. Although these heat transfer path lengths can be estimated, a high level of accuracy requires that experimental measurements be used to calculate these path lengths and thus "tune" the heat transfer analysis. Without experimental data, the absolute values of the temperatures provided by this analysis can be no more accurate than the path lengths supplied as input. However, even though the numerical values of temperature may be in doubt, the analysis should still predict

trends accurately.

### 3.2 Definition of Temperatures

Figure 3.1 shows a cross-section of the engine cylinder and identifies the various temperatures used in the analysis. Heat transfer occurs from the hot cylinder gases through the metal parts to the engine coolant. Three coolant temperatures are identified: the head coolant, the cylinder wall coolant and the piston coolant. The exhaust valve receives heat from the cylinder gases and loses it to the head by conduction through the valve seat, to the valve guide by conduction up the valve stem and to the exhaust port gases by convection.

The temperatures labeled in Figure 3.1 are defined below.

TC1 = Piston cooling oil temperature  
TC2 = Cylinder wall coolant temperature  
TC3 = Head coolant temperature  
TWOC = Coolant side cylinder wall temperature  
TWGC = Gas side cylinder wall temperature  
TWCH = Coolant side head temperature  
TWGH = Gas side head temperature  
TWCP = Coolant side piston temperature  
TWGP = Gas side piston temperature  
TWPR = Piston rim temperature  
TWCR = Top compression ring temperature  
TWEV = Exhaust valve temperature  
TWEVG = Exhaust valve guide temperature  
TEXHP = Exhaust port gas temperature

### 3.3 Network Diagram

It is common in heat transfer problems to take advantage of the analogy between heat transfer through thermal resistance and direct current flow through electrical resistance. Steady state heat transfer relations such as

$$Q = h A (T_2 - T_1) \quad \text{and} \quad Q = k A \frac{(T_1 - T_2)}{L}$$




Figure 3.1 Cross-section of Cylinder

can be written as

$$Q = \frac{T_2 - T_1}{R_1} \quad \text{and} \quad Q = \frac{T_1 - T_2}{R_2}$$

where

$$R_1 = \frac{1}{h A} \quad \text{and} \quad R_2 = \frac{L}{k A}$$

the temperatures  $T_1$  and  $T_2$  represent potentials similar to voltages and the thermal resistances  $R_1$  and  $R_2$  are analogous to electrical resistances. One advantage of this approach is that it allows the heat transfer problem to be represented pictorially as a resistance network diagram.

Figure 3.2 shows the network diagram of the heat transfer problem identified above. The node points in this diagram correspond to the temperatures identified in Figure 3.2. The resistances are defined below.

- $R_1$  = Conductive resistance between exhaust valve and the valve guide
- $R_2$  = Convective resistance between exhaust valve and exhaust port gases.
- $R_3$  = Conductive resistance between exhaust valve and the cylinder head through the valve seat.
- $R_4$  = Conductive resistance through the cylinder head.
- $R_5$  = Convective resistance between head and head coolant
- $R_6$  = Conductive resistance from the gas side of piston crown to oil-cooled under-side of piston.
- $R_7$  = Convective resistance on oil-cooled underside of piston
- $R_8$  = Conductive resistance between piston and cylinder wall through the lower rings and the oil film.
- $R_9$  = Conductive resistance between piston crown and piston rim.
- $R_{10}$  = Conductive resistance between top compression ring and the cylinder wall.
- $R_{11}$  = Conductive resistance through cylinder wall.
- $R_{12}$  = Conductive resistance between piston rim and top compression ring.
- $R_{13}$  = Convective resistance between cylinder wall and coolant.
- $R_{14}$  = Combined convective and radiative resistance between cylinder



- wall and cylinder gases.
- $R_{15}$  = Combined convective and radiative resistance between piston crown and cylinder gases.
- $R_{16}$  = Combined convective and radiative resistance between head and cylinder gases.
- $R_{17}$  = Combined convective and radiative resistance between exhaust valve and cylinder gases.

These resistances can be expressed in terms of more fundamental quantities as follows,

$$\begin{aligned}
 R_1 &= \frac{XXEVG}{AEXVS \cdot CEXV} & R_2 &= \frac{1}{HEXHP \cdot AEXV} \\
 R_3 &= \frac{XXEVH}{AEXST \cdot CEXV} & R_4 &= \frac{XXHED}{AHEAD \cdot CHEAD} \\
 R_5 &= \frac{1}{HCHD \cdot AHEAD} & R_6 &= \frac{XXPIS}{APIST1 \cdot CPIST} \\
 R_7 &= \frac{1}{HOILP \cdot APIST2} & R_8 &= \frac{XXPSL}{ASLEEV \cdot CPIST} \\
 R_9 &= \frac{XXPCR}{APISTR \cdot CPIST} & R_{10} &= \frac{XXRSL}{ARING1 \cdot CRING} \\
 R_{11} &= \frac{XXSLV}{ASLEEV \cdot CSLEEV} & R_{12} &= \frac{XXPRG}{ARING2 \cdot CRING} \\
 R_{13} &= \frac{1}{HCSL \cdot ASLEEV}
 \end{aligned}$$

where the heat transfer path lengths, areas, thermal conductivities, and convection coefficients are given below

- XXEVG = Path length from exhaust valve to valve guide  
 XXEVH = Path length from exhaust valve to valve seat  
 XXHED = Path length through head  
 XXPIS = Path length through piston  
 XXPSL = Path length from piston to cylinder wall through lower rings and oil film  
 XXPCR = Path length from piston crown to piston rim  
 XXRSL = Path length from top compression ring to cylinder wall  
 XXSLV = Path length through cylinder wall  
 XXPRG = Path length from piston rim to top compression ring
- AEXVS = Area of exhaust valve stem  
 AEXV = Area of exhaust valve exposed to combustion chamber  
 AEXST = Exhaust valve seat contact area

AHEAD = Cylinder head area not covered by exhaust valves  
 APIST1= Cross-sectional area of cylinder  
 APIST2= Surface area exposed to oil on underside of piston  
 ASLEEV= Characteristic area for heat transfer through cylinder wall  
 APISTR= Characteristic area between piston crown and piston rim  
 ARING1= Contact area between top compression ring and cylinder wall  
 ARING2= Contact area between top compression ring and piston rim

CEXV = Thermal conductivity of exhaust valve  
 CHEAD = Thermal conductivity of head  
 CPIST = Thermal conductivity of piston  
 CRING = Thermal conductivity of ring  
 CSLEEV= Thermal conductivity of cylinder wall

HEXHP = Convection coefficient from back side of exhaust valve to  
           gases in exhaust port  
 HCHD = Convection coefficient for coolant on backside of head  
 HOILP = Convection coefficient for cooling oil on backside of piston  
 HCSL = Convection coefficient for coolant on backside of cylinder wall

$R_{14}$  through  $R_{17}$  are combined convective and radiative resistances between the time varying cylinder gas and the cylinder wall, and must be handled in a special way. The heat transfer to one of the combustion chamber surfaces, such as the head, piston, cylinder wall or exhaust valve, is given for an entire cycle by

$$Q_{\text{cycle}} = \oint h_i A_i (T_i - T_{\text{gas}}) dt$$

and the average continuous heat transfer rate is obtained by multiplying by the engine speed

$$\dot{Q} = N_r \oint h_i A_i (T_i - T_{\text{gas}}) dt$$

The convection coefficient,  $h_i$ , in this expression will be obtained from either the Annand or Woschni correlations already present in the Benson program. The Annand correlation includes a radiation term,  $c (T_i^4 - T_{\text{gas}}^4)$ , and this term must be included by defining a psuedo-convective coefficient as follows,

$$\dot{Q} = (h_c + h_r) A_i (T_i - T_{\text{gas}})$$



where  $h_c$  = conventional convective coefficient,

$$h_r = \text{radiative coefficient} = c [T_i^3 + T_i^2 T_{\text{gas}} + T_i T_{\text{gas}}^2 + T_{\text{gas}}^3]$$

When using the Annand Correlation, the coefficient  $h_i$  is equal to the sum of  $h_c$  and  $h_r$ .

The integral in the expression for  $\dot{Q}$  can be separated and  $T_i$  can be removed from its integral since it is a constant.

$$\dot{Q} = N_r T_i \oint h_i A_i dt - N_r \oint h_i A_i T_{\text{gas}} dt$$

or

$$\dot{Q} = N_r \oint h_i A_i dt \left[ T_i - \frac{\oint h_i A_i T_{\text{gas}} dt}{\oint h_i A_i dt} \right]$$

By defining an effective gas temperature,  $T_{\text{eg}}$ ,

$$T_{\text{eg}} = \frac{\oint h_i A_i T_{\text{gas}} dt}{\oint h_i A_i dt}$$

the heat transfer rate from the gas to surface i becomes

$$\dot{Q} = N_r \oint h_i A_i dt [T_i - T_{\text{eg}}]$$

or

$$\dot{Q} = \frac{T_i - T_{\text{eg}}}{R}$$

where  $R = \frac{1}{N_r \oint h_i A_i dt}$

It should be noted that the effective gas temperature will be a different value for each surface.

$T_{\text{eg,exh valve}}$  = Effective gas temperature for exhaust valve

$T_{\text{eg,head}}$  = Effective gas temperature for head

$T_{\text{eg,pist}}$  = Effective gas temperature for piston

$T_{\text{eg,cyl}}$  = Effective gas temperature for cylinder wall

### 3.4 Definition of Heat Generation Terms

In addition to the resistances and nodes shown on the network diagram in Figure 3.2, there are a number of heat source terms which are identified as either  $Q_{\text{fric}}$  or  $Q_{\text{cv}}$ . The  $Q_{\text{fric}}$  terms relate to the heat generated by friction between the cylinder wall and the piston and rings. The  $Q_{\text{cv}}$  terms relate to the heat transferred from the cylinder gases as they cool in the crevice volume between the piston and cylinder wall above the top ring.

#### 3.4.1 Friction Submodel

The friction mean effective pressure (FMEP) due to piston/ring cylinder wall friction can be predicted using a correlation developed by Bishop [7].

$$\frac{\text{FMEP}}{\rho_o \bar{U}_p^2} = \frac{6.2 \times 10^4 r^{0.2}}{\text{Re}}$$

where  $\rho_o$  = oil density

$\bar{U}_p$  = mean piston speed

$r$  = compression ratio

$$\text{Re} = \text{Reynolds number} = \frac{\rho_o \bar{U}_p b}{\mu_o}$$

$b$  = bore

$\mu_o$  = oil viscosity

The torque required to overcome this friction, in a two stroke engine, is

$$T_f = \frac{(\text{FMEP}) V_d}{2\pi} = \frac{(\text{FMEP}) b^2 S}{8}$$

where  $V_d$  is the displacement volume and  $S$  is the stroke.

The power required to overcome the friction, and thus the rate at which energy

must be dissipated by heat transfer is given by

$$P_f = T_f \omega = 2 \pi N_r T_f$$

where  $N_r$  is the engine speed.

The distribution of the heat transfer must be estimated either from measurements or more detailed analysis than that provided here. This information can be provided to the simulation through two defined parameters.

CFRIC1 which is the fraction of the total piston/ring/cylinder wall friction which is due to the top compression ring and

CFRIC2 which is the fraction of the heat transfer resulting from top ring friction which goes to the ring side.

Using these definitions, the heat source terms for the network diagram in Figure 3.2 become

$$\begin{aligned}\dot{Q}_{\text{fric}_1} &= \text{CFRIC1} \cdot \text{CFRIC2} \cdot P_f \\ \dot{Q}_{\text{fric}_2} &= (1 - \text{CFRIC2}) P_f \\ \dot{Q}_{\text{fric}_3} &= (1 - \text{CFRIC1}) \cdot \text{CFRIC2} \cdot P_f\end{aligned}$$

#### 3.4.2 Crevice Volume Heat Transfer Submodel

Figure 3.3 shows a cross-section of the crevice volume region of the piston/cylinder wall above the top ring and the dimensions which must be specified to characterize this volume. Gas enters and leaves this volume as the pressure in the cylinder increases and decreases. Heat transfer from these gases to the piston and top ring can significantly raise the top ring temperature above that due to conduction from the piston and frictional heating. It is possible to calculate a characteristic time for conduction as




Figure 3.3 Crevice Volume Dimensions

$\tau = \frac{L^2}{\alpha}$  where  $L$  is a characteristic length and  $\alpha$  is the thermal diffusivity of the conducting medium. Assuming a 0.005 inch clearance between the piston and cylinder wall as a characteristic length and the thermal diffusivity of air at 2000 deg F, the characteristic time becomes

$$\tau = \frac{(0.005/12 \text{ ft})^2}{2.83 \times 10^{-3} \text{ ft}^2/\text{sec}} = 6.13 \times 10^{-5} \text{ sec}$$

which is equal to 2.2 degrees of crankshaft rotation at 6000 RPM. This indicates that conduction will rapidly bring any air which enters the crevice volume into thermal equilibrium with the walls.

The following assumptions are used in the model for crevice volume heat transfer.

1. The pressure in the crevice volume is equal to the cylinder pressure.
2. The temperature of the gas in the crevice volume is constant at a value determined by an area-average of the wall temperatures.

$$T_{cv} = \frac{A_P}{A_T} TWPR + \frac{A_R}{A_T} TWCR + \frac{A_C}{A_T} TWGC$$

where  $T_{cv}$  = Crevice volume gas temperature

$TWPR$  = Piston rim temperature

$TWCR$  = Top compression ring temperature

$TWGC$  = Gas side cylinder wall temperature

$A_P$  = Piston area exposed to crevice volume

$A_R$  = Ring area exposed to crevice volume

$A_C$  = Cylinder area exposed to crevice volume

$A_T = A_P + A_R + A_C$

3. Since the volume of the crevice is constant, and the temperature and

pressure in the crevice are known from assumptions 1 and 2, the mass of gas in the crevice can be calculated from the ideal gas equation

$$m_{cv} = \frac{P_{cyl} V_{cv}}{R T_{cv}}$$

where  $P_{cyl}$  = cylinder pressure

$V_{cv}$  = volume of crevice

$R$  = Ideal gas constant for the cylinder contents

From one time step to the next, the mass added to the crevice volume will be

$$\Delta m_{cv} = \frac{V_{cv}}{R T_{cv}} [\Delta P_{cyl}]$$

where  $\Delta P_{cyl}$  is the change in cylinder pressure during the time step

$\Delta m_{cv}$  is the change in mass of the crevice volume

4. Gas which enters the crevice volume is instantly cooled and this energy is delivered to the walls in proportion to their areas.

$$Q_T = \Delta m C_p (T_{gas} - T_{cv})$$

and

$$Q_{cv_1} = \frac{A_p}{A_T} Q_T, \quad Q_{cv_2} = \frac{A_R}{A_T} Q_T, \quad Q_{cv_3} = \frac{A_C}{A_T} Q_T$$

where  $Q_T$  = energy transferred from gas to crevice volume walls.

$\Delta m$  = Increment of mass added to crevice volume in one time step

$T_{gas}$  = Cylinder gas temperature

$Q_{cv_1}$  = Fraction of heat transfer which goes to piston rim

$Q_{cv_2}$  = Fraction of heat transfer which goes to top compression ring

$Q_{cv_3}$  = Fraction of heat transfer which goes to cylinder wall

Combining these equations gives the following expression for the crevice

volume heat transfer for one time step.

$$Q = \left[ \frac{\gamma}{\gamma-1} \right] V_{cv} \left[ \frac{T_{gas}}{T_{cv}} - 1 \right] \Delta P_{cyl}$$

The total heat transfer for a cycle is given by summing the heat transfer at each time step

$$Q_T = \sum_{cycle} \left[ \frac{\gamma}{\gamma-1} \right] V_{cv} \left[ \frac{T_{gas}}{T_{cv}} - 1 \right] \Delta P_{cyl}$$

and the average heat transfer rate is obtained by multiplying by the engine speed.

$$\dot{Q}_T = N_r \cdot \sum_{cycle} \left[ \frac{\gamma}{\gamma-1} \right] V_{cv} \left[ \frac{T_{gas}}{T_{cv}} - 1 \right] \Delta P_{cyl}$$

### 3.5 Node Equations

Based on the concept that at steady state the currents into any node of the network diagram given in Figure 3.2 must add to zero, equations can be written which sum the heat transfer into each node. There is one equation for each of the nine unknown temperatures. These equations are given below.

$$\begin{aligned} \frac{TC2 - TWOC}{R_{13}} + \frac{TWGC - TWOC}{R_{11}} &= 0 \\ \frac{TC1 - TWCP}{R_7} + \frac{TWGP - TWCP}{R_6} &= 0 \\ \frac{TC3 - TWCH}{R_5} + \frac{TWGH - TWCH}{R_4} &= 0 \\ \frac{TWEVG - TWEV}{R_1} + \frac{TEXHP - TWEV}{R_2} + \frac{TWGH - TWEV}{R_3} + \frac{T_{eg,exh valve} - TWEV}{R_{17}} &= 0 \\ \frac{TWCH - TWGH}{R_4} + \frac{TWEV - TWGH}{R_3} + \frac{T_{eg,head} - TWGH}{R_{16}} &= 0 \\ \frac{TWGC - TWGP}{R_8} + \frac{TWPR - TWGP}{R_9} + \frac{TWCP - TWGP}{R_6} + \frac{T_{eg,pist} - TWGP}{R_{15}} + \dot{q}_{fric3} &= 0 \\ \frac{TWGP - TWPR}{R_9} + \frac{TWCR - TWPR}{R_{12}} + \dot{q}_{cv3} &= 0 \end{aligned}$$

$$\frac{TWOC - TWGC}{R_{11}} + \frac{TWCR - TWGC}{R_{10}} + \frac{TWGP - TWGC}{R_8} + \frac{T_{eg.cyl} - TWGC}{R_{14}} + \dot{Q}_{cv_2} + \dot{Q}_{fric_2} = 0$$

$$\frac{TWGC - TWCR}{R_{10}} + \frac{TWPR - TWCR}{R_{12}} + \dot{Q}_{cv_1} + \dot{Q}_{fric_1} = 0$$

### 3.6 Solution Technique

The nine node equations listed above are a system of linear algebraic equations and can be solved using a Gaussian elimination procedure. A subroutine for this purpose was obtained from Gerald [8]. The calculation is performed at the end of each cycle iteration providing an updated estimate of the nine metal temperatures. Depending on the value of the user specified parameter, NHEAT, four of these temperatures, the cylinder wall temperature, the piston crown temperature, the head temperature and the exhaust valve temperature, can be used in the next iteration so that the metal temperatures will approach their steady state values (NHEAT = 1). The other option is to fix these four metal temperatures at values specified by the user (NHEAT = 0).



#### 4.0 INPUT DATA

Two sets of input data must be provided to the Benson program to define the particular application being considered. The first data set provides general data describing the engine and operating conditions being simulated. The second data set relates specifically to the steady state heat transfer analysis discussed in Chapter 3.0 and contains the thermal properties of the engine components and the appropriate areas and path lengths.

##### 4.1 Subroutine INPUT

Below is listed the input data set required by the Benson program. The variable names are also provided. The current version of the program has these variables entered through a BLOCK DATA statement in the main program and then passed through a COMMON block into the program. READ statements are provided in the INPUT subroutine to read an external file to obtain these variables but these statements have been made into comment statements.

---

EQUIVD	RPM	PEXH	PAIR	TAIR	
CR	BORE	STROKE	CONROD	FPISTA	
EVO	EVC	AVO	AVC		
TWALL	WFUEL				
ACB	ACF				
ANNA	FMEPM				
NPCWF	DEL1	DEL2	DEL3	AAN(1)	AAN(2)
VALEXH					
CDE	NTEXH				
ALPHEX(1)	FEXH(1)				
ALPHEX(2)	FEXH(2)				
.	.				
.	.				
ALPHEX(NTEXH)	FEXH(NTEXH)				
VALAIR					
CDA	WIDTHA				

---

EQUIVD = Desired trapped equivalence ratio. If a specified fuel flow rate is desired, then EQUIVD should be set to zero and WFUEL set to the amount of fuel injected per cycle.

RPM = Crankshaft speed, revolutions per minute.

PEXH = Exhaust pressure, psia.

PAIR = Intake manifold pressure, psia.

TAIR = Intake manifold temperature, deg R.

CR = Geometric Compression ratio

BORE = Bore, inches.

STROKE = Stroke, inches

CONROD = Connecting rod length, inches.

FPISTA = Ratio of piston surface area to crosssectional area of cylinder.

EVO = Crankangle at which exhaust valve opens, deg ATDC.

EVC = Crankangle at which exhaust valve closes, deg ATDC

AVO = Crankangle at which intake port opens, deg ATDC

AVC = Crankangle at which intake port closes, deg ATDC.

TWALL = Initial estimate of cylinder wall temperature, deg R.

WFUEL = Initial estimate of fuel injected be cycle, unless EQUIVD is zero in which case WFUEL is the actual fuel injected per cycle, Lbm.

ACB = Start of combustion, degrees ATDC.

ACF = End of combustion, degrees ATDC

ANNA = Parameter for heat transfer model

FMEPM = Multiplier for friction model

NPCWF = Parameter for selection of combustion model
 

- If NPCWF = -1 Whitehouse-Way model used
- If NPCWF = 0 and DEL3 = 0. AVL model used
- If NPCWF = 0 and DEL3 > 0. Wiebe model used
- If NPCWF = 1 Watson model used
- If NPCWF = 2 User supplied model

DEL1 = Parameter for combustion model

DEL2 = Parameter for combustion model

DEL3 = Parameter for combustion model

AAN(1) = Injection rate parameter for Whitehouse-Way combustion model

AAN(2) = Injection rate parameter for Whitehouse-Way combustion model

VALEXH = Parameter which determines whether an exhaust valve or port is used
 

- If VALEXH = 0., exhaust ports are used
- If VALEXH = 10., exhaust valves are used

CDE = Exhaust valve/port discharge coefficient

NTEXH = If an exhaust valve is used, NTEXH is the number of crankangle area combinations provided to specify the valve flow area

ALPHEX(I) = Array of crank positions at which valve flow area is specified.

FEXH(I) = Array of exhaust valve flow areas corresponding to ALPHEX(I).

VALAIR = Parameter which determines whether an intake port or valve is used  
           If VALAIR = 0., intake ports are used.  
           If VALAIR =10., intake valves are used.  
 CDA     = Intake port/valve discharge coefficient.  
 WIDTHA  = If an intake port is used, this parameter specifies the fraction of the circumference which is taken up by port area.

#### 4.2 Subroutine INPUT2

Below is listed the input data set required by the Steady State Heat Transfer Analysis. The variable names are provided below. The current version of the program has these variables defined within the subroutine INPUT2 although READ statements are provided to read these variables from an external file. Currently these READ statements have been made into comment statements.

---

TWEV	TWGH	TWGP	TWGC	TWEVG	
TC1	TC2	TC3			
NEXHV	DEXHV				
D1	D2	D3	D4	D5	D6
XXEVG	XXEVH	XXPSL			
XXPIS	XXPRG	XXHED			
XXPCR	XXRSL	XXSLV			
AEXVS	AEXST				
ASLEEV	APIST2				
APISTR	ARING1	ARING2			
CEXV	CHEAD	CSLEEV	CPIST	CRING	
HEXHP	HOILP	HCSL	HCHD		

---

TWEV = Initial estimate of the exhaust valve temperature, deg F.  
 TWGH = Initial estimate of the gas side head temperature, deg F.  
 TWGP = Initial estimate of the gas side piston temperature, deg F.  
 TWGC = Initial estimate of the gas side cylinder wall temperature, deg F.  
 TWEVG = Exhaust valve guide temperature, deg F.  
 TC1 = Piston cooling oil temperature, deg F.  
 TC2 = Cylinder wall coolant temperature, deg F.  
 TC3 = Head coolant temperature, deg F.  
 NEXHV = Number of exhaust valves

DEXHV = Diameter of exhaust valves, inches  
 D1 = Distance below piston surface of top ring groove, inches.  
 D2 = Depth of ring groove, inches.  
 D3 = Width of ring groove, inches.  
 D4 = Piston/cylinder wall clearance (piston is assumed centered in bore), inches.  
 D5 = Ring width, inches.  
 D6 = Ring depth, inches.  
 XXEVG = Heat transfer path length from exhaust valve to valve guide  
 XXEVH = Heat transfer path length from exhaust valve to valve seat  
 XXPSL = Heat transfer path length from piston to cylinder wall through lower rings and oil film  
 XXPIS = Heat transfer path length through piston  
 XXPRG = Heat transfer path length from piston rim to top compression ring  
 XXHED = Heat transfer path length through head  
 XXPCR = Heat transfer path length from piston crown to piston rim  
 XXRSL = Heat transfer path length from top compression ring to cylinder wall  
 XXSLV = Heat transfer path length through cylinder wall  
 AEXVS = Area of exhaust valve stem  
 AEXST = Exhaust valve seat contact area  
 ASLEEV = Characteristic area for heat transfer through cylinder wall  
 APIST2 = Surface area exposed to oil on underside of piston  
 APISTR = Characteristic area between piston crown and piston rim  
 ARING1 = Contact area between top compression ring and cylinder wall  
 ARING2 = Contact area between top compression ring and piston rim  
 CEXV = Thermal conductivity of exhaust valve  
 CHEAD = Thermal conductivity of head  
 CPIST = Thermal conductivity of piston  
 CRING = Thermal conductivity of ring  
 CSLEEV = Thermal conductivity of cylinder wall  
 HEXHP = Convection coefficient from back side of exhaust valve to gases in exhaust port  
 HOILP = Convection coefficient for cooling oil on backside of piston  
 HCSL = Convection coefficient for coolant on backside of cylinder wall  
 HCHD = Convection coefficient for coolant on backside of head

## 5.0 OUTPUT

The Benson program creates three output files containing the results of the engine simulation. The first file, written from UNIT 2, contains a summary of the input data and then the following results written for each iteration.

1. Fuel Flow
2. Scavenge Ratio
3. Trapping Efficiency
4. Scavenge Efficiency
5. Temperature Out (Exhaust)
6. Power
7. True Purity
8. Air Flow
9. Equivalence Ratio
10. Maximum Pressure
11. Maximum Temperature
12. Heat Loss (percent)

After the program has converged a summary of the heat transfer results is printed showing the metal part temperatures and the fraction of the heat transfer going to each part of the engine.

The second output file, UNIT 3, contains a listing of the cylinder pressure, temperature, specific heat ratio and volume as a function of crank angle for each iteration performed by the program. The last complete cycle of data corresponds to the cycle where the program converged.

The final output file, UNIT 4, contains a summary of the cycle data which is written at the end of each iteration. It includes the trapped pressure and temperature, the maximum pressure and temperature, the release pressure and temperature, the various gas exchange efficiencies described in section 7.1 and the indicated power. This data is printed for each iteration so the final listing corresponds to the listing for the converged cycle calculation.

## 6.0 SAMPLE CASES

### 6.1 Napier Nomad

The Napier Nomad was a combined cycle diesel engine developed during the early 1950's as a highly efficient aircraft engine. It is the most efficient aircraft engine ever flown, although the fuel economy of the Nomad did not provide sufficient advantage over the smaller, lighter gas turbine engine. In this example, the Benson program was combined with a simple compressor and turbine model to simulate the take-off performance of the Napier Nomad engine. Sufficient published data of the Nomad is available to confirm the analysis. The Nomad was liquid cooled, and the analysis was conducted assuming both oil and water cooling.

The input BLOCK DATA for this simulation is provided below. A summary of the results is presented in Table 6.1. A listing of the program which calls the Benson program including the turbomachinery is provided in Appendix 10.2.

```
DATA EQUIVD,RPM,PEXH,PAIR,TAIR /0.60,2050.,134.79,149.76,896./
DATA CR,BORE,STROKE,CONROD,FPISTE,FPISTA /11.17,6.00,7.375,
1 14.75,1.,1.13/
DATA EVO,EVC,AVO,AVC /105.,255.,130.,230./
DATA TWALL,WFUEL /1460.,0.0001/
DATA ACB,ACF /335.0,10./
DATA ANNA,FMEPM /0.30,1.25/
DATA NPCWF,DEL1,DEL2,DEL3,AAN(1),AAN(2) /-1,0.01457,0.667,0.4,
1 0.4,0.5/
DATA VALEXH,CDE,WIDTHE /0.,0.85,0.20/
DATA VALAIR,CDA,WIDTHA /0.,0.85,0.36/
```

Table 6.1

Napier Nomad

## Specifications:

Two Stroke, Loop Scavenged

12 Cylinders      Bore: 6.00 inches      Stroke: 7.375 inches

Effective Compression Ratio: 8.00

At Takeoff Power: Speed: 2050 rpm      Mean Piston Speed: 2520 ft/min

Inlet Manifold Pressure: 89 psia

Inlet Manifold Temperature: 475 F

Compressor Efficiency: 0.85

Turbine Efficiency: 0.84

Under Takeoff Conditions

	Published Data	Benson Program (Water Cooled)	Benson Program (Oil Cooled)
BMEP	205 psi	205.1 psi	205.4 psi
Peak Pressure	2200 psi	2186 psi	2205 psi
Air Flow	13 lb/sec	13.03 lb/sec	13.00 lb/sec
Turbine Inlet Temp	1222 F	1162 F	1199 F
Diesel Power (12 cyl)	2660 hp	2654 hp	2658 hp
Turbine Power	2250 hp	2374 hp	2424 hp
Compressor Power	1840 hp	1858 hp	1854 hp
Total Shaft Power	3070 hp	3169 hp	3228 hp
Overall BSFC	0.345 lb/hp-hr	0.339 lb/hp-hr	0.329 lb/hp-hr
Percent Heat Loss	NA	13.8 %	10.2 %
Head Temp	NA	782 F	1498 F
Piston Temp	NA	834 F	1008 F
Sleeve Temp	NA	791 F	1224 F

## 6.2 Garrett OCE

The Garrett Turbine Engine Company, under Army contract, used the Benson program to simulate a compound cycle engine suitable for use in a light helicopter. The engine proposed by Garrett is a 6 cylinder, two stroke diesel with two expansion turbines on the diesel exhaust. The first turbine drives the compressor for the diesel intake air and the second is a power turbine which is connected directly to the engine's output shaft. As in the above example, the Benson program was combined with a simple compressor and turbine model to simulate the Garrett design for a Compound Cycle Engine. Data for the predicted performance was supplied by Garrett in the final contract report. This data is compared below in Table 6.2 with the results of the simulation for both water and oil cooling. The input data set is also provided below. A listing of the main program used to simulate the Garrett engine is provided in Appendix 10.3.

```
DATA EQUIVD,RPM,PEXH,PAIR,TAIR /0.68,6122.,134.79,149.76,896./
DATA CR,BORE,STROKE,CONROD,FPISTE,FPISTA /9.1712,3.101,2.940,
1 7.168,1.,1.13/
DATA EVO,EVC,AVO,AVC /90.,239.,126.,234./
DATA TWALL,WFUEL /1460.,0.000145332/
DATA ACB,ACF /345.,10.5/
DATA ANNA,FMEPM /0.36,1.0/
DATA NPCWF,DEL1,DEL2,DEL3,AAN(1),AAN(2) /-1,0.01457,0.667,0.4,
1 0.4,0.5/
DATA VALEXH,CDE,NTEXH /10.,0.8864,13/
DATA VALAIR,CDA,WIDTHA /0.,0.8,0.5542/
DATA ALPHEX/0.00,10.97,25.00,31.61,41.00,52.25,72.89,90.95,104.00,
1 111.59,119.00,132.23,149.00,37*0./
DATA FEXH/0.0,0.00093264,0.00364,0.00591222,0.00899,0.0106201,
1 0.01175263,0.01111131,0.00923,0.00717895,0.00461,0.00181743,0.,
2 37*0./
```



Table 6.2

Garrett OCE

## Specifications:

Two Stroke, Uniflow Scavenged

6 Cylinders                      Bore: 3.101 inches                      Stroke: 2.940 inches

Effective Compression Ratio: 7.50

At Rated Power: Inlet Manifold Pressure: 149.79 psia

Inlet Manifold Temperature: 436 F

Compressor Efficiency: 0.79

Turbine Efficiency: 0.845, 0.848

Rated Power Conditions

	Published Data	Benson Program (Water Cooled)	Benson Program (Oil Cooled)
BMEP	400 psi	386.8 psi	386.5 psi
Peak Pressure	3364 psi	3401.1 psi	3429.2 psi
Air Flow	2.349 lb/sec	2.316 lb/sec	2.301 lb/sec
Turbine Inlet Temp	1752 F	1738 F	1785 F
Diesel Power (6 cyl)	824 hp	796.0 hp	795.5 hp
Turbine Power	226 hp	233.1 hp	248.6 hp
Fan Power	51 hp	51 hp	51 hp
Total Shaft Power	999 hp	978.1 hp	993.1 hp
Overall BSFC	0.328 lb/hp-hr	0.332 lb/hp-hr	0.323 lb/hp-hr
Percent Heat Loss	8.46 %	8.59 %	5.74 %
Head Temp	1244.3 F	1299.6 F	2078.3 F
Piston Temp	1279.3 F	1375.8 F	1571.3 F
Sleeve Temp	418.3 F	1344.8 F	1792.2 F

## 7.0 DOCUMENTATION OF SUBROUTINES

### 7.1 Subroutine BENSON

A simulation using the Benson program is initiated by a call to subroutine BENSON. There is no argument list for this subroutine. All data is passed into the subroutine through input files or COMMON blocks and all output data is written to the three output files discussed in Chapter 5.0.


Subroutine BENSON calls the input subroutines, the initialization subroutine, and then organizes the calls to CYLNDR and POWER to integrate the energy balance throughout the cycle. Examples of how BENSON is called from a main program are given in the Appendix for the sample cases of Chapter 6.0.

### 7.2 Subroutine BAL

This subroutine can be used for two purposes:

1. To find the enthalpy of combustion products given the fuel-air ratio and the temperature.
2. To find a final temperature of combustion products given an initial temperature and a rise in the enthalpy of the products.

For the combustion equation



the number of moles of products, per mole of air, are given by the following equations.

$$X_1 = 0.79$$

$$X_2 = 0.21 - X_3 - \frac{1}{2} X_4$$

$$X_3 = \frac{\text{lb fuel}}{\text{lb air}} \cdot \frac{\text{lb C}}{\text{lb fuel}} \cdot \frac{\text{lb air}}{\text{mole air}} \cdot \frac{\text{mole C}}{\text{lb C}} = \frac{\text{mole C}}{\text{mole air}}$$

$$= \text{FZA} \cdot \text{CARBON} \cdot 28.85 / 12.01$$

$$X_4 = \frac{\text{lb fuel}}{\text{lb air}} \cdot \frac{\text{lb H}_2}{\text{lb fuel}} \cdot \frac{\text{lb air}}{\text{mole air}} \cdot \frac{\text{mole H}_2}{\text{lb H}_2} = \frac{\text{mole H}_2}{\text{mole air}}$$

$$= \text{FZA} \cdot (1 - \text{CARBON}) \cdot 28.85 / 2.016$$

These quantities can be used to calculate mole fractions by summing the total number of moles and dividing each term by the total.

To accomplish the first purpose of this subroutine the user specifies the temperature and fuel/air ratio of the mixture as well as the mass fraction of carbon in the fuel and the subroutine calculates the mole fractions of the product gas composition and then evaluates fourth order polynomial curve fits to JANAF table data to obtain the enthalpy of the gas mixture at the specified temperature [1].

For the case where the subroutine is intended to locate a temperature given an initial temperature and an increment of enthalpy, the subroutine first evaluates the enthalpy at the specified initial temperature and adds the enthalpy increment to obtain the enthalpy of the unknown state. Then the subroutine guesses a temperature and tests whether the enthalpy at this temperature is the same as the unknown. If not, the program adjusts the temperature and checks again. Newton's method is used to speed convergence. When the enthalpy matches within 0.01%, the subroutine returns to the calling program.

The argument list for subroutine BAL is

SUBROUTINE BAL(CARBON,FZA,T1,DELH,T2,GAM,H3)

where CARBON is the mass fraction of carbon in the fuel

FZA is the fuel/air mass ratio

T1 is the initial temperature when the subroutine is being used to locate a second unknown temperature.

DELH is the enthalpy increment.

T2 is the temperature at which the enthalpy is desired or is the unknown temperature.

GAM is the ratio of specific heats evaluated at T2.

H3 is the enthalpy at T2.

### 7.3 Subroutine CYLNDR

This subroutine integrates the energy equation described earlier for the gas exchange portion of the cycle. The subroutine checks to see if the valves or ports are open and, if so, integrates the energy equation. If the valves are closed, then CYLNDR calls POWER to integrate the energy equation for the compression-expansion portion of the cycle. When the subroutine is called the first time step after the gas exchange has been completed, the subroutine totals the mass added and removed from the cylinder and calculates the various gas exchange efficiencies. These efficiencies are defined below.

Scavenging Efficiency: 
$$\frac{\text{mass of delivered air retained in cylinder}}{\text{mass of trapped cylinder charge}}$$

Purity: 
$$\frac{\text{mass of air in trapped cylinder charge}}{\text{total mass of trapped cylinder charge}}$$

Charging Efficiency based on Trapped Condition:

$$\frac{\text{mass of delivered air retained in cylinder}}{\text{Trapped volume} \times \text{trapped density}}$$

Charging Efficiency based on Inlet conditions and trapped volume:

$$\frac{\text{mass of delivered air retained in cylinder}}{\text{Trapped volume} \times \text{inlet density}}$$

Charging Efficiency based on inlet conditions and swept volume:

$$\frac{\text{mass of delivered air retained in cylinder}}{\text{Swept volume} \times \text{inlet density}}$$

Trapping Efficiency:  $\frac{\text{mass of delivered air retained in cylinder}}{\text{total mass of air delivered to cylinder}}$

Scavenge Ratio based on swept volume:

$$\frac{\text{total mass of air delivered to cylinder}}{\text{Swept volume} \times \text{inlet density}}$$

Scavenge Ratio based on trapped volume:

$$\frac{\text{total mass of air delivered to cylinder}}{\text{Trapped volume} \times \text{inlet density}}$$

Relative Charging Efficiency based on trapped volume:

$$\frac{\text{total mass of trapped cylinder charge}}{\text{Trapped volume} \times \text{inlet density}}$$

Relative Charging Efficiency based on swept volume:

$$\frac{\text{total mass of trapped cylinder charge}}{\text{Swept volume} \times \text{inlet density}}$$

#### 7.4 Subroutine CYLVOL

This subroutine takes the piston position and the piston velocity provided by STROK and calculates the cylinder volume and the rate of change of volume.

The volume at some crank position is equal to the sum of the volume displaced by the piston plus the displacement volume. The volume displaced by the piston is equal to the piston area times the distance between the top of the piston and its position at top dead center which is XSTROK as calculated by the subroutine STROK. The clearance volume can be expressed in terms of the compression ratio as

$$r = \frac{V_d + V_{cl}}{V_{cl}}$$

or

$$V_{cl} = \frac{V_d}{r - 1} = \frac{S \cdot \text{AREA}}{r - 1}$$

where  $V_{cl}$  is the clearance volume,

$V_d$  is the displacement volume

S is the stroke

AREA is the piston area

r is the compression ratio

Thus, the volume in the cylinder can be expressed as

$$V = \text{AREA} \cdot \text{XSTROK} + \frac{S \cdot \text{AREA}}{r - 1}$$

or

$$V = \text{AREA} \cdot \left[ \text{XSTROK} + \frac{S}{r - 1} \right]$$

The rate of change of the volume is equal to the derivative of this expression or in terms of DSTROK provided by the subroutine STROK,

$$\frac{dV}{d\theta} = \text{AREA} \cdot \text{DSTROK}$$

The argument list follows.

SUBROUTINE CYLVOL(FCYLG,XSTROK,STROKE,CRR,DSTROK,VCYLG,DVCYLG)

where FCYLG is the cross-sectional area of the cylinder

XSTROK is the piston position

STROKE is the engine stroke  
CRR is the compression ratio  
DSTROK is the piston velocity  
VCYLG is the volume  
DVCLYG is the rate of change of the volume

### 7.5 Subroutine ELIM

This subroutine is used to solve the system of nine linear algebraic equations developed by subroutine HTRANS for the metal part temperatures in the engine. The subroutine was copied from Gerald [8] and uses Gaussian elimination with partial pivoting. The argument list is as follows.

SUBROUTINE ELIM(AB,N,NP,NDIM)

where AB = Coefficient matrix augmented with vectors consisting of the right hand sides of the system equations (may be more than one set).

N = Number of equations.

NP = Total number of columns in the augmented matrix AB.

NDIM = First dimension of matrix AB in the calling program.

The solution vector(s) are returned in the augmentation columns of AB.

### 7.6 Subroutine FCLOSE

This subroutine closes the input/output files and states that the files created should be kept after completion of the program.

### 7.7 Subroutine FOPEN

This subroutine opens the input and output files which the Benson program reads from and writes to. Unit 1 is the input file and it is named DIESEL1.INP and units 2 through 5 are output files with names that can be specified by the user in the calling program. the user defined names are passed to FOPEN as 16 character names in the COMMON block named OPEN.

### 7.8 Subroutine HEADER

This subroutine writes titles and column headings to the output files and also writes out selected values of the input parameters so the particular run can be identified. The subroutine has no argument list and all data is passed into the subroutine through COMMON blocks /GEN/ and /CYL/.

### 7.9 Subroutine HTRANS

This subroutine executes the procedure described in Section 2.2 for calculating the engine part temperatures. The subroutine calculates the resistances described in that section and assembles the coefficient matrix for the system of algebraic equations for solution by subroutine ELIM. HTRANS also calculates the friction mean effective pressure due to the piston/ring friction so that the heat transfer terms associated with the dissipation of this friction can be added to the coefficient matrix. The terms for the crevice volume heat transfer are evaluated in subroutine POWER but are added to the coefficient matrix in HTRANS.

After solving the system equations by calling subroutine ELIM, the various heat transfer flow paths in the network diagram are summed to provide



a summary of the distribution of the heat transfer throughout the cylinder area. This data is provided to the main program through COMMON/HEAT1/ and COMMON/HEAT2/ and may be printed if desired.

#### 7.10 Subroutine INITLZ

This subroutine is called early in the execution of the Benson program to perform a variety of tasks necessary to starting the calculations. If necessary, input variables are converted to the proper dimensions and then many of the variables are nondimensionalized. Variables used in summing calculations are assigned initial values of zero. The values of the polynomial coefficients used to calculate gas properties are assigned in this subroutine based on curve fits to the JANAF table data. The subroutine has no argument list and all data is passed into the subroutine through COMMON blocks /XXX/, /GEN/ and /CYL/.

#### 7.11 Subroutine INPUT

This subroutine is used to supply the Benson program with input data about the specific engine application being simulated. The subroutine contains read statements for the essential data, however, these statements have been converted to comment statements and the data is either present as assignment statements in the subroutine or is assigned in the main calling program and then passed into the subroutine through COMMON/BNSN/. This was done so that the Benson program could be repeatedly called as a subroutine itself without having to reread the input data file for every run. INPUT has no argument list and all variables are passed through to the other subroutines

using COMMON blocks.

#### 7.12 Subroutine INPUT2

This subroutine is used to supply the Benson program with input data for the detailed heat transfer calculations. The subroutine contains READ statements for the data, however, these statements have been converted to comment statements and the data is assigned directly to the variables by executable statements within the subroutine. To change the values of these parameters the subroutine must be edited and then recompiled. The format of the input data file and the variable name list are given in Section 3.2.

#### 7.13 Subroutine MASSFL

Flow through the intake and exhaust ports and valves can be modeled as an adiabatic quasi-steady flow process. Potential energy effects are generally assumed negligible. With these assumptions, the energy balance for a control volume takes the following form.

$$h_1 + \frac{V_1^2}{2} = h_2 + \frac{V_2^2}{2}$$

where state 1 designates the upstream condition and state 2 is the condition at the minimum area section of the flow passage. Since state 1 is normally taken to be a stagnation condition,  $V_1$  can be assumed to be zero. Thus,

$$V_2 = [2(h_1 - h_2)]^{1/2}$$

or for constant specific heat

$$V_2 = [2 C_p (T_1 - T_2)]^{1/2}$$

Since the process is assumed isentropic, again for constant specific heats,

$$\frac{T_1}{T_2} = \left[ \frac{P_1}{P_2} \right]^{\frac{\gamma-1}{\gamma}}$$

where  $\gamma$  is the ratio of specific heats,  $C_p/C_v$ .

Substituting this expression into the equation for  $V_2$  gives

$$V_2 = \left[ 2 C_p T_2 \left[ \left( \frac{P_1}{P_2} \right)^{\frac{\gamma-1}{\gamma}} - 1 \right] \right]^{1/2}$$

if this velocity is divided by the speed of sound at state 2,  $a_2 = \sqrt{\gamma R T}$ ,

then a Mach number is obtained

$$U_m = \frac{V_2}{a_2} = \left[ \left( \frac{2}{\gamma-1} \right) \left[ \left( \frac{P_1}{P_2} \right)^{\frac{\gamma-1}{\gamma}} - 1 \right] \right]^{1/2}$$

if this Mach number is greater than or equal to 1., then the flow through the valve or port is choked and the velocity at section 2 will be sonic. If the Mach number is less than 1. then the flow is not choked and the velocity at section 2 will be given by the above expression.

The mass flow rate through the valve or port can be obtained from the continuity equation

$$\dot{m} = \rho A V$$

When this equation is applied at section 2 the following expression for mass flow through the valve or port is obtained.

$$\dot{m} = \rho_2 A_2 a_2 \left[ \left( \frac{2}{\gamma-1} \right) \left[ \left( \frac{P_1}{P_2} \right)^{\frac{\gamma-1}{\gamma}} - 1 \right] \right]^{1/2}$$

In the Benson program, the expression for mass flow rate is non-dimensionalized using several defined reference quantities. A list of these quantities follows.

$T_{ref}$  = Reference Temperature

$P_{ref}$  = Reference Pressure

$V_{\text{ref}}$  = Reference Volume

$F_{\text{ref}}$  = Reference Area

$X_{\text{ref}}$  = Reference length

$D_{\text{ref}}$  = Reference diameter

$a_{\text{ref}}$  = Reference speed of sound,  $a_{\text{ref}} = \sqrt{\gamma RT}$

$m_{\text{ref}}$  = Reference mass,  $m_{\text{ref}} = \frac{P_{\text{ref}} V_{\text{ref}}}{R T_{\text{ref}}} = \frac{\gamma P_{\text{ref}} V_{\text{ref}}}{a_{\text{ref}}^2}$

Using these reference quantities, which are assigned internally in the program, the mass flow equation can be rearranged to obtain the form used in the Benson program.

$$\dot{m} = \rho_2 A_2 a_2 U_m$$

but  $\rho_2 = \rho_1 \left[ \frac{P_2}{P_1} \right]$  and  $a_2 = \sqrt{\gamma RT_2}$

$$\dot{m} = \rho_1 \left[ \frac{P_2}{P_1} \right] A_2 \sqrt{\gamma RT_2} U_m$$

Now, from the equation defining the Mach number,

$$\frac{P_2}{P_1} = \left[ 1 + \frac{\gamma-1}{\gamma} U_m^2 \right]^{\frac{\gamma}{1-\gamma}}$$

So the mass flow can be arranged as

$$\dot{m} = \frac{\gamma P_1 A_2 U_m}{a_1 \left[ 1 + \frac{\gamma-1}{\gamma} U_m^2 \right]^{\frac{\gamma+1}{2(\gamma-1)}}}$$

The non-dimensional mass flow rate, WFLOW, is equal to

$$\text{WFLOW} = \frac{\dot{m}}{\left[ \frac{m_{\text{ref}} V_{\text{ref}}}{F_{\text{ref}} a_{\text{ref}}} \right]} = \frac{\left[ \frac{P_1}{P_{\text{ref}}} \right] \left[ \frac{A_2}{A_{\text{ref}}} \right] \text{FM}}{\text{AO } \gamma_{\text{ref}}}$$

where  $\text{AO} = \frac{a_1}{a_{\text{ref}}}$

$$\text{and } FM = \frac{\gamma U_m}{\left[ 1 + \frac{\gamma-1}{2} U_m^2 \right]^{\frac{\gamma+1}{2(\gamma-1)}}}$$

if the flow is choked, the equation is the same but FM becomes

$$FM = \gamma \left[ \left( \frac{2}{\gamma+1} \right)^{\frac{\gamma+1}{\gamma-1}} \right]^{1/2}$$

The argument for subroutine MASSFL follows.

SUBROUTINE MASSFL(FHOLE,RUP,RDP,AO,GR,G,WFLOW)

where FHOLE is the non-dimensional flow area,  $\left[ \frac{A_2}{A_{ref}} \right]$

RUP is the upstream pressure divided by the reference pressure

RDP is the downstream pressure divided by the reference pressure

AO is the ratio of the speed of sound at the upstream temperature  
to the reference speed of sound.

GR is the reference value of  $\gamma$ , the ratio of specific heats

G is  $\gamma$ , the ratio of specific heats

WFLOW is the non-dimensional mass flow rate

#### 7.14 Subroutine POWER

This subroutine integrates the energy balance equation for the compression-expansion portion of the cycle. The techniques used are the same as those described in detail in section 2.1 of this report.

Power is called by CYLNDR after the valves close indicating the start of the compression process. POWER calculates the gas properties at the start and end of each time step to obtain the internal energy and calculates the work and heat transfer. POWER also contains the combustion calculations resulting from the four combustion models. The amount of fuel burned is calculated and

multiplied by the constant volume heating value to obtain an effective heat release. This heat release is included in the energy balance. At the end of the expansion process, the indicated power and efficiency is calculated and printed to a file.

#### 7.15 Subroutine SPLFIT

This subroutine is used to interpolate between discrete data provided to define a valve flow area curve. The calling program provides the X and Y arrays of discrete data and a value of X at which an interpolated Y is required and the subroutine fits a spline curve to the data and evaluates the spline at X. The relevant argument list follows.

SUBROUTINE SPLFIT (O,O,NP,O,O.,XKX,O,FY,O,X,Y,ITRP)

where NP is the number of points describing the curve

XKX(I) is the NP X-values defining the curve (25 points max). These points must be in ascending order

FY(I) is the array of NP Y-values defining the curve (corresponding to the X-values)

X is the X-value where the function value is required

Y is the calculate function value at the desired X-value

ITRP is an error indicator.

#### 7.16 Subroutine SREA

This subroutine is used to calculate the surface area of the portion of the combustion chamber exposed to the combustion gases at a given crank position. This area will be the sum of the areas of the head surface, the

piston surface and the instantaneous exposed cylinder wall surface. Each of these areas is calculated as follows.

$$\text{Head Area} = \text{FPISTE} \frac{\pi}{4} (\text{BORE})^2$$

$$\text{Piston Area} = \text{FPISTA} \frac{\pi}{4} (\text{BORE})^2$$

$$\text{Cylinder Wall Area} = \pi (\text{BORE}) L$$

where FPISTE = the ratio of the head surface area to the cylinder cross-section

FPISTA = the ratio of the piston surface area to the cylinder cross-section

BORE = the cylinder diameter

L = the distance between the current position of the piston and its position at top dead center

Since the volume at any time is approximately equal to  $\frac{\pi}{4} (\text{BORE})^2 L$  it is possible to express the cylinder wall surface area in terms of the volume as

$$\text{Cylinder wall area} = \pi (\text{BORE}) \frac{4}{\pi (\text{BORE})^2} = \frac{4V}{\text{BORE}}$$

Using this relation, the total surface area can be expressed as

$$\text{AREA} = \frac{4V}{\text{BORE}} + (\text{FPISTE} + \text{FPISTA}) \frac{\pi}{4} (\text{BORE})^2$$

The subroutine SREA evaluates this equation for a given set of input arguments. The argument list follows.

SUBROUTINE SREA (SAREA,FCYLL,DCYLL,XR,DR,FPISTA,FPISTE)

where SAREA is the total surface area

FCYLL is equal to  $\frac{\pi}{4} (\text{BORE})^2$

DCYLL is the Bore

XR and DR are reference dimensions (assumed = 1. in the BENSON program)

### 7.17 Subroutine STROK

This subroutine calculates the piston position and the rate of change of piston position (piston velocity) for a specified engine geometry and at a specified crank angle. Ferguson [9] gives the following expression for the instantaneous cylinder volume for a reciprocating engine.

$$V = V_{cl} \left[ 1 + \frac{r-1}{2} \left[ 1 - \cos \theta + \frac{1}{\epsilon} [1 - (1 - \epsilon^2 \sin^2 \theta)^{1/2}] \right] \right]$$

where  $V_{cl}$  is the clearance volume

$r$  is the compression ratio

$\epsilon$  is a geometric ratio =  $\frac{2L}{S}$

$L$  is the connecting rod length

$S$  is the stroke

$\theta$  is the crank angle

By defining the quantity FNN

$$FNN = \left[ \frac{1}{\epsilon^2} - \sin^2 \theta \right]^{1/2}$$

and recognizing that the compression ratio is equal to  $\frac{V_d + V_{cl}}{V_{cl}}$  so that

$(r-1) = \frac{V_d}{V_{cl}}$  it can be shown that the volume can be expressed as

$$V = V_{cl} + \frac{V_d}{2} \left[ 1 - \cos \theta + \frac{1}{\epsilon} - FNN \right]$$

or

$$V = V_{cl} + \frac{\pi/4 b^2 S}{2} \left[ 1 - \cos \theta + \frac{1}{\epsilon} - FNN \right]$$

where  $b$  = bore

$V_d$  = displacement volume

The subroutine STROK calculates the quantity



$$X = \frac{S}{2} \left[ 1 - \cos \theta + \frac{1}{\epsilon} - FNN \right]$$

which is the distance between the top of the piston at the specified crank angle and its position at top dead center. Thus, at TDC, when  $\theta = 0$ , the value of  $X = 0$ . This value is provided in non-dimensional form by dividing by a reference length,  $XREF$

$$XSTROK = \frac{X}{XREF} = \frac{S}{2 XREF} \left[ 1 - \cos \theta + \frac{1}{\epsilon} - FNN \right]$$

The relation for the piston position can be differentiated with time to provide an expression for the piston velocity.

$$\begin{aligned} \frac{d[X]}{dt} &= \frac{S}{2} \left[ \frac{d(\cos \theta)}{dt} - \frac{d(FNN)}{dt} \right] \\ &= \frac{S}{2} \left[ \sin \theta + \frac{\sin 2\theta}{2 \cdot FNN} \right] \frac{d\theta}{dt} \\ &= \frac{S}{2} \left[ \sin \theta + \frac{\sin 2\theta}{2 FNN} \right] \cdot 2\pi \cdot REVENG \end{aligned}$$

where  $REVENG$  is the engine speed in rev/sec.

The piston speed can be non-dimensionalized by introducing a non-dimensional time parameter,  $ZREF = \frac{360 \cdot XREF \cdot REVREF}{AREF}$  where  $REVREF$  is a reference engine speed and  $AREF$  is a reference speed of sound.

$$DSTROK = \frac{1}{AREF} \left[ \frac{d[X]}{dt} \right] = \frac{\pi}{360} ZREF \left[ \frac{REVENG}{REVREF} \right] \left[ \frac{S}{XREF} \right] \left[ \sin \theta + \frac{\sin 2\theta}{2 \cdot FNN} \right]$$

The non-dimensional piston position and velocity supplied by subroutine STROK

are used by other routines in the Benson program to calculate such quantities as the cylinder volume and cylinder surface area.

The argument list follows.

SUBROUTINE STROK(XSTROK,DSTROK,THETAЕ,STROKE,CONROD,RPS,ZR)

where XSTROK is the nondimensional piston position returned by STROK

DSTROK is the nondimensional piston velocity returned by STROK

THETAЕ is the crank position

STROKE is the stroke normalized by XREF

CONROD is the connecting rod length normalized by XREF

RPS is the rotational speed of the engine, normalized by dividing by the reference engine speed

ZR is the nondimensional time parameter (ZREF)

#### 7.18 Subroutine UNITP

This subroutine is used to change the units of a pressure supplied as an input. The argument list follows.

SUBROUTINE UNITP (IA,IB,PP,PPB)

where IA and IB are used to designate the type of unit conversion desired, PP is the pressure which will be returned after having been multiplied by the appropriate conversion factor and PPB is the barometric pressure. PPB is required for conversions from gage pressure to absolute pressure. The values of IA and IB should be selected from the following choices.

<u>IA</u>	<u>IB</u>	<u>Conversion</u>
1	1	do nothing
1	2	do nothing
2	1	psia → bars (absolute)
2	2	bars (absolute) → psia
≠ 1,2	1	psig → bars (absolute)
≠ 1,2	2	bars (gage) → psia

### 7.19 Subroutine UNITT

This subroutine is used to change the units of a temperature supplied as an input. The argument list follows.

SUBROUTINE UNITT (IA,IB,TT)

where IA and IB are used to designate the type of unit conversion desired and TT is the temperature which will be returned after having been multiplied by the appropriate conversion factor. The values of IA and IB should be selected from the following choices.

<u>IA</u>	<u>IB</u>	<u>Conversion</u>
1	2	None
2	2	°K → °C
3	2	°K → °R
≠ 1,2,3	2	°K → °F
1	≠ 2	None
2	≠ 2	°C → °K
3	≠ 2	°R → °K
≠ 1,2,3	≠ 2	°F → °K

### 7.20 Subroutine UNITW

This subroutine is used to change the units of a mass supplied as an argument. The argument list follows.

SUBROUTINE UNITW (IA,IB,WW)

where IA and IB are used to designate the type of unit conversion desired and is the mass which will be returned after having been multiplied by the appropriate conversion factor. The values of IA and IB should be selected from the following choices.

<u>IA</u>	<u>IB</u>	<u>Conversion</u>
1	2	None
1	≠ 2	None
≠ 1	2	kg → lbm
≠ 1	≠ 2	lbm → kg

## 8.0 CONCLUSION

### 8.1 Suggestions for Future Work

The major weakness of thermodynamic modeling diesel engines is the lack of a reliable and simple way to predict the heat transfer and heat release rates. Correlations are available for both these quantities and they are available in the Benson program, however, these correlations were developed under conditions very different from those present in the proposed Compound Cycle Engine. Experimental measurements at speeds above 6000 RPM and boost pressures above 100 psia are not currently available in the technical literature. These measurements must be made and used to verify the correlations before they can be used reliably at these conditions.

The current combustion models in the Benson program are of two types. The Watson model, the AVL model and the Wiebe model are simple functional models and cannot be used to understand the details of the diesel combustion. The Whitehouse-Way model is an attempt to include some of the physics of the fuel injection and combustion processes in a model and so it has the potential to provide the predictive information required for design. However, the Whitehouse-Way model is based on an out-of-date understanding of diesel combustion. This model treats the spray from a droplet perspective whereas more modern approaches recognize that the droplets vaporize very quickly after entering the combustion chamber (especially in a highly rated engine) and the subsequent combustion has the characteristics of a gaseous turbulent diffusion flame. The more successful modern diesel combustion models are based on this

approach. A more modern combustion model should be added to the Benson program allowing the effects of parameters such as fuel injection pressure, injection duration, nozzle diameter, air swirl to be investigated.

Another useful feature that should be included in a model of the complete Compound Cycle Engine is second law thermodynamic analysis. Second law analysis is based on tracking the utilization and destruction of availability through the engine. Availability is defined as "the maximum amount of work that could be obtained by bringing a system into equilibrium with its surroundings." Availability enters the engine with the fuel and either leaves as work or is progressively destroyed by irreversible processes inside the engine. In contrast to conventional thermodynamic analysis which tracks energy through the system and cannot tell whether the energy could be profitably converted to work, second law analysis allows the sources of irreversibility in the engine to be identified and quantified so that their effect on the fuel efficiency of the engine can be determined.

## 8.2 Summary

This report documents the Benson Diesel Engine Simulation Program. This program is currently configured to simulate a loop or uniflow scavenged two stroke engine. The program can provide information about the effects of combustion timing, valve timing, heat release rate and other engine design and operating parameters. The program has been extended to include a more detailed heat transfer model that allows the prediction of metal part temperatures.

## 9.0 REFERENCES

1. JANAF Thermochemical Tables, 2nd Edition, National Bureau of Standards Publications, NSRDS-N35 37, Washington D.C., 1971.
2. Whitehouse, N.D. and Way, R.J.B., "A Simple Method for the Calculation of Heat Release Rates in Diesel Engines Based on the Fuel Injection Rate," Society of Automotive Engineers Paper No. 710134, (1971)
3. Whitehouse, N.D. and Way, R., "Rate of Heat Release in Diesel Engines and its Correlation with Fuel Injection Data," Proc Instn Mech Engrs, Vol. 184, Pt. 3J, pp. 17-27 (1969-70)
4. Watson, N., Pilley, A.D. and Marzouk, M., "A Combustion Correlation for Diesel Combustion Engine Simulation," Society of Automotive Engineers Paper No. 800029, (1980)
5. Annand, W.J.D., "Heat Transfer in the Cylinders of Reciprocating Internal Combustion Engines," Proc Instn Mech Engrs, Vol 177, No. 36, pp. 973-996. (1963)
6. Woschni, G., "A Universally Applicable Equation for the Instantaneous Heat Transfer Coefficient in the Internal Combustion Engine," Society of Automotive Engineers Paper No. 670931, (1967)
7. Bishop, J.N., "Effects of Design Variables on Friction and Economy," Society of Automotive Engineers Paper No. 812A, 1964.
8. Gerald, Curtis F., Applied Numerical Analysis, 2nd Edition, p.132.
9. Ferguson, C.R., Internal Combustion Engines, John Wiley and Sons, New York, 1986.

## 10.0 APPENDIX

### 10.1 Variable Name List

ACB = Start of Combustion  
ACF = End of Combustion  
AIR = An indicator of whether the intake valve/port is open or closed during the cycle (=0 when closed, =10 when open)  
AIRVMX = Maximum flow area of intake valves/ports  
ALPAIR = Array of crank positions corresponding to the intake valve flow areas given in FAIR, degrees.  
ALPHAT = Cumulative total crankangle during integration.  
ALPHEX = Array of crank positions corresponding to the exhaust valve flow areas given in FEXH, degrees.  
ANGEND = Maximum number of crank degrees allowed before integration is terminated.  
AAN(1) = Fuel injection parameters for Whitehouse-Way model.  
AAN(2) = Fuel injection parameters for Whitehouse-Way model.  
AVC = Intake valve/port closing angle, degrees.  
AVO = Intake valve/port opening angle, degrees.  
AREF = Reference value for speed of sound (based on TREF).  
ANNA, ANNB, ANNC = Parameter for Annand or Woschni Heat Transfer model.  
BETA = Parameter in Watson combustion model.  
CARBON = Mass fraction of carbon in fuel.  
CALVAL = Constant volume heat of combustion with water present as vapor in the products.  
CD1, CD2 = Parameters in Watson combustion model.  
CDA = Discharge Coefficient for intake valve/port.  
CDE = Discharge Coefficient for exhaust valve/port.  
CEFFYI = Charging efficiency based on inlet conditions and trapped volume.  
CHEFFY = Charging efficiency based on trapped conditions.  
CONDY = Thermal Conductivity of cylinder contents.  
CYCLE = 2 for a two stroke engine, = 4 for a four stroke engine.  
COEFFA, COEFFB, COEFFC, COEFFD = Coefficient for polynomial fit to JANAF tables.  
CP1, CP2 = Parameter in Watson Combustion model.  
CPT = Specific heat at constant pressure.  
CVT = Specific heat at constant volume.  
DEL1, DEL2, DEL3 = Parameter in either Wiebe or Whitehouse-Way combustion models.  
DHEAT = Heat transfer rate from cylinder during gas exchange.  
DREF = Reference diameter.



DZ = Nondimensional time increment.  
 DQF = Heat addition to cylinder due to combustion.  
 DQCR = Heat transfer from cylinder due to radiation.  
 DQCY = Heat transfer from cylinder due to convection.  
 ETI = Internal energy of gases in cylinder at start of time step.  
 ETF = Internal energy of gases in cylinder at end of time step.  
 EVC = Exhaust valve/port opening angle, degrees.  
 EVO = Exhaust valve/port closing angle, degrees.  
 EXH = An indicator of whether the exhaust valve/port is open or closed during the cycle. (=0 when closed, =10 when open).  
 EXHVMX = Maximum flow area of exhaust valves/ports.  
 FCYL = Crosssectional area of cylinder.  
 FMEP1, FMEP2, FMEP3 = Parameters in FMEP correlation.  
 FMEPM = Multiplier for FMEP correlation.  
 FPISTA = Ratio of surface area of piston top to crosssectional area of cylinder.  
 FPISTE = Ratio of surface area of head exposed to combustion chamber to crosssectional area of cylinder.  
 FAIR = Array specifying the geometric intake valve flow area.  
 FEXH = Array specifying the geometric exhaust valve flow area.  
 FREF = A reference area used to normalize areas in the program.  
 FZA = Fuel/air mass ratio.  
 GA = Ratio of specific heats for air.  
 GE = Ratio of Specific heats for exhaust products.  
 GREF = Reference ratio of specific heats.  
 HEATG = Total heat transfer during gas exchange.  
 HEATRF = Heat released due to combustion  
 HC1 ... HC8 = Integral of the convective coefficient times the area for steady state heat transfer analysis.  
 HCT1 ... HCT8 = Integral of the convective coefficient times the gas temperature times the area for steady state heat transfer analysis.  
 HTA = Enthalpy of air entering cylinder  
 HTF = Enthalpy of cylinder contents at end of time step.  
 NPCWF = Parameter which determines which combustion model is used in the program  
     when NPCWF.LT.0           Whitehouse-Way Model  
     when NPCWF.EQ.0 and DEL3.EQ.0   AVL Model  
     when NPCWF.EQ.0 and DEL3.GT.0   Wiebe Model  
     when NPCWF.GT.0           Watson Model  
 NTAIR = Number of points provided in ALPAIR and FAIR to specify the intake valve flow area. FAIR(NTAIR), ALPAIR(NTAIR)  
 NTEXH = Number of points provided in ALPHEX and FEXH to specify the exhaust valve flow area. FEXH(NTEXH), ALPHEX(NTEXH)  
 PBARAB = Barometric pressure.  
 PI = 3.141592654  
 PO2 = Partial pressure of oxygen.  
 PREF = Reference pressure.

PORTED = 1 for loop scavenged, = 2 for uniflow scavenged.  
 PVEL = Mean piston speed.  
 PURITY = Purity. Ratio of mass of air in trapped cylinder charge to total mass of trapped cylinder charge.  
 RELCHG = Relative charging efficiency based on trapped volume.  
 RELCHS = Relative charging efficiency based on swept volume.  
 REVENG = Engine speed, rev/sec.  
 REVREF = Reference engine speed, rev/sec.  
 REY = Reynolds number of cylinder contents.  
 SCAEFF = Scavenging Efficiency  
 SCASW = Scavenge ratio based on swept volume.  
 SCAVR = Scavenge ratio based on trapped volume.  
 STOIC = Stoichiometric fuel/air ratio.  
 SURFC = Surface area of cylinder wall exposed to combustion.  
 SURFH = Surface area of head exposed to combustion chamber.  
 SURFP = Surface area of piston.  
 TAIR = Temperature of air entering cylinder through intake.  
 TEXH = Exhaust temperature (initial estimate specified as input)  
 TREF = Reference temperature.  
 TREFF = Trapping Efficiency.  
 TWALL = Cylinder wall temperature.  
 VALAIR = 0 if engine has intake ports, = 10 if engine has intake valves.  
 VALEXH = 0 if engine has exhaust ports, = 10 if engine has exhaust valves.  
 VCYL = Cylinder volume.  
 VEFFYI = Charging efficiency based on inlet conditions and swept volume.  
 VISCTY = Viscosity of cylinder contents.  
 WABU = Mass of air required to burn fuel under stoichiometric conditions.  
 WAR = Water to air ratio.  
 WCA = Air retained in the cylinder.  
 WCAIR = Total mass of air trapped in cylinder.  
 WCHG = Mass of air plus residual in cylinder per cycle.  
 WCO = Total mass flow rate through exhaust valve.  
 WCYL = Total mass in cylinder.  
 WCYLT = Trapped mass in cylinder.  
 WIDTHA = Fraction of cylinder circumference allocated for intake ports.  
 WIDTHE = Fraction of cylinder circumference allocated for exhaust ports.  
 WFUEL = Mass of fuel injected per cycle.  
 WMW = Molecular weight.  
 WN(I) = Number of moles of species I.  
 WNA = Number of moles of air trapped in cylinder.  
 WNI(I) = Number of moles of each species present at start of time step.  
 WNF(I) = Number of moles of each species present at end of time step.

WNP = Increase in number of moles in cylinder due to  
combustion (moles air - moles products).  
WNR = Number of moles of residual trapped in cylinder.  
WNTF = Total number of moles of gases in cylinder.  
WRES = Mass of residual gases in cylinder.  
WTOT = Total mass in cylinder, air+residual+fuel

## 10.2 Napier Nomad program listing

### MAIN PROGRAM

```

CHARACTER*16 FNAME1,FNAME2,FNAME3,FNAME4
CHARACTER*2 INC1,INC2,INC3,INC4
COMMON/BNSN/ EQUIVD,RPM,PEXH,PAIR,TAIR,
1      CR,BORE,STROKE,CONROD,FPISTE,FPISTA,
2      EVO,EVC,AVO,AVC,
3      TWALL,WFUEL,
4      ACB,ACF,
5      ANNA,FMEPM,
6      NPCWF,DEL1,DEL2,DEL3,AAN(2),
7      VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),
8      VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)
COMMON/GEN/ALPHAT,ANGEND,ANGRES,AIRPO,EXHPO,IMOLS,
1      APAIR,APEXH,AREF,AP(2),
1      APN(2),CYCLE,DALPHA,
1      DREF,DZ,FREF,
1      IPOWER,IREV,GA,GE,GREF,IUNITL,
1      IUNITP,IUNITT,IUNITK,IUNITW,IUNITQ,
1      WAR,PBAR,PBARAB,
1      PI,PREF,REVENG,REVREF,RPAIR,RPEXH,RP(2),
1      RPN(2),STEP2,TEXH,TREF,VREF,WREF,XREF,
1      Z,ZREF,HAIR,HREF,SCMULT,NC
COMMON/COMB/ AIRFL,EQUIV,TEXHS,SHPS,FZA,HRD,SCASW,TREFF,SCAEFF,
1      AIRVMX,EXHVMX,PORTED,STOIC,WCO,BLBACK,FUELF,BHP
COMMON/OPEN/ FNAME1,FNAME2,FNAME3,FNAME4
COMMON/TEMP/TWEV,TWGH,TWGP,TWGC,TWCR,TWPR,TWCP,TWOC,TWCH,TEXHP,
1      TWEVG,TC1,TC2,TC3
COMMON/HEAT1/ QF,QFPC,QC,QCPC,A1,A1PC,A2,A2PC,A3,A3PC,A4,A4PC,
1      QCYL,QCYLPC
COMMON/HEAT2/ QEVG,QEVGPC,QEXHP,QEXHPC,
1      QTC1,QTC1PC,QTC2,QTC2PC,QTC3,QTC3PC,QOUT,QOUTPC
FNAME1='FILE01.AAA'
FNAME2='FILE01.BBB'
FNAME3='FILE01.CCC'
FNAME4='FILE01.DDD'
INC1='02'
INC2='03'
INC3='04'
INC4='05'

```

C

C

ASSUME COMPRESSOR PRESSURE RATIO AND PRESSURE RATIO ACROSS DIESEL

C

P2P1=6.0544

P6P5=1./1.171

C

C

INLET CONDITIONS

C

```

      T1=518.7
      P1=14.7
C
C COMPRESSOR OUTLET CONDITIONS
C
      ETACTT=0.85
      P2=P2P1*P1
      DUMMY=P2P1**0.2857 - 1.
      T2=T1*(DUMMY/ETACTT + 1.)
      WC=0.24*T1/ETACTT*DUMMY
C
C LOSSES TO AFTERCOOLER/AFTERCOOLER INLET CONDITIONS
C
      P3=0.98*P2
      P3=P2
      T3=T2
C
C AFTERCOOLER EXIT CONDITIONS
C
      E=0.4
      T4=T3-E*(T3-T1)
      P4=0.98*P3
      T4=T3
      P4=P3
C
C LOSSES TO DIESEL/DIESEL INLET CONDITIONS
C
      P5=P4
      T5=T4
      PAIR=P5
      TAIR=T5
      PEXH=P6P5*PAIR
C
C RUN DIESEL PROGRAM
C
      CALL BENSON
C
C EXHAUST CONDITIONS
C
      P6=PEXH
      T6=TEXHS
C
C LOSSES TO HIGH PRESSURE TURBINE/TURBINE INLET CONDITIONS
C
      P7=0.98*P6
      T7=T6
C
C TURBINE OUTLET CONDITIONS - WORK MATCHED TO COMPRESSOR REQUIREMENTS
C ASSUMES 2% LOSS TO BEARING FRICTION
C
      ICHK=0

```

```

      TS=T7
      P8=14.7
30    TM=(T8+T7)/2.
      CALL PROP(EQUIVD, TM, CPX, GX)
      ETAT1=0.84
      DUMMY=1.-(P8/P7)**((GX-1.)/GX)
      TS=T7*(1.-DUMMY*ETAT1)
      WT=ETAT1*CPX*T7*DUMMY*(FUELF+AIRFL)*3600./2544.
      IF(ICHK.EQ.1) GO TO 40
      ICHK=1
      GO TO 30
40    CONTINUE

```

C  
C

```

      TWOCF=TWOC*1.8-460.
      TWCPF=TWCP*1.8-460.
      TWCHF=TWCH*1.8-460.
      TWEVF=TWEV*1.8-460.
      TWGHF=TWGH*1.8-460.
      TWGPF=TWGP*1.8-460.
      TWPRF=TWPR*1.8-460.
      TWGCF=TWGC*1.8-460.
      TWCRF=TWCR*1.8-460.

```

C

```

      WRITE(2,1010)
1010  FORMAT(/5X,'ENGINE PART TEMPERATURES',40X,'HEAT TRANSFER SUMMARY')
      WRITE(2,1011) TWGH,TWGHF,QF,QFPC
1011  FORMAT(/2X,'GAS SIDE HEAD TEMPERATURE',7X,F8.1,' K',F11.1,' F',
1      12X,'FRICTION GENERATED HEAT TRANSFER',3X,F10.3,F11.2,' %')
      WRITE(2,1012) TWGP,TWGPF,QC,QCPC
1012  FORMAT(2X,'GAS SIDE PISTON CROWN TEMPERATURE',F7.1,' K',F11.1,
1      ' F',12X,'CREVICE VOLUME HEAT TRANSFER',F17.3,F11.2,' %')
      WRITE(2,1013) TWGC,TWGCF,A1,A1PC
1013  FORMAT(2X,'GAS SIDE SLEEVE TEMPERATURE',5X,F8.1,' K',F11.1,' F',
1      12X,'HEAT TRANSFER TO CYLINDER WALL',F15.3,F11.2,' %')
      WRITE(2,1014) TWEV,TWEVF,A2,A2PC
1014  FORMAT(2X,'EXHAUST VALVE TEMPERATURE',7X,F8.1,' K',F11.1,' F',
1      12X,'HEAT TRANSFER TO PISTON',4X,F18.3,F11.2,' %')
      WRITE(2,1015) TWPR,TWPRF,A3,A3PC
1015  FORMAT(2X,'PISTON RIM TEMPERATURE',10X,F8.1,' K',F11.1,' F',
1      12X,'HEAT TRANSFER TO HEAD',6X,F18.3,F11.2,' %')
      WRITE(2,1016) TWCR,TWCRF,A4,A4PC
1016  FORMAT(2X,'COMPRESSION RING TEMPERATURE',4X,F8.1,' K',F11.1,' F',
1      12X,'HEAT TRANSFER TO EXHAUST VALVE',F15.3,F11.2,' %')
      WRITE(2,1017) TWCH,TWCHF,QCYL,QCYLPC
1017  FORMAT(2X,'COOLANT SIDE HEAD TEMPERATURE',3X,F8.1,' K',F11.1,' F',
1      12X,'TOTAL HEAT INPUT TO NETWORK',3X,F15.3,F11.2,' %')
      WRITE(2,1018) TWCP,TWCPF
1018  FORMAT(2X,'OIL SIDE PISTON TEMPERATURE',5X,F8.1,' K',F11.1,' F')
      WRITE(2,1019) TWOC,TWOCF
1019  FORMAT(2X,'COOLANT SIDE SLEEVE TEMPERATURE',F9.1,' K',F11.1,' F')

```

```

WRITE(2,1002) QEVG,QEVGPC,QEXHP,QEXHPC,
1 QTC1,QTC1PC,QTC2,QTC2PC,QTC3,QTC3PC,QOUT,QOUTPC
1002 FORMAT(69X,'HEAT TRANSFER TO EXH VALVE GUIDE',3X,F10.3,F11.2,' %' /
1 69X,'HEAT TRANSFER TO EXHAUST PORT GASES',F10.3,F11.2,' %' /
2 69X,'HEAT TRANSFER TO PISTON COOLING OIL',F10.3,F11.2,' %' /
3 69X,'HEAT TRANSFER TO SLEEVE COOLING OIL',F10.3,F11.2,' %' /
4 69X,'HEAT TRANSFER TO HEAD COOLING OIL ',F10.3,F11.2,' %' /
5 69X,'TOTAL HEAT TRANSFER FROM NETWORK ',F10.3,F11.2,' %')

C
WC=-WC*(FUELF+AIRFL)*3600./2544.
THP=BHP+WC+WT
BSFC=FUELF/THP*3600.
WRITE(2,1030) BHP,WC,WT,THP,BSFC
1030 FORMAT(/3X,'DIESEL BRAKE POWER',F10.2,' HP' /
1 3X,'COMPRESSOR POWER',F12.2,' HP' /3X,'TURBINE POWER',F15.2,
2 ' HP' /3X,'TOTAL SHAFT POWER',F11.2,' HP' /3X,'BSFC',20X,F11.4)

C
CALL FCLOSE
STOP
END

C
BLOCK DATA
COMMON/BNSN/ EQUIVD,RPM,PEXH,PAIR,TAIR,
1 CR,BORE,STROKE,CONROD,FPISTE,FPISTA,
2 EVO,EVC,AVO,AVC,
3 TWALL,WFUEL,
4 ACB,ACF,
5 ANNA,FMEPM,
6 NPCWF,DEL1,DEL2,DEL3,AAN(2),
7 VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),
8 VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)

C
DATA EQUIVD,RPM,PEXH,PAIR,TAIR /0.60,2050.,134.79,149.76,896./
DATA CR,BORE,STROKE,CONROD,FPISTE,FPISTA /11.17,6.00,7.375,
1 14.75,1.,1.13/
DATA EVO,EVC,AVO,AVC /105.,255.,130.,230./
DATA TWALL,WFUEL /1460.,0.0001/
DATA ACB,ACF /335.0,10./
DATA ANNA,FMEPM /0.30,1.25/
DATA NPCWF,DEL1,DEL2,DEL3,AAN(1),AAN(2) /-1,0.01457,0.667,0.4,
1 0.4,0.5/
DATA VALEXH,CDE,WIDTHE /0.,0.85,0.20/
DATA VALAIR,CDA,WIDTHA /0.,0.85,0.36/
END

C
SUBROUTINE PROP(EQUIV,T,CPX,GX)
IF(EQUIV.GT.0.) GO TO 10
X1=0.
X2=0.
X3=0.21
X4=0.79

```

```

GO TO 20
10 CARBON=0.85561
   HC=12.011/1.008*(1.-CARBON)/CARBON
   ASTO=(2.+HC/2.)/2./0.21
   Y1=1.
   Y2=HC/2.
   Y3=ASTO/EQUIV*0.21 - 1. - HC/4.
   Y4=ASTO/EQUIV * 0.79
   YTOT=Y1+Y2+Y3+Y4
   X1=Y1/YTOT
   X2=Y2/YTOT
   X3=Y3/YTOT
   X4=Y4/YTOT
20 CP1=16.2-6.53E3/T+1.41E6/T**2
   CP2=19.86-597./SQRT(T)+7500./T
   CP3=11.515-172./SQRT(T)+1530./T
   CP4=9.47-3.47E3/T+1.16E6/T**2
   CPX=X1*CP1+X2*CP2+X3*CP3+X4*CP4
   AVM=X1*44.01+X2*18.016+X3*32.00+X4*28.01
   CPX=CPX/AVM
   RX=1545./778./AVM
   CVX=CPX-RX
   GX=CPX/CVX
   RETURN
   END

```



### 10.3 Garrett OCE program listing

#### MAIN PROGRAM

CHARACTER\*16 FNAME1,FNAME2,FNAME3,FNAME4

CHARACTER\*2 INC1,INC2,INC3,INC4

COMMON/BNSN/ EQUIVD,RPM,PEXH,PAIR,TAIR,

1 CR,BORE,STROKE,CONROD,FPISTE,FPISTA,

2 EVO,EVC,AVO,AVC,

3 TWALL,WFUEL,

4 ACB,ACF,

5 ANNA,FMEPM,

6 NPCWF,DEL1,DEL2,DEL3,AAN(2),

7 VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),

8 VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)

COMMON/GEN/ALPHAT,ANGEND,ANGRES,AIRPO,EXHPO,IMOLS,

1 APAIR,APEXH,AREF,AP(2),

1 APN(2),CYCLE,DALPHA,

1 DREF,DZ,FREF,

1 IPOWER,IREV,GA,GE,GREF,IUNITL,

1 IUNITP,IUNITT,IUNITK,IUNITW,IUNITQ,

1 WAR,PBAR,PBARAB,

1 PI,PREF,REVENG,REVREF,RPAIR,RPEXH,RP(2),

1 RPN(2),STEP2,TEXH,TREF,VREF,WREF,XREF,

1 Z,ZREF,HAIR,HREF,SCMULT,NC

COMMON/COMB/ AIRFL,EQUIV,TEXHS,SHPS,FZA,HRD,SCASW,TREFF,SCAEFF,

1 AIRVMX,EXHVMX,PORTED,STOIC,WOO,BLBACK,FUELF,BHP

COMMON/OPEN/ FNAME1,FNAME2,FNAME3,FNAME4

COMMON/TEMP/TWEV,TWGH,TWGP,TWGC,TWCR,TWPR,TWCP,TWOC,TWCH,TEXHP,

1 TWEVG,TC1,TC2,TC3

COMMON/HEAT1/ QF,QFPC,QC,QCPC,A1,A1PC,A2,A2PC,A3,A3PC,A4,A4PC,

1 QCYL,QCYLPC

COMMON/HEAT2/ QEVG,QEVGPC,QEXHP,QEXHPC,

1 QTC1,QTC1PC,QTC2,QTC2PC,QTC3,QTC3PC,QOUT,QOUTPC

FNAME1='FILE01.AAA'

FNAME2='FILE01.BBB'

FNAME3='FILE01.CCC'

FNAME4='FILE01.DDD'

INC1='02'

INC2='03'

INC3='04'

INC4='05'

C

C

ASSUME COMPRESSOR PRESSURE RATIO AND PRESSURE RATIO ACROSS DIESEL

C

P2P1=10.61

P6P5=1./1.111

C

C

INLET CONDITIONS

C

T1=518.7

```

      P1=14.7
C
C COMPRESSOR OUTLET CONDITIONS
C
      ETACTT=0.79
      P2=P2P1*P1
      DUMMY=P2P1**0.2857 - 1.
      T2=T1*(DUMMY/ETACTT + 1.)
      WC=0.24*T1/ETACTT*DUMMY
C
C LOSSES TO AFTERCOOLER/AFTERCOOLER INLET CONDITIONS
C
      P3=0.98*P2
      P3=P2
      T3=T2
C
C AFTERCOOLER EXIT CONDITIONS
C
      E=0.4
      T4=T3-E*(T3-T1)
      P4=0.98*P3
C
C LOSSES TO DIESEL/DIESEL INLET CONDITIONS
C
      P5=P4*0.98
      T5=T4
      PAIR=P5
      TAIR=T5
      PEXH=P6P5*PAIR
C
C RUN DIESEL PROGRAM
C
      CALL BENSON
C
C EXHAUST CONDITIONS
C
      P6=PEXH
      T6=TEXHS
C
C LOSSES TO HIGH PRESSURE TURBINE/TURBINE INLET CONDITIONS
C
      P7=0.98*P6
      T7=T6
C
C AFTERBURNER OUTLET CONDITIONS
C
      F=0.0
      TIN=T6
      CALL TBURN(EQUIVD,F,TIN,TOUT)
      T7=TOUT
      XFUEL=F*(AIRFL+FUELF)

```

```

C
C   TURBINE OUTLET CONDITIONS - WORK MATCHED TO COMPRESSOR REQUIREMENTS
C   ASSUMES 2% LOSS TO BEARING FRICTION
C
      ICHK=0
      T8=T7
30  TM=(T8+T7)/2.
      CALL PROP(EQUIVD, TM, CPX, GX)
      ETAT1=0.845
      WT1=1.02*WC
      P8=P7*(1.-WT1/(ETAT1*CPX*T7))*((GX/(GX-1.)))
      DUMMY=1.-(P8/P7)*((GX-1.)/GX)
      T8=T7*(1.-DUMMY*ETAT1)
      IF(ICHK.EQ.1) GO TO 40
      ICHK=1
      GO TO 30
40  CONTINUE
C
C   LOSSES BETWEEN TURBINES/POWER TURBINE INLET CONDITIONS
C
      P9=0.98*P8
      T9=T8
C
C   POWER TURBINE OUTLET CONDITIONS
C
      ICHK=0
      T10=T9
50  TM=(T9+T10)/2.
      CALL PROP(EQUIVD, TM, CPX, GX)
      WRITE(6,*) 'CPX,GX',CPX,GX
      P10=14.7
      ETAT2=0.848
      DUMMY=1.-(P10/P9)*((GX-1.)/GX)
      T10=T9*(1.-DUMMY*ETAT2)
      IF(ICHK.EQ.1) GO TO 60
      ICHK=1
      GO TO 50
60  CONTINUE
      WT2=ETAT2*CPX*T9*DUMMY*(FUELF+AIRFL)*3600./2544.
C
      WRITE(6,*) 'T9,P9,T10,P10',T9,P9,T10,P10
C
      TWCCF=TWCC*1.8-460.
      TWCPF=TWCP*1.8-460.
      TWCHF=TWCH*1.8-460.
      TWEVF=TWEV*1.8-460.
      TWGHF=TWGH*1.8-460.
      TWGPF=TWGP*1.8-460.
      TWPRF=TWPR*1.8-460.
      TWGCF=TWGC*1.8-460.
      TWCRF=TWCR*1.8-460.

```

C

```

WRITE(2,1010)
1010 FORMAT(/5X,'ENGINE PART TEMPERATURES',40X,'HEAT TRANSFER SUMMARY')
WRITE(2,1011) TWGH,TWGHF,QF,QFPC
1011 FORMAT(/2X,'GAS SIDE HEAD TEMPERATURE',7X,F8.1,' K',F11.1,' F',
1 12X,'FRICTION GENERATED HEAT TRANSFER',3X,F10.3,F11.2,' %')
WRITE(2,1012) TWGP,TWGPf,QC,QPC
1012 FORMAT(2X,'GAS SIDE PISTON CROWN TEMPERATURE',F7.1,' K',F11.1,
1 ' F',12X,'CREVICE VOLUME HEAT TRANSFER',F17.3,F11.2,' %')
WRITE(2,1013) TWGC,TWGCf,A1,A1PC
1013 FORMAT(2X,'GAS SIDE SLEEVE TEMPERATURE',5X,F8.1,' K',F11.1,' F',
1 12X,'HEAT TRANSFER TO CYLINDER WALL',F15.3,F11.2,' %')
WRITE(2,1014) TWEV,TWEVf,A2,A2PC
1014 FORMAT(2X,'EXHAUST VALVE TEMPERATURE',7X,F8.1,' K',F11.1,' F',
1 12X,'HEAT TRANSFER TO PISTON',4X,F18.3,F11.2,' %')
WRITE(2,1015) TWPR,TWPRf,A3,A3PC
1015 FORMAT(2X,'PISTON RIM TEMPERATURE',10X,F8.1,' K',F11.1,' F',
1 12X,'HEAT TRANSFER TO HEAD',6X,F18.3,F11.2,' %')
WRITE(2,1016) TWCR,TWCRf,A4,A4PC
1016 FORMAT(2X,'COMPRESSION RING TEMPERATURE',4X,F8.1,' K',F11.1,' F',
1 12X,'HEAT TRANSFER TO EXHAUST VALVE',F15.3,F11.2,' %')
WRITE(2,1017) TWCH,TWCHf,QCYL,QCYLPC
1017 FORMAT(2X,'COOLANT SIDE HEAD TEMPERATURE',3X,F8.1,' K',F11.1,' F',
1 12X,'TOTAL HEAT INPUT TO NETWORK',3X,F15.3,F11.2,' %')
WRITE(2,1018) TWCP,TWCPf
1018 FORMAT(2X,'OIL SIDE PISTON TEMPERATURE',5X,F8.1,' K',F11.1,' F')
WRITE(2,1019) TWCC,TWCCf
1019 FORMAT(2X,'COOLANT SIDE SLEEVE TEMPERATURE',F9.1,' K',F11.1,' F')
WRITE(2,1002) QEVG,QEVGPC,QEXHP,QEXHPC,
1 QTC1,QTC1PC,QTC2,QTC2PC,QTC3,QTC3PC,QOUT,QOUTPC
1002 FORMAT(69X,'HEAT TRANSFER TO EXH VALVE GUIDE',3X,F10.3,F11.2,' %'/
1 69X,'HEAT TRANSFER TO EXHAUST PORT GASES',F10.3,F11.2,' %'/
2 69X,'HEAT TRANSFER TO PISTON COOLING OIL',F10.3,F11.2,' %'/
3 69X,'HEAT TRANSFER TO SLEEVE COOLING OIL',F10.3,F11.2,' %'/
4 69X,'HEAT TRANSFER TO HEAD COOLING OIL ',F10.3,F11.2,' %'/
5 69X,'TOTAL HEAT TRANSFER FROM NETWORK ',F10.3,F11.2,' %')

```

C

```

FANP=51./6.
THP=BHP+WT2-FANP
BSFC=(FUELF+XFUEL)/THP*3600.
WRITE(2,1030) BHP,WT2,FANP,THP,BSFC
1030 FORMAT(/3X,'DIESEL BRAKE POWER',F10.2,' HP'/
1 3X,'TURBINE POWER',F15.2,' HP'/
2 3X,'FAN POWER ',F15.2,
3 ' HP'/3X,'TOTAL SHAFT POWER',F11.2,' HP'/3X,'BSFC',15X,F11.4)
WRITE(6,*) 'BSFC = ',BSFC

```

C

```

CALL FCLOSE
STOP
END

```

C

# BLOCK DATA

COMMON/BNSN/ EQUIVD,RPM,PEXH,PAIR,TAIR,

```
1      CR,BORE,STROKE,CONROD,FPISTE,FPISTA,
2      EVO,EVC,AVO,AVC,
3      TWALL,WFUEL,
4      ACB,ACF,
5      ANNA,FMEPM,
6      NPCWF,DEL1,DEL2,DEL3,AAN(2),
7      VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),
8      VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)
```

C\*\*\*\*\*

```
DATA EQUIVD,RPM,PEXH,PAIR,TAIR /0.68,6122.,134.79,149.76,896./
DATA CR,BORE,STROKE,CONROD,FPISTE,FPISTA /9.1712,3.101,2.940,
1  7.168,1.,1.13/
DATA EVO,EVC,AVO,AVC /90.,239.,126.,234./
DATA TWALL,WFUEL /1460.,0.000145332/
DATA ACB,ACF /345.,10.5/
DATA ANNA,FMEPM /0.36,1.0/
DATA NPCWF,DEL1,DEL2,DEL3,AAN(1),AAN(2) /-1,0.01457,0.667,0.4,
1  0.4,0.5/
DATA VALEXH,CDE,NTEXH /10.,0.8864,13/
DATA VALAIR,CDA,WIDTHA /0.,0.8,0.5542/
DATA ALPHEX/0.00,10.97,25.00,31.61,41.00,52.25,72.89,90.95,104.00,
1  111.59,119.00,132.23,149.00,37*0./
DATA FEXH/0.0,0.00093264,0.00364,0.00591222,0.00899,0.0106201,
1  0.01175263,0.01111131,0.00923,0.00717895,0.00461,0.00181743,0.,
2  37*0./
END
```

C

```
SUBROUTINE PROP(EQUIV,T,CPX,GX)
IF(EQUIV.GT.0.) GO TO 10
X1=0.
X2=0.
X3=0.21
X4=0.79
GO TO 20
10 CARBON=0.85561
HC=12.011/1.008*(1.-CARBON)/CARBON
ASTO=(2.+HC/2.)/2./0.21
Y1=1.
Y2=HC/2.
Y3=ASTO/EQUIV*0.21 - 1. - HC/4.
Y4=ASTO/EQUIV * 0.79
YTOT=Y1+Y2+Y3+Y4
X1=Y1/YTOT
X2=Y2/YTOT
X3=Y3/YTOT
X4=Y4/YTOT
20 CP1=16.2-6.53E3/T+1.41E6/T**2
CP2=19.86-597./SQRT(T)+7500./T
CP3=11.515-172./SQRT(T)+1530./T
```

```

CP4=9.47-3.47E3/T+1.16E6/T**2
CPX=X1*CP1+X2*CP2+X3*CP3+X4*CP4
AVM=X1*44.01+X2*18.016+X3*32.00+X4*28.01
CPX=CPX/AVM
RX=1545./778./AVM
CVX=CPX-RX
GX=CPX/CVX
RETURN
END

```

C

```

SUBROUTINE TBURN(EQUIV,F,T1,T2)
HV=18600.
CALL PROP(EQUIV,T1,CP1,G1)
T537=537.
CALL PROP(EQUIV,T537,CPO,G0)
CPAVE=(CP1+CPO)/2.
DELH1=CPAVE*(T1-T537)
DELH=DELH1+HV*F

```

C

```

CARBON=0.85561
STOIC=1./((CARBON/12.01+(1.-CARBON)/(1.008*4.))*(32.0+3.76*28.0))
EQUIV2=(F+1.)*EQUIV + F/STOIC

```

C

```

WRITE(6,*) 'STOIC,EQUIV2',STOIC,EQUIV2
TOLD=2300.

```

```

CALL PROP(EQUIV2,TOLD,CP2,G2)
T537=537.
CALL PROP(EQUIV2,T537,CPO,G0)
CPAVE=(CP2+CPO)/2.
DELH2=CPAVE*(TOLD-T537)*(1.+F)
ZOLD=DELH2-DELH
TNEW=TOLD*1.05

```

```

25 CALL PROP(EQUIV2,TNEW,CP2,G2)
CPAVE=(CP2+CPO)/2.
DELH2=CPAVE*(TNEW-T537)*(1.+F)
ZNEW=DELH2-DELH
DELT=ZNEW*(TNEW-TOLD)/(ZOLD-ZNEW)
T2=TNEW+DELT
WRITE(6,*) 'ZNEW,T2',ZNEW,T2
IF(ABS(DELT).LT. 0.001) GO TO 50
TOLD=TNEW
TNEW=T2
ZOLD=ZNEW
GO TO 25
50 WRITE(6,*) 'DELH,DELH2',DELH,DELH2
RETURN
END

```

C  
C

#### 10.4 Benson Program Listing

```
C  VARIABLE NAMES:
C  ACBB = DUMMY VARIABLE USED TO STORE ACB, START OF COMBUSTION
C  ACFF = DUMMY VARIABLE USED TO STORE ACF, END OF COMBUSTION
C  AIR  = AN INDICATOR OF WHETHER INTAKE VALVE/PORT IS OPEN OR
C        CLOSED DURING THE CYCLE (=0 WHEN CLOSED, =10 WHEN
C        OPEN.
C  ALPAIR = ARRAY OF CRANK POSITIONS CORRESPONDING TO THE INTAKE
C          VALVE FLOW AREAS GIVEN IN FAIR, DEGREES (INPUT)
C  ALPHAT = CUMULATIVE TOTAL CRANKANGLE DURING INTEGRATION
C  ALPHEX = ARRAY OF CRANK POSITIONS CORRESPONDING TO THE EXHAUST
C          VALVE FLOW AREAS GIVEN IN FEHX, DEGREES (INPUT)
C  ANGEND = MAXIMUM NUMBER OF CRANK DEGREES ALLOWED BEFORE
C          INTEGRATION IS TERMINATED
C  AAN(1) = FUEL INJECTION PARAMETER FOR WHITEHOUSE-WAY MODEL
C
C  AAN(2) = FUEL INJECTION PARAMETER FOR WHITEHOUSE-WAY MODEL
C  ACB  = BEGINNING OF INJECTION WHEN NPCWF.LT.0
C        BEGINNING OF HEAT RELEASE WHEN NPCWF.GT.0
C  ACF  = END OF INJECTION WHEN NPCWF.LT.0
C        END OF HEAT RELEASE WHEN NPCWF.GT.0
C  AVC  = INTAKE VALVE/PORT OPENING ANGLE, DEGREES
C  AVO  = INTAKE VALVE/PORT CLOSING ANGLE, DEGREES
C  AREF  = REFERENCE VALUE FOR SPEED OF SOUND (BASED ON TREF)
C  ANNA  = PARAMETER FOR ANNAND OR WOSCHNI HEAT TRANSFER MODEL
C  ANNB  = PARAMETER FOR ANNAND OR WOSCHNI HEAT TRANSFER MODEL
C  ANNC  = PARAMETER FOR ANNAND OR WOSCHNI HEAT TRANSFER MODEL
C  BETA  = PARAMETER IN WATSON COMBUSTION MODEL
C  CARBON = MASS FRACTION OF CARBON IN FUEL
C  CD1   = PARAMETER IN WATSON COMBUSTION MODEL
C  CD2   = PARAMETER IN WATSON COMBUSTION MODEL
C  CYCLE = 2 FOR TWO CYCLE ENGINE, = 4 FOR FOUR CYCLE ENGINE
C  COEFA = COEFFICIENT FOR POLYNOMIAL FIT TO JANAF TABLES
C  COEFB = COEFFICIENT FOR POLYNOMIAL FIT TO JANAF TABLES
C  COEFC = COEFFICIENT FOR POLYNOMIAL FIT TO JANAF TABLES
C  COEFD = COEFFICIENT FOR POLYNOMIAL FIT TO JANAF TABLES
C  CP1   = PARAMETER IN WATSON COMBUSTION MODEL
C  CP2   = PARAMETER IN WATSON COMBUSTION MODEL
C  CYCLE = 2 FOR TWO STROKE ENGINE, = 4 FOR A FOUR STROKE ENGINE
C  SURFC = SURFACE AREA OF CYLINDER WALL EXPOSED TO COMBUSTION
C  DEL1  = PARAMETER FOR EITHER WIEBE OR WHITEHOUSE-WAY MODEL
C  DEL2  = PARAMETER FOR EITHER WIEBE OR WHITEHOUSE-WAY MODEL
C  DEL3  = PARAMETER FOR EITHER WIEBE OR WHITEHOUSE-WAY MODEL
C  DHEAT = HEAT TRANSFER RATE FROM CYLINDER DURING GAS EXCHANGE
C  DQF   = HEAT ADDITION TO CYLINDER DUE TO COMBUSTION
C  DQCR  = HEAT TRANSFER FROM CYLINDER DUE TO RADIATION
C  DQCY  = HEAT TRANSFER FROM CYLINDER DUE TO CONVECTION
C  ETI   = INTERNAL ENERGY OF GASES IN CYLINDER AT START OF
C          TIME STEP
C  ETF   = INTERNAL ENERGY OF GASES IN CYLINDER AT END OF
```

C           TIME STEP  
 C   EVC   = EXHAUST VALVE/PORT OPENING ANGLE, DEGREES  
 C   EVO   = EXHAUST VALVE/PORT CLOSING ANGLE, DEGREES  
 C   EXH   = AN INDICATOR OF WHETHER THE EXHAUST VALVE/PORT IS OPEN  
 C           OR CLOSED DURING THE CYCLE. (=0 WHEN CLOSED, =10 WHEN  
 C           OPEN)  
 C   FCYL   = CROSSECTIONAL AREA OF CYLINDER  
 C   FMPE1   = PARAMETER IN FMPE CORRELATION  
 C   FMPE2   = PARAMETER IN FMPE CORRELATION  
 C   FMPE3   = PARAMETER IN FMPE CORRELATION  
 C   FPISTA = RATIO OF SURFACE AREA OF PISTON TOP TO CROSSECTIONAL  
 C           AREA OF CYLINDER  
 C   FPISTE = RATIO OF SURFACE AREA OF HEAD EXPOSED TO COMBUSTION  
 C           CHAMBER TO CROSSECTIONAL AREA OF CYLINDER  
 C   FAIR   = ARRAY SPECIFYING THE GEOMETRIC INTAKE VALVE FLOW AREA  
 C   FEXH   = ARRAY SPECIFYING THE GEOMETRIC EXHAUST VALVE FLOW AREA  
 C   FREF   = A REFERENCE AREA USED TO NORMALIZE AREAS IN THE PROGRAM  
 C   FZA    = FUEL/AIR MASS RATIO  
 C   GA     = RATIO OF SPECIFIC HEATS FOR AIR  
 C   GE     = RATIO OF SPECIFIC HEATS FOR EXHAUST PRODUCTS  
 C   GREF   = REFERENCE RATIO OF SPECIFIC HEATS (INPUT)  
 C   HEATG   = TOTAL HEAT TRANSFER DURING GAS EXCHANGE  
 C   NPCWF   = PARAMETER WHICH DETERMINES WHICH COMBUSTION MODEL IS  
 C           USED IN THE PROGRAM  
 C           WHEN NPCWF.LT.0   WHITEHOUSE-WAY MODEL  
 C           WHEN NPCWF.EQ.0 AND DEL3.EQ.0   AVL MODEL  
 C           WHEN NPCWF.EQ.0 AND DEL3.GT.0   WIEBE MODEL  
 C           WHEN NPCWF.GT.0   WATSON MODEL  
 C   NTAIR   = NUMBER OF POINTS PROVIDED IN ALPAIR AND FAIR TO SPECIFY  
 C           THE INTAKE VALVE FLOW AREA. FAIR(NTAIR), ALPAIR(NTAIR)  
 C   NTEXH   = NUMBER OF POINTS PROVIDED IN ALPEX AND FEXH TO SPECIFY  
 C           THE EXHAUST VALVE FLOW AREA. FEXH(NTEXH), ALPEX(NTEXH)  
 C   PO2     = PARTIAL PRESSURE OF OXYGEN  
 C   PORTED = 1 FOR LOOP SCAVENGED, = 2 FOR UNIFLOW SCAVENGED  
 C   STOIC   = STOICHIOMETRIC FUEL/AIR RATIO  
 C   SURFP   = SURFACE AREA OF PISTON  
 C   SURFH   = SURFACE AREA OF HEAD EXPOSED TO COMBUSTION CHAMBER  
 C   TAIR    = TEMPERATURE OF AIR ENTERING CYLINDER THROUGH INTAKE  
 C   TEXH    = EXHAUST TEMPERATURE (INITIAL ESTIMATE SPECIFIED AS INPUT)  
 C   TREF    = REFERENCE TEMPERATURE (INPUT)  
 C  
 C   TWALL   = CYLINDER WALL TEMPERATURE  
 C   VALAIR = 0 IF ENGINE HAS INTAKE PORTS, = 10 IF ENGINE HAS  
 C           INTAKE VALVES  
 C   VALEXH = 0 IF ENGINE HAS EXHAUST PORTS, = 10 IF ENGINE HAS  
 C           EXHAUST VALVES  
 C   WABU    = MASS OF AIR REQUIRED TO BURN FUEL UNDER STOICHIOMETRIC  
 C           CONDITIONS, MASS UNITS  
 C   WCA     = AIR RETAINED IN CYLINDER PER CYCLE, MASS UNITS  
 C   WCHG    = MASS OF AIR PLUS RESIDUAL IN CYLINDER PER CYCLE, MASS UNITS  
 C   WCO     = TOTAL MASS FLOW RATE THROUGH EXHAUST VALVE, MASS/TIME  
 C   WIDTHA = FRACTION OF CYLINDER BORE OCCUPIED BY INTAKE PORTS  
 C   WIDTHE = FRACTION OF CYLINDER BORE OCCUPIED BY EXHAUST PORTS  
 C   WFUEL   = MASS OF FUEL INJECTED PER CYCLE, MASS UNITS



C     WMW   = MOLECULAR WEIGHT  
 C     WN(I) = NUMBER OF MOLES OF SPECIES I  
 C     WNA   = NUMBER OF MOLES OF AIR TRAPPED IN CYLINDER  
 C     WNI(I) = NUMBER OF MOLES OF EACH SPECIES PRESENT AT START OF  
 C           TIME STEP  
 C     WNF(I) = NUMBER OF MOLES OF EACH SPECIES PRESENT AT END OF  
 C           TIME STEP  
 C     WNP   = INCREASE IN NUMBER OF MOLES IN CYLINDER DUE TO  
 C           COMBUSTION (MOLS AIR —MOLES PRODUCTS)  
 C     WNR   = NUMBER OF MOLES OF RESIDUAL TRAPPED IN CYLINDER  
 C     WNTF  = TOTAL NUMBER OF MOLES OF GASES IN CYLINDER, GMOLES  
 C     WORKGA = WORK DONE WHEN VALVES ARE CLOSED  
 C     WORKGE = WORK DONE DURING GAS EXCHANGE  
 C     WRES  = MASS OF RESIDUAL GASES IN CYLINDER, MASS UNITS  
 C     WTOT  = TOTAL MASS IN CYLINDER, AIR+RESIDUAL+FUEL, MASS UNITS  
 C  
 C  
 C  
 C

SUBROUTINE BENSON  
 C     CYLINDER PRESSURE, TEMPERATURE, VOLUME ON DIESEL3.OUT  
 C     IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)  
 COMMON/BNSN/ EQUIVZ,RPZ,PEXZ,PAIZ,TAIZ,  
 1       CZ,BORZ,STROKZ,CONROZ,FPISTY,FPISTZ,  
 2       EVOZ,EVCZ,AVOZ,AVCZ,  
 3       TWALLZ,WFUEZ,  
 4       ACBZ,ACFZ,  
 5       ANNAZ,FMEPMZ,  
 6       NPCWFZ,DEL1Z,DEL2Z,DEL3Z,AANZ(2),  
 7       VALEXZ,CDEZ,NTEXHZ,WIDTZE,ALPHEZ(50),FEXHZ(50),  
 8       VALAIZ,CDAZ,NTAIRZ,WIDTZA,ALPAIZ(50),FAIRZ(50)  
 COMMON/XXX/ EQUIVD,RPM,PEXH,PAIR,TAIR,  
 1       CR,BORE,STROKE,CONROD,FPISTE,FPISTA,  
 2       EVO,EVC,AVO,AVC,  
 3       TWALL,WFUEL,  
 4       ACB,ACF,  
 5       ANNA,FMEPM,  
 6       NPCWF,DEL1,DEL2,DEL3,AAN(2),  
 7       VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),  
 8       VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)  
 COMMON/GEN/ALPHAT,ANGEND,ANGRES,AIRPO,EXHPO,IMOLS,  
 1       APAIR,APEXH,AREF,AP(2),  
 1       APN(2),CYCLE,DALPHA,  
 1       DREF,DZ,FREF,  
 1       IPOWER,IREV,GA,GE,GREF,IUNITL,  
 1       IUNITP,IUNITT,IUNITK,IUNITW,IUNITQ,  
 1       WAR,PBARAB,  
 1       PI,PREF,REVENG,REVREF,RPAIR,RPEXH,RP(2),  
 1       RPN(2),STEP2,TEXH,TREF,VREF,WREF,XREF,  
 1       Z,ZREF,HAIR,HREF,SCMULT,NC  
 COMMON/CYL/ACSB,ALPHA,ALPHAE,ANNB,ANNC,AC,  
 1       ACN,ACR,ALPHAC,  
 1       CALVAL,CARBON,  
 1       COEFFA(4),COEFFB(4),COEFFC(4),COEFFD(4),  
 1       COEFFE(4),COEFFZ(4),CRANK,DCYL,DHEAT,

```

1      DRC,DVCYL,DWCIN,DWCP(2),DWCYL,
1      FCYL,HEATG,
1      PURITY,PVEL,PCR,PCYLT,
1      PORTS,RC,RCN,RCR,SURFC,
1      TCR,TCYLT,VSWEPT,
1      VCYL,WCAIR,WCIN,
1      WCOU,WCYL,WMW(4),WPCNT(4),WCYLR,
1      WN(4),WORKGA,WORKGE,XCRA,XSTA,
1      NCD,WCYLT,DWCINT,
1      TPIST,THEAD,TEXV,CID
COMMON/COMB/AIRFL,EQUIV,TEXHS,SHPS,FZA,HRD,SCASW,TREFF,SCAEFF,
+ AIRVMX,EXHVMX,PORTED,STOIC,WCO,BLBACK,FUELF,BHP
COMMON/HEAT/NHEAT,QSLEV1,QPIST1,QHEAD1,QEXHV1,QTOT1,
1      QSLEV2,QPIST2,QHEAD2,QEXHV2,QTOT2,
2      HC1,HC2,HC3,HC4,HC5,HC6,HC7,HC8,
3      HCT1,HCT2,HCT3,HCT4,HCT5,HCT6,HCT7,HCT8
COMMON/STOP/ISTOP
WRITE(6,*) 'INSIDE BENSON'
EQUIVD=EQUIVZ
RPM=RPZ
PEXH=PEXZ
PAIR=PAIZ
TAIR=TAIZ
CR=CZ
BORE=BORZ
STROKE=STROKZ
CONROD=CONROZ
FPISTE=FPISTY
FPISTA=FPISTZ
EVO=EVOZ
EVC=EVCZ
AVO=AVOZ
AVC=AVCZ
TWALL=TWALLZ
WFUEL=WFUEZ
ACB=ACBZ
ACF=ACFZ
ANNA=ANNAZ
FMEPM=FMEPMZ
NPCWF=NPCWFZ
DEL1=DEL1Z
DEL2=DEL2Z
DEL3=DEL3Z
AAN(1)=AANZ(1)
AAN(2)=AANZ(2)
VALEXH=VALEXZ
CDE=CDEZ
NTEXH=NTEXHZ
WIDTHE=WIDTZE
VALAIR=VALAIZ
CDA=CDAZ
NTAIR=NTAIRZ
WIDTHA=WIDTZA
DO 444 I=1,50

```

```

      ALPHEX(I)=ALPHEZ(I)
      FEXH(I)=FEXHZ(I)
      ALPAIR(I)=ALPAIZ(I)
444 FAIR(I)=FAIRZ(I)
C
C
      ISTOP=0
      ZERO=0.0
      ONE=1.0
      PI=3.1415927
C
C SELECT HEAT TRANSFER MODEL
C
      NHEAT=1
C
C OPEN OUTPUT DATA FILES
C
      CALL FOPEN
      WRITE(6,*) 'RETURNED FROM FOPEN'
C
C This section gets and prints the time and date of this run on the outputs
C
      CALL GETTIM (Ihour, Iminut, IDUM1, IDUM2)
      CALL GETDAT (IYEAR, IMONTH, IDAY)
      DO 2 IZZZ=2,4
      WRITE(IZZZ,1) IMONTH, IDAY, IYEAR, Ihour, Iminut
C 1  FORMAT(' DATE: ',I2,'/',I2,'/',I4,15X,'TIME: ',I2,':',I2)
C 2 CONTINUE
C
      TEXHS = 0.
      SHPS = 0.
      FZA = 0.
      EQUIV = .5
      AIRVMX = 0.
      EXHVMX = 0.
C
      CALL INPUT
      WRITE(6,*) 'RETURNED FROM INPUT'
C
      CALL INPUT2
      WRITE(6,*) 'RETURNED FROM INPUT2'
C
      CALL HEADER
      WRITE(6,*) 'RETURNED FROM HEADER'
C
      WRITE(3,2048)
2048 FORMAT (4X, 5HANGLE,5X, 8HPRESSURE,3X,11HTEMPERATURE,4X,
+ 5HGAMMA,5X, 6HVOLUME,5X, 9HMEAN TEMP/)
      JJJJ=1
      Z=0.000
      CALL UNITP(IUNITP,1,PREF,PBARAB)
C SET UP TEMPERATURES TO S.I. UNITS
      CALL UNITT(IUNITT,1,TREF)
      AREF=SQRT(287.1*GREF*TREF)

```

```

C ENTER CALCULATION FIRST TIME
  XREF=1.
  DREF=1.
  FREF=1.
  VREF=1.
  WREF=GREF*PREF*VREF*1.0E5/AREF**2
  ZREF=360.0*XREF*REVREF/AREF
  REVENG=REVENG/REVREF
  CALL UNITT(IUNITT,1,TEXH)
  CALL UNITT(IUNITT,1,TAIR)
  CALL UNITP(IUNITP,1,PEXH,PBARAB)
  CALL UNITP(IUNITP,1,PAIR,PBARAB)
  CALL BAL(0.,0.,0.,0.,TAIR,GA,HAIR)
  CALL BAL(0.,0.,0.,0.,TREF,DUM,HREF)
  WRITE(6,*) 'ENTERING LOOP'

C
6 RPEXH=PEXH/PREF
  RPAIR=PAIR/PREF
  APEXH=(SQRT(0.287E3*GE*TEXH))/AREF
  AAEXH=APEXH/RPEXH**((GE-1.0)/(2.0*GE))
  APAIR=(SQRT(0.287E3*GA*TAIR))/AREF

C
  DZ = STEP2/(ZREF*REVENG)
  Z = Z+DZ
  ALPHAT = Z*ZREF*REVENG

C
  IF (JJJJ.EQ.1) CALL INITLZ

C
  CALL CYLINDR(JJJJ)

C
C CHECK TO SEE IF CALCULATION IS COMPLETED
C
  IF(ISTOP.EQ.1) GO TO 999

C
C CHECK TO SEE IF MAXIMUM NUMBER OF ITERATIONS IS EXCEEDED
C
  IF(ALPHAT.GT.ANGEND) GO TO 7
  JJJJ=2
C REENTER CALCULATION AGAIN
  GO TO 6
7 CONTINUE
  WRITE(6,*) 'MAXIMUM NUMBER OF ITERATIONS EXCEEDED'

C
C This section gets and prints the time and date of this run on the outputs
C
C  CALL GETTIM (IHOURL,IMINUT,IDUM1,IDUM2)
C  CALL GETDAT (IYEAR,IMONTH,IDAY)
C  DO 4 IZZZ=2,4
C    WRITE(IZZZ,3) IMONTH,IDAY,IYEAR,IHOURL,IMINUT
C  3  FORMAT(' DATE: ',I2,'/',I2,'/',I4,15X,'TIME: ',I2,':',I2)
C  4 CONTINUE

C
C
C999 CALL FCLOSE

```

999 CONTINUE

RETURN  
END

C

SUBROUTINE INITLZ

COMMON/XXX/ EQUIVD, RPM, PEXH, PAIR, TAIR,

1 CR, BORE, STROKE, CONROD, FPISTE, FPISTA,  
2 EVO, EVC, AVO, AVC,  
3 TWALL, WFUEL,  
4 ACB, ACF,  
5 ANNA, FMEPM,  
6 NPCWF, DEL1, DEL2, DEL3, AAN(2),  
7 VALEXH, CDE, NTEXH, WIDTHE, ALPHEX(50), FEXH(50),  
8 VALAIR, CDA, NTAIR, WIDTHA, ALPAIR(50), FAIR(50)  
COMMON/GEN/ALPHAT, ANGEND, ANGRES, AIRPO, EXHPO, IMOLS,

1 APAIR, APEXH, AREF, AP(2),  
1 APN(2), CYCLE, DALPHA,  
1 DREF, DZ, FREF,  
1 IPOWER, IREV, GA, GE, GREF, IUNITL,  
1 IUNITP, IUNITT, IUNITK, IUNITW, IUNITQ,  
1 WAR, PBARAB,  
1 PI, PREF, REVENG, REVREF, RPAIR, RPEXH, RP(2),  
1 RPN(2), STEP2, TEXH, TREF, VREF, WREF, XREF,  
1 Z, ZREF, HAIR, HREF, SCMULT, NC  
COMMON/CYL/ACSB, ALPHA, ALPHAE, ANNB, ANNC, AC,

1 ACN, ACR, ALPHAC,  
1 CALVAL, CARBON,  
1 COEFFA(4), COEFFB(4), COEFFC(4), COEFFD(4),  
1 COEFFE(4), COEFFZ(4), CRANK, DCYL, DHEAT,  
1 DRC, DVCYL, DWCIN, DWCP(2), DWCYL,  
1 FCYL, HEATG,  
1 PURITY, PVEL, PCR, PCYLT,  
1 PORTS, RC, RCN, RCR, SURFC,  
1 TCR, TCYLT, VSWEPT,  
1 VCYL, WCAIR, WCIN,  
1 WCOU, WCYL, WMW(4), WPCNT(4), WCYLR,  
1 WN(4), WORKGA, WORKGE, XCRA, XSTA,  
1 NCD, WCYLT, DWCINT,  
1 TPIST, THEAD, TEXV, CID

COMMON/COMB/AIRFL, EQUIV, TEXHS, SHPS, FZA, HRD, SCASW, TREFF, SCAEFF,  
+ AIRVMX, EXHVMX, PORTED, STOIC, WCO, BLBACK, FUELF, BHP

C \*\*\*\*\*

C CONVERT TO SI UNITS

C \*\*\*\*\*

11 DCYL=DCYL/3.281  
XSTA=XSTA/3.281  
XCRA=XCRA/3.281  
IF (VALEXH.EQ.0.0) GO TO 15  
DO 14 N=1, NTEXH  
14 FEXH(N)=FEXH(N)/3.281\*\*2  
15 IF (VALAIR.EQ.0.0) GO TO 17  
DO 16 N=1, NTAIR  
16 FAIR(N)=FAIR(N)/3.281\*\*2  
17 CALL UNITP (IUNITP, 1, PCYLT, PBARAB)

```

      CALL UNITT(IUNITT,1,TCYLT)
      IF (IUNITW.EQ.1) GO TO 22
      WFUEL=WFUEL/2.205
22  CALL UNITT(IUNITT,1,TWALL)
      CALL UNITT(IUNITT,1,TPIST)
      CALL UNITT(IUNITT,1,THEAD)
      CALL UNITT(IUNITT,1,TEXV)
C *****
C  ENTER ENTHALPY AND VISCOSITY COEFFICIENTS, MOLECULAR WEIGHT
C  JANAF CURVE FIT 400 K TO 2400 K
C *****
      COEFFA(1)=3.00845
      COEFFA(2)=2.94628
      COEFFA(3)=3.29003
      COEFFA(4)=3.50953
      COEFFB(1)=6.15041E-4
      COEFFB(2)=1.03617E-3
      COEFFB(3)=2.69417E-3
      COEFFB(4)=6.54488E-4
      COEFFC(1)=-1.09800E-7
      COEFFC(2)=-3.39775E-7
      COEFFC(3)=-8.66074E-7
      COEFFC(4)=9.41722E-8
      COEFFD(1)=5.68186E-12
      COEFFD(2)=4.75627E-11
      COEFFD(3)=1.11529E-10
      COEFFD(4)=-3.43661E-11
      DO 49 I=1,4
49  COEFFE(I)=8.3143*((COEFFA(I)-1.)*TREF+COEFFB(I)*TREF**2+
      + COEFFC(I)*TREF**3+COEFFD(I)*TREF**4)
      COEFFZ(1)=4.46E-7
      COEFFZ(2)=5.4E-7
      COEFFZ(3)=3.72E-7
      COEFFZ(4)=3.27E-7
      WMW(1)=28.016
      WMW(2)=32.000
      WMW(3)=44.010
      WMW(4)=18.016
      IMOLS=0
C  SET UP ANGLES FOR EACH CYLINDER
      ALPHAC=EVO-CRANK
      IF (ALPHAC.LT.0.) ALPHAC=ALPHAC+180.*CYCLE
C  SET UP NON-DIMENSIONAL PARAMETERS
      FCYL=(PI/4.0)*DCYL**2
30  IF (VALEXH.EQ.0.0) GO TO 31
      DO 32 N=1,NTEXH
32  FEXH(N)=FEXH(N)/FREF
      GO TO 33
31  CONTINUE
      ZERO=0.0
43  CALL STROK(EXHP0,ZERO,EVO,XSTA,XCRA,REVENG,ZREF)
33  IF (VALAIR.EQ.0.0) GO TO 34
      DO 35 N=1,NTAIR
35  FAIR(N)=FAIR(N)/FREF

```

```

      GO TO 36
34  ZERO=0.0
      CALL STROK(AIRPO,ZERO,AVO,XSTA,XCRA,REVENG,ZREF)
36  PVEL=2.0*XSTA*XREF*REVREF*REVENG
      WORKGA=0.
      WORKGE=0.
      HEATG=0.
      IMOLS=100
C
      CALL POWER(1,0)
C
37  CONTINUE
      RCR=PCR/PREF
      ACR=SQRT(0.287E3*GE*TCR)/AREF
C *****
C  CALCULATE INITIAL CONDITIONS IN CYLINDER
C *****
      DST=1.0
      CALL STROK(XST,DST,EVO,XSTA,XCRA,REVENG,ZREF)
      CALL CYLVOL(FCYL,XST,XSTA,CR,DST,VCYL,DVCYL)
39  VCYL=XSTA*FCYL
      DVCYL=0.0
41  CONTINUE
      WCYL=GE*RCR*VCYL/(((ACR)**2)*GREF)
      WCYLR=WCYL
      DRC=0.
      RC=RCR
      AC=ACR
      WORKGA=0.0
      WORKGE=0.0
      HEATG=0.0
      WCIN=0.0
      SUMIMP=0.
      SUMCAP=0.
      WCOUT=0.0
      AIRNET=0.
      WCAIR=0.0
      DWCYL=0.0
      RETURN
      END

      SUBROUTINE CYLNDR(JJJJ)
      DIMENSION XMOL(4)
C  IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)
      COMMON/XXX/ EQUIVD,RPM,PEXH,PAIR,TAIR,
1      CR,BORE,STROKE,CONROD,FPISTE,FPISTA,
2      EVO,EVC,AVO,AVC,
3      TWALL,WFUEL,
4      ACB,ACF,
5      ANNA,FMEPM,
6      NPCWF,DEL1,DEL2,DEL3,AAN(2),
7      VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),
8      VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)
      COMMON/GEN/ALPHAT,ANGEND,ANGRES,AIRPO,EXHPO,IMOLS,

```

```

1      APAIR, APEXH, AREF, AP(2),
1      APN(2), CYCLE, DALPHA,
1      DREF, DZ, FREF,
1      IPOWER, IREV, GA, GE, GREF, IUNITL,
1      IUNITP, IUNITT, IUNITK, IUNITW, IUNITQ,
1      WAR, PBARAB,
1      PI, PREF, REVENG, REVREF, RPAIR, RPEXH, RP(2),
1      RPN(2), STEP2, TEXH, TREF, VREF, WREF, XREF,
1      Z, ZREF, HAIR, HREF, SCMULT, NC
COMMON/CYL/ACSB, ALPHA, ALPHAЕ, ANNB, ANNC, AC,
1      ACN, ACR, ALPHAC,
1      CALVAL, CARBON,
1      COEFFA(4), COEFFB(4), COEFFC(4), COEFFD(4),
1      COEFFE(4), COEFFZ(4), CRANK, DCYL, DHEAT,
1      DRC, DVCYL, DWCIN, DWCP(2), DWCYL,
1      FCYL, HEATG,
1      PURITY, PVEL, PCR, PCYLT,
1      PORTS, RC, RCN, RCR, SURFC,
1      TCR, TCYLT, VSWEPT,
1      VCYL, WCAIR, WCIN,
1      WCOUT, WCYL, WMW(4), WPCNT(4), WCYLR,
1      WN(4), WORKGA, WORKGE, XCRA, XSTA,
1      NCD, WCYLT, DWCINT,
1      TPIST, THEAD, TEXV, CID
COMMON/COMB/AIRFL, EQUIV, TEXHS, SHPS, FZA, HRD, SCASW, TREFF, SCAEFF,
+ AIRVMX, EXHVMX, PORTED, STOIC, WCO, BLBACK, FUELF, BHP
COMMON/CPURE/WCA, WCHG, IMIX
COMMON/ENERGY/ UINITL, UFINAL, HOUT
COMMON/TEMP/TWEV, TWGH, TWGP, TWGC, TWCR, TWPR, TWCP, TWCC, TWCH, TEXHP,
1  TWEVG, TC1, TC2, TC3
COMMON/INPT2/
1  XXEVG, XXEVH, XXPSL, XXPIS, XXPRG, XXHED, XXPCR, XXPSL, XXSLV,
2  AEXVS, AEXV, AEXST, AHEAD, ASLEEV, APIST1, APIST2, APISTR, ARING1, ARING2,
3  CEXV, CHEAD, CSLEEV, CPIST, CRING,
4  HEXHP, HOILP, HCSL, HCHD, NEXHV, DEXHV,
5  D1, D2, D3, D4, D5, D6, VCV, APP, ARR, ASS
COMMON/HEAT/ NHEAT, QSLEV1, QPIST1, QHEAD1, QEXHV1, QTOT1,
1  QSLEV2, QPIST2, QHEAD2, QEXHV2, QTOT2,
2  HC1, HC2, HC3, HC4, HC5, HC6, HC7, HC8,
3  HCT1, HCT2, HCT3, HCT4, HCT5, HCT6, HCT7, HCT8
COMMON/STOP/ ISTOP
RPS=REVENG*REVREF
2  CONTINUE
ACN=AC
RCN=RC
NEX=1
APN(NEX)=AP(NEX)
RPN(NEX)=RP(NEX)
C  SET UP CRANK ANGLE
101 ALPHAC=ALPHAC+DZ*ZREF*REVENG
IF (ALPHAC.LT.180.0*CYCLE) GO TO 52
ALPHAC=ALPHAC-180.0*CYCLE
52 ALPHA=ALPHAC
ALPHAЕ=ALPHA

```



```

C *****
C TEST IF CYLINDER OPEN TO EXHAUST AFTER FIRST REVOLUTION
C     IF SO, START GAS EXCHANGE CALCULATIONS
C     IF NOT, GO TO STATEMENT 12 WHICH INITIALIZES
C     VARIABLES AND RETURNS TO MAIN
C *****
C     CRANK=CRANK-DZ*ZREF*REVENG
C     IF (CRANK.LE.0.0) GO TO 102
C     150 DWCP(NEX)=0.
C     151 PORTS=0.0
C     GO TO 12
C SET UP CYLINDER CONDITIONS
C     102 RC=RC+DZ*DRC
C     WCYL=WCYL+DZ*DWCYL
C *****
C CALCULATE CYLINDER VOLUME, VOLUME CHANGE AND SURFACE AREA
C *****
C     DVCYLE=0.0
C     DST=1.0
C     CALL STROK (XST,DST,ALPHA,XSTA,XCRA,REVENG,ZREF)
C     XHTA=XST
C     CALL CYLVOL (FCYL,XST,XSTA,CR,DST,VCYL,DVCYL)
C     FPISTE=1.0
C     CALL SREA (SURFC,VCYL,FCYL,DCYL,XREF,DREF,
C     1 FPISTA,FPISTE)
C CALCULATE SURFACE AREA OF SLEEVE
C     SURFC=SURFC-(FPISTA+FPISTE)*FCYL
C CALCULATE SURFACE AREA OF PISTON
C     SURFP=FPISTA*FCYL
C CALCULATE SURFACE AREA OF EXHAUST VALVE(S)
C     SURFE=FLOAT(NEXHV)*0.7854*DEXHV**2/(39.37)**2
C CALCULATE SURFACE AREA OF HEAD
C     SURFH=FPISTE*FCYL-SURFE
C CALCULATE AC
C     AC=SQRT(GE*RC*VCYL/(WCYL*GREF))
C *****
C TEST WHETHER PORTS AND VALVES ARE OPEN, IF SO, SET FLAGS
C *****
C     AIR=10.
C     IF (ALPHA.GE.AVC .OR. ALPHA.LE.AVO) AIR=0.0
C     EXH=10.
C     IF (ALPHA.GE.EVC .OR. ALPHA.LE.EVO) EXH=0.0
C *****
C TEST WHETHER GAS EXCHANGE IS COMPLETE
C     IF SO, PRINT OUT MASS FLOW TOTALS
C     CALCULATE GAS EXCHANGE EFFICIENCIES
C     CALL POWER TO DO COMBUSTION CALCULATIONS
C *****
C HAS COMPRESSION STARTED YET?
C     IF (ALPHA.LT.ACSB) GO TO 152
C     DALPHA=DZ*ZREF*REVENG
C IS THIS THE FIRST TIME STEP AFTER GAS EXCHANGE? IF SO, DO CALCULATIONS.
C     OTHERWISE, SKIP TO BOTTOM
C     IF (ALPHA-ACSB.GT.DALPHA*0.99) GO TO 152

```

```

C   IF (ALPHA-ACSB.GE.DALPHA) GO TO 152
C *****
C   PRINT OUT MASS FLOW TOTALS
C *****
  BAL2=-HEATG-WORKGA+HIN-HOUT-UNITL+UFINAL
  BAL2=BAL2/(WFUEL*CALVAL)*100.
  WRITE(6,2223) BAL2
2223 FORMAT(2X,'GAS EXCHANGE ENERGY BALANCE',F8.4,' % OF FUEL ENERGY')
C
  BLBACK=1.-AIRNET/WCIN
  AIRFL=AIRNET*WREF*2.205*RPS*2./CYCLE
  IF(CYCLE.EQ.4.) GO TO 248
  IF(SCMULT.NE.1.) GO TO 247
  IF(PORTED.EQ.1.) GO TO 247
  SCASW=WCIN*WREF*.002871*TAIR/(PAIR*FCYL*XSTA)
  VEFFYI=1.-0.9811*EXP(-1.1201*SCASW)
  WCAIR=VEFFYI*PAIR*FCYL*XSTA/(WREF*.002871*TAIR)
  GO TO 248
247 WCAIR=WCAIR*SCMULT
C
C   CALCULATE AND PRINT OUT THE TOTAL AIR SUPPLIED TO THE CYLINDER
C
248 WCI=WCIN*WREF*2.0*RPS/CYCLE
  CALL UNITW(IUNITW,2,WCI)
  IF(IUNITW.EQ.2) GO TO 270
  WRITE(4,251)WCI
251 FORMAT(35H TOTAL AIR SUPPLIED PER SECOND(KG)=,F11.6)
  GO TO 273
270 WRITE(4,252)WCI
252 FORMAT(35H TOTAL AIR SUPPLIED PER SECOND(LB)=,F11.6)
C
C   CALCULATE AND PRINT OUT THE MASS FLOW RATE THROUGH THE EXHAUST VALVE
C
273 WCO=WCOU*WREF*2.0*RPS/CYCLE
  CALL UNITW(IUNITW,2,WCO)
  IF(IUNITW.EQ.2) GO TO 271
  WRITE(4,253)WCO
253 FORMAT(50H TOTAL MASS FLOW THROUGH EXH VALVE PER SECOND(KG)=,
1    F11.6)
  GO TO 274
271 WRITE(4,254)WCO
254 FORMAT(50H TOTAL MASS FLOW THROUGH EXH VALVE PER SECOND(LB)=,
1    F11.6)
C
C   CALCULATE AND PRINT OUT THE MASS OF AIR RETAINED IN THE CYLINDER
C
274 WCA=WCAIR*WREF
  CALL UNITW(IUNITW,2,WCA)
  IF(IUNITW.EQ.2) GO TO 272
  WRITE(4,255)WCA
255 FORMAT(34H TOTAL AIR RETAINED PER CYCLE(KG)=,F11.6)
  GO TO 275
272 WRITE(4,256)WCA
256 FORMAT(34H TOTAL AIR RETAINED PER CYCLE(LB)=,F11.6)

```

```

C
275 SCAVR=WCIN*WREF/((PAIR*1.0E5*VCYL*VREF)/
1 (0.2871*1.0E3*TAIR))
WRITE(4,257) SCAVR
257 FORMAT(16H SCAVENGE RATIO=,F6.4)
SCASW=WCIN*WREF/(PAIR*XSTA*XREF*PI*((DCYL*DREF)**2)/(4.
1*TAIR*.00287))
WRITE(4,261) SCASW
261 FORMAT(33H SCAVENGE RATIO ON SWEPT VOLUME =,F6.4)
CHEFFY=WCAIR*100.0/WCYL
PURITY=CEFFY/100.
ONE=1.0000
PURITY=AMIN1(PURITY,ONE)/(1.+WAR)
CEFFYI=WCAIR*WREF*100.0/((PAIR*1.0E5*VCYL*VREF)/
1 (0.2871*1.0E3*TAIR))
VEFFYI=CEFFYI*VCYL/(XSTA*FCYL)
WRITE(4,258) CHEFFY
WRITE(4,259) CEFFYI
WRITE(4,260) VEFFYI
258 FORMAT(20H CHARGING EFFICIENCY,
1 28H BASED ON TRAPPED CONDITION=,F6.2)
259 FORMAT(20H CHARGING EFFICIENCY,
1 43H BASED ON INLET CONDITION AND TRAPPED VOL.=,F6.2)
260 FORMAT(20H CHARGING EFFICIENCY,
1 41H BASED ON INLET CONDITION AND SWEPT VOL.=,F6.2)
WSUPPL=WCIN*WREF
WCA=WCAIR*WREF
WCHG=WCYL*WREF
WCA=AMIN1(WCA,WCHG)
WDISP=PAIR*1.0E5*VCYL*VREF/ (.2871*1.0E3*TAIR)
WDISPS=PAIR*1.0E5*FCYL*FREF*XSTA*XREF/ (.2871*1.0E3*TAIR)
TREFF=WCA/WSUPPL*100.
RELCHG=WCHG/WDISP*100.
RELCHS=WCHG/WDISPS*100.
SCAEFF=WCA/WCHG*100.
WRITE(4,401) TREFF
WRITE(4,402) RELCHG
WRITE(4,404) RELCHS
WRITE(4,403) SCAEFF
401 FORMAT(23H TRAPPING EFFICIENCY = ,F6.2)
402 FORMAT(32H RELATIVE CHARGING EFFICIENCY = ,F6.2)
403 FORMAT(23H SCAVENGE EFFICIENCY = ,F6.2)
404 FORMAT(47H RELATIVE CHARGING EFF BASED ON SWEPT VOLUME = ,F6.2)
WRITE(4,405) STOIC
405 FORMAT(33H STOICHIOMETRIC FUEL AIR RATIO = ,F6.4)
C *****
C SET UP PARAMETERS FOR NEXT TIME
C *****
WCIN=0.0
WCOU=0.0
SUMIMP=0.
SUMCAP=0.
WCAIR=0.0
AIRNET=0.

```

```

C *****
C  CALCULATE TRAPPED PRESSURE AND TEMPERATURE
C *****
  N=1
  PCYLT=PREF*(RC-(RC-RCN)*(ALPHA-ACSB)/DALPHA)
  ACT=AC-(AC-ACN)*(ALPHA-ACSB)/DALPHA
  TCYLT=(GREF*TREF*ACT**2)/GE
  IF(IPOWER.EQ.0) GO TO 188
  IMOLS=100
C *****
C  CALL POWER TO DO COMBUSTION CALCULATIONS
C *****
  CALL POWER(1,1)
  IF(ISTOP.EQ.1) RETURN
C
188 RCR=PCR/PREF
  ACR=SQRT(GE*TCR/(GREF*TREF))
  DST=1.0
  CALL STROK(XST,DST,EVO,XSTA,XCRA,REVENG,ZREF)
  CALL CYLVOL(FCYL,XST,XSTA,CR,DST,VCYL,DVCYL)
  WCYL=GE*RCR*VCYL/((ACR**2)*GREF)
  WORKGE=0.0
  WORKGA=0.0
  HEATG=0.0
  QSLEV2=0.
  QPIST2=0.
  QHEAD2=0.
  QEXHV2=0.
  HOUT=0.0
  HIN=0.0
  HOUT2=0.0
  HIN2=0.0
  HC5=0.
  HC6=0.
  HC7=0.
  HC8=0.
  HCT5=0.
  HCT6=0.
  HCT7=0.
  HCT8=0.
C  STORE RELEASE MASS
  WCYL=WCYL
C  TEST IF BOTH AIR AND EXHAUST CLOSED
152 IF(EXH.NE.0.0) GO TO 124
  IF(AIR.NE.0.0) GO TO 124
  GO TO 150
C *****
C  CALCULATE GAS EXCHANGE WORK
C *****
124 WORKGA=WORKGA+0.5*PREF*VREF*(RC+RCN)*(DVCYL-DVCYLE)*DZ*100.
  WORKGE=WORKGE+0.5*PREF*VREF*(RC+RCN)*DVCYLE*DZ*100.
C *****
C  CALCULATE FLOW THROUGH VALVES/PORTS
C *****

```

```

    PORTS=100.0
    IF(EXH.GT.0.0) GO TO 129
C   EXHAUST VALVE/PORT IS CLOSED, SET MASS FLOW EQUAL TO ZERO
    DWCP(NEX)=0.
    GO TO 126
C
C   EXHAUST VALVES/PORTS OPEN
C       CHECK WHETHER ENGINE HAS EXHAUST VALVES OR PORTS
C
    129 IF(VALEXH.NE.0.0) GO TO 140
C   ENGINE IS PORTED. CALCULATE PORT FLOW AREA AND NONDIMENSIONALIZE.
    XHTE=XHTA
    141 FEXHV=WIDTHE*PI*DCYL*(XHTE-EXHP0)
    FEXHV=FEXHV*DREF*XREF/FREF
    GO TO 542
C   ENGINE IS VALVED, USE SPLINE ROUTINE TO INTERPOLATE USER
C   SUPPLIED EXHAUST VALVE FLOW AREA DATA AT THIS CRANK POSITION
    140 CALL SPLFIT(0,0,NTEXH,0,0.0,ALPHEX,0,FEXH,0,ALPHA,FEXHV,ITRP)
    542 CONTINUE
    533 FEXHV=CDE*FEXHV
    EXHVMX = AMAX1(EXHVMX,FEXHV)
C
C   MASS FLOW EXHAUST
C
C       CHECK WHETHER FLOW IS IN OR OUT OF CYLINDER
C
    IF(RPEXH.LT.RC) GO TO 590
    CALL MASSFL(FEXHV,RPEXH,RC,APEXH,GREF,GE,DWCP(NEX))
    DWCP(NEX)=-DWCP(NEX)
    GO TO 547
    590 CALL MASSFL(FEXHV,RC,RPEXH,AC,GREF,GE,DWCP(NEX))
    547 CONTINUE
C   TEST FOR AIR PORTS
    126 IF(AIR.GT.0.0) GO TO 130
    127 DWCPIN=0.0
    GO TO 147
C
C   INTAKE VALVES/PORTS OPEN
C       CHECK WHETHER ENGINE HAS INTAKE VALVES OR PORTS
C
    130 IF(VALAIR.NE.0.0) GO TO 144
C   ENGINE IS PORTED. CALCULATE PORT FLOW AREA AND NONDIMENSIONALIZE.
    FAIRV=WIDTHA*PI*DCYL*(XHTA-AIRP0)
    FAIRV=FAIRV*DREF*XREF/FREF
    GO TO 189
C   ENGINE IS VALVED, USE SPLINE ROUTINE TO INTERPOLATE USER
C   SUPPLIED INTAKE VALVE FLOW AREA DATA AT THIS CRANK POSITION
    144 CALL SPLFIT(0,0,NTAIR,0,0.0,ALPAIR,0,FAIR,0,ALPHA,FAIRV,ITRP)
    189 CONTINUE
    133 FAIRV=CDA*FAIRV
    AIRVMX = AMAX1(AIRVMX,FAIRV)
C   MASS FLOW AIR
    IF(RPAIR.LT.RC) GO TO 190
    CALL MASSFL(FAIRV,RPAIR,RC,APAIR,GREF,GA,DWCIN)

```

```

GO TO 147
190 CALL MASSFL(FAIRV,RC,RPAIR,AC,GREF,GE,DWCIN)
DWCIN=-DWCIN
IF(NCD.EQ.1) DWCIN=0.
C *****
C MASS BALANCE
C *****
147 DWCYL=DWCIN-DWCP(NEX)
C
C KEEP TRACK OF AMOUNT OF NEW AIR ADDED TO CYLINDER
C ASSUMES CYLINDER CONTENTS ARE PERFECTLY MIXED
C
177 IF ((ALPHA-EVO)-(DZ*ZREF*REVENG)) 170,171,171
170 DZT=(ALPHA-EVO)/(ZREF*REVENG)
GO TO 172
171 DZT=DZ
C TEST FLOW DIRECTION THROUGH AIR VALVE
172 IF(DWCIN.GT.0.0) GO TO 174
C OUTFLOW THROUGH AIR VALVE
C TEST FLOW DIRECTION THROUGH EXHAUST VALVE
IF(DWCP(NEX).GT.0.0) GO TO 173
C OUTFLOW AIR VALVE, INFLOW EXH VALVE
DWEAIR=WCAIR*DWCIN/WCYL
WCAIR=WCAIR+DWEAIR*DZT
GO TO 176
C OUTFLOW AIR VALVE, OUTFLOW EXH VALVE
173 DWEAIR=(DWCIN-DWCP(NEX))*WCAIR/WCYL
WCAIR=WCAIR+DWEAIR*DZT
GO TO 176
C TEST FLOW DIRECTION THROUGH EXHAUST VALVE
174 IF(DWCP(NEX).GT.0.0) GO TO 175
C INFLOW AIR VALVE, INFLOW EXH VALVE
DWEAIR=0.0
WCAIR=WCAIR+DWCIN*DZT
WCIN=WCIN+DWCIN*DZT
GO TO 176
C INFLOW AIR VALVE, OUTFLOW EXH VALVE
175 DWEAIR=WCAIR*DWCP(NEX)/WCYL
WCAIR=WCAIR+(DWCIN-DWEAIR)*DZT
WCIN=WCIN+DWCIN*DZT
C TOTAL MASS FLOW THROUGH EXHAUST VALVE
176 WCOU=WCOU+DWCP(NEX)*DZT
C TOTAL MASS FLOW THROUGH INTAKE VALVE
AIRNET=AIRNET+DWCIN*DZT
C *****
C CALCULATE HEAT TRANSFER
C *****
TC=(GREF*TREF*AC**2)/GE
TEXH=TC
RHO=RC*PREF*1.0E2/(0.287*TC)
WMOLS=RC*PREF*VCYL*VREF*1.0E2/(8.3143*TC)
IF(IPOWER.NE.0) GO TO 160
WN(1)=0.79*WMOLS
WN(2)=0.21*WMOLS

```

```

      WN(3)=0.0
      WN(4)=0.0
      GO TO 168
160 IF(IMOLS.EQ.0) GO TO 164
C  CALCULATE PERCENT BY WT. OF CONSTITUENTS AT END OF POWER CYCLE
      WT=0.0
      DO 165 I=1,4
165 WT=WT+WMW(I)*WN(I)
      DO 166 J=1,4
166 WPCNT(J)=WMW(J)*WN(J)/WT
      IMOLS=0
C  CALCULATE INSTANTANEOUS NO. OF MOLS. IN GAS EXCHANGE
164 WN(1)=WREF*(0.767*WCAIR+WPCNT(1)
      1  *(WCYL-WCAIR))/WMW(1)
      WN(2)=WREF*(0.233*WCAIR+WPCNT(2)
      1  *(WCYL-WCAIR))/WMW(2)
      WN(3)=WREF*WPCNT(3)*(WCYL-WCAIR)/WMW(3)
      WN(4)=WREF*WPCNT(4)*(WCYL-WCAIR)/WMW(4)
C *****
C  CALCULATE HEAT TRANSFER DATA
C *****
168 CPT=0.0
      DO 161 I=1,4
161 CPT=CPT+WN(I)*(COEFFA(I)+2.0*COEFFB(I)*TC+3.0*COEFFC(I)*TC**2
      1  +4.0*COEFFD(I)*TC**3)
      CPT=8.3143*CPT/(WCYL*WREF)
      SUMMOL=WN(1)+WN(2)+WN(3)+WN(4)
      RGAS=8.3143*SUMMOL/(WCYL*WREF)
      GE=CPT/(CPT-RGAS)
      SUMIMP=SUMIMP+TC*CPT*DWCP(1)*DZ
      SUMCAP=SUMCAP+CPT*DWCP(1)*DZ
      TAVG=1.8*SUMIMP/SUMCAP
      PRESS=14.5*PREF*RC
      TRANK=1.8*TC
      VOL=61032.7*VREF*VCYL
      WRITE(3,1020) ALPHA,PRESS,TRANK,GE,VOL
1020 FORMAT (5(1X,E11.5))
      XSTIN=XST*39.372
C
C  CALCULATE ENTHALPY OF AIR ENTERING CYLINDER
      HTA=0.0
      XMOL(1)=.79
      XMOL(2)=.21
      DO 21 I=1,2
21 HTA=HTA+XMOL(I)*(8.3143*((COEFFA(I))*TAIR+COEFFB(I)*TAIR**2
      1  +COEFFC(I)*TAIR**3+COEFFD(I)*TAIR**4)-COEFFE(I))
      HTA=HTA/28.85
C  CALCULATE ENTHALPY AND INTERNAL ENERGY OF CYLINDER CONTENTS AT
C  THE END OF THE TIME STEP
      HTF=0.0
      DO 91 I=1,4
      XMOL(I)=WN(I)/SUMMOL
91 HTF=HTF+XMOL(I)*(8.3143*((COEFFA(I))*TC+COEFFB(I)*TC**2
      1  +COEFFC(I)*TC**3+COEFFD(I)*TC**4)-COEFFE(I))

```

```

HTF=HTF*SUMMOL/(WREF*WCYL)
ETF=HTF-8.3142*TC*SUMMOL/(WREF*WCYL)
C
DHOUT=DWCP(1)*HTF*WREF*DZT
HOUT=HOUT+DHOUT
DHIN=DWCIN*HTA*WREF*DZT
HIN=HIN+DHIN
C CALCULATE COEFFICIENTS FOR GAS VISCOSITY EQUATION
A=0.0
B=0.0
DO 162 I=1,4
A=WN(I)*COEFFZ(I)*SQRT(WMW(I))+A
162 B=WN(I)*SQRT(WMW(I))+B
C *****
C CALCULATE HEAT TRANSFER DURING GAS EXCHANGE
C *****
IF(NHEAT.EQ.0) GO TO 777
TWALL=TWGC
TPIST=TWGP
THEAD=TWGH
TEXV=TWEV
777 VISCTY=(A*TC**0.645)/B
CONDY=CPT*VISCTY/0.7
REY=RHO*PVEL*DCYL*DREF/VISCTY
IF(ANNC.EQ.0) REY=REY*6.18
H=(ANNA*CONDY*REY**ANNB)/(DCYL*DREF)
DHEAT=SURFC*H*(TWALL-TC)*VREF*1000./AREF
DHEAT=DHEAT+(SURFP*(TPIST-TC)+SURFH*(THEAD-TC)
1 +SURFE*(TEXV-TC))*H*VREF*1000./AREF
C TOTAL HEAT TRANSFER DURING GAS EXCHANGE (KJ)
HEATG=HEATG+DHEAT*DZ*1.0E-3
C
DQSLEV=SURFC*H*(TWALL-TC)*VREF*1000./AREF
DQPIST=SURFP*H*(TPIST-TC)*VREF*1000./AREF
DQHEAD=SURFH*H*(THEAD-TC)*VREF*1000./AREF
DQEXHV=SURFE*H*(TEXV-TC)*VREF*1000./AREF
QSLEV2=QSLEV2+DQSLEV*DZ/1000.
QPIST2=QPIST2+DQPIST*DZ/1000.
QHEAD2=QHEAD2+DQHEAD*DZ/1000.
QEXHV2=QEXHV2+DQEXHV*DZ/1000.
QTOT2=QSLEV2+QPIST2+QHEAD2+QEXHV2
C
HC5=HC5+H*SURFC*2.
HC6=HC6+H*SURFP*2.
HC7=HC7+H*SURFH*2.
HC8=HC8+H*SURFE*2.
HCT5=HCT5+H*SURFC*TC*2.
HCT6=HCT6+H*SURFP*TC*2.
HCT7=HCT7+H*SURFH*TC*2.
HCT8=HCT8+H*SURFE*TC*2.
C *****
C FIRST LAW OF THERMODYNAMICS
C ENERGY BALANCE AND PRESSURE CHANGE FOR GAS EXCHANGE
C *****

```



```

      CVT=CPT-8.3143*SUMMOL/(WREF*WCYL)
      DTEMP=(DHEAT/1000.+WREF*(DWCIN*HTA-DWCP(1)*HTF-DWCYL
+ *ETF)-RC*PREF*DVCYL*VREF*100.)/(WREF*WCYL*CVT)
      DRC=RC*(DTEMP/TC+DWCYL/WCYL-DVCYL/VCYL)
C
12 IF(PORTS.NE.0.0) GO TO 100
   RC=RCR
   AC=ACR
   DRC=0.0
   DWCYL=0.0
   DWCIN=0.0
100 CONTINUE
   1 RETURN
   END
C
C
      SUBROUTINE ELIM(AB,N,NP,NDIM)
      DIMENSION AB(NDIM,NP)
C THIS SUBROUTINE SOLVES A SET OF LINEAR EQUATIONS.
C THE GAUSS ELIMINATION METHOD IS USED, WITH PARTIAL PIVOTING.
C MULTIPLE RIGHT HAND SIDES ARE PERMITTED, THEY SHOULD BE SUPPLIED
C AS COLUMNS THAT AUGMENT THE COEFFICIENT MATRIX
C PARAMETERS ARE —
C AB COEFFICIENT MATRIX AUGMENTED WITH R.H.S. VECTORS
C N NUMBER OF EQUATIONS
C NP TOTAL NUMBER OF COLUMNS IN THE AUGMENTED MATRIX
C NDIM FIRST DIMENSION OF MATRIX AB IN THE CALLING PROGRAM.
C THE SOLUTION VECTOR(S) ARE RETURNED IN THE AUGMENTATION
C COLUMNS OF AB.
C REFERENCE: APPLIED NUMERICAL ANALYSIS, 2ND EDITION
C CURTIS F. GERALD P. 132
C
C BEGIN THE REDUCTION
   NM1=N-1
   DO 35 I=1,NM1
C FIND THE ROW NUMBER OF THE PIVOT ROW. WE WILL THEN
C INTERCHANGE ROWS TO PUT THE PIVOT ELEMENT ON THE DIAGONAL.
      IPVT=I
      IP1=I+1
      DO 10 J=IP1,N
         IF(ABS(AB(IPVT,I)) .LT. ABS(AB(J,I))) IPVT=J
10 CONTINUE
C CHECK TO BE SURE THE PIVOT ELEMENT IS NOT TOO SMALL, IF SO
C PRINT A MESSAGE AND RETURN
      IF((ABS(AB(IPVT,I)) .LT. 1.E-5)) GO TO 99
C NOW INTERCHANGE, EXCEPT IF THE PIVOT ELEMENT IS ALREADY ON
C THE DIAGONAL, DON'T NEED TO.
      IF(IPVT.EQ.I) GO TO 25
      DO 20 JCOL = 1,NP
         SAVE=AB(I,JCOL)
         AB(I,JCOL)=AB(IPVT,JCOL)
         AB(IPVT,JCOL)=SAVE
20 CONTINUE
C NOW REDUCE ALL ELEMENTS BELOW THE DIAGONAL IN THE I-TH ROW. CHECK

```

```

C FIRST TO SEE IF A ZERO ALREADY PRESENT. IF SO,
C CAN SKIP REDUCTION FOR THAT ROW.
25 DO 32 JROW=IP1,N
   IF (AB(JROW,I).EQ.0) GO TO 32
   RATIO=AB(JROW,I)/AB(I,I)
   DO 30 KCOL=IP1,NP
     AB(JROW,KCOL) = AB(JROW,KCOL) -RATIO*AB(I,KCOL)
30 CONTINUE
32 CONTINUE
35 CONTINUE
C WE STILL NEED TO CHECK A(N,N) FOR SIZE
   IF (ABS (AB(N,N)) .LT. 1.E-5) GO TO 99
C NOW WE BACK SUBSTITUTE
   NP1=N+1
   DO 50 KCOL=NP1,NP
     AB(N,KCOL)=AB(N,KCOL)/AB(N,N)
   DO 45 J=2,N
     NVBL=NP1-J
     L=NVBL+1
     VALUE=AB(NVBL,KCOL)
     DO 40 K=L,N
       VALUE=VALUE-AB(NVBL,K)*AB(K,KCOL)
40 CONTINUE
     AB(NVBL,KCOL)=VALUE/AB(NVBL,NVBL)
45 CONTINUE
50 CONTINUE
   RETURN
C MESSAGE FOR A NEAR SINGULAR MATRIX
99 WRITE(6,100)
100 FORMAT(2X,'SOLUTION IS NOT FEASIBLE. A NEAR ZERO PIVOT WAS ENCOUN
   1TERED.')
   RETURN
   END

```

```

SUBROUTINE POWER (N,IPUR)
DIMENSION VCILA(360),VCYLE(360),VCYLP(360),PCP(360),TCP(360),
1 PRANG(360),CANG(2),PCFINT(2),WNI(4),WNF(4)
C IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)
COMMON/XXX/ EQUIVD,RPM,PEXH,PAIR,TAIR,
1 CR,BORE,STROKE,CONROD,FPISTE,FPISTA,
2 EVO,EVC,AVO,AVC,
3 TWALL,WFUEL,
4 ACB,ACF,
5 ANNA,FMEPM,
6 NPCWF,DEL1,DEL2,DEL3,AAN(2),
7 VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),
8 VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)
COMMON/GEN/ALPHAT,ANGEND,ANGRES,AIRPO,EXHPO,IMOLS,
1 APAIR,APEXH,AREF,AP(2),
1 APN(2),CYCLE,DALPHA,

```

```

1      DREF,DZ,FREF,
1      IPOWER,IREV,GA,GE,GREF,IUNITL,
1      IUNITP,IUNITT,IUNITK,IUNITW,IUNITQ,
1      WAR,PBARAB,
1      PI,PREF,REVENG,REVREF,RPAIR,RPEXH,RP(2),
1      RPN(2),STEP2,TEXH,TREF,VREF,WREF,XREF,
1      Z,ZREF,HAIR,HREF,SCMULT,NC
COMMON/CYL/ACSB,ALPHA,ALPHAE,ANNB,ANNC,AC,
1      ACN,ACR,ALPHAC,
1      CALVAL,CARBON,
1      COEFFA(4),COEFFB(4),COEFFC(4),COEFFD(4),
1      COEFFE(4),COEFFZ(4),CRANK,DCYL,DHEAT,
1      DRC,DVCYL,DWCIN,DWCP(2),DWCYL,
1      FCYL,HEATG,
1      PURITY,PVEL,PCR,PCYLT,
1      PORTS,RC,RCN,RCR,SURFC,
1      TCR,TCYLT,VSWEPT,
1      VCYL,WCAIR,WCIN,
1      WCOUT,WCYL,WMW(4),WPCNT(4),WCYLR,
1      WN(4),WORKGA,WORKGE,XCRA,XSTA,
1      NCD,WCYLT,DWCINT,
1      TPIST,THEAD,TEXV,CID
COMMON/COMB/AIRFL,EQUIV,TEXHS,SHPS,FZA,HRD,SCASW,TREFF,SCAEFF,
+ AIRVMX,EXHVMX,PORTED,STOIC,WCO,BLBACK,FUELF,BHP
COMMON/TEMP/TWEV,TWGH,TWGP,TWGC,TWCR,TWPR,TWCP,TWCC,TWCH,TEXHP,
1      TWEVG,TC1,TC2,TC3
COMMON/HEAT/NHEAT,QSLEV1,QPIST1,QHEAD1,QEXHV1,QTOT1,
1      QSLEV2,QPIST2,QHEAD2,QEXHV2,QTOT2,
2      HC1,HC2,HC3,HC4,HC5,HC6,HC7,HC8,
3      HCT1,HCT2,HCT3,HCT4,HCT5,HCT6,HCT7,HCT8
COMMON/INPT2/
1      XXEVG,XXEVH,XXPSL,XXPIS,XXPRG,XXHED,XXPCR,XXRSL,XXSLV,
2      AEXVS,AEXV,AEXST,AHEAD,ASLEEV,APIST1,APIST2,APISTR,ARING1,ARING2,
3      CEXV,CHEAD,CSLEEV,CPIST,CRING,
4      HEXHP,HOILP,HCSL,HCHD,NEXHV,DEXHV,
5      D1,D2,D3,D4,D5,D6,VCV,APP,ARR,ASS
COMMON/CV/QCV,QCV1,QCV2,QCV3
COMMON/FRIC/QFRIC1,QFRIC2,QFRIC3
COMMON/CPURE/WCA,WCHG,IMIX
COMMON/ENERGY/UINITL,UFINAL,HOUT
COMMON/STOP/ISTOP
COMMON/WHITWY/PSUM,RSUM,FUELS,TF,DA,XO2
C *****
C      SET UP ANGLES TO START CALCULATION
C *****
      RPS=REVENG*REVREF
      ANGLA=ACSB
      ANGLE=ACSB
      ANGLP=180.0*CYCLE-ACSB+EVO
      ANGLC=0.0
      K=1
      PRANG(1)=ACSB
C      SET UP COMBUSTION ANGLES
      ACBB=ACB

```

```

IF (ACBB.LT.180.0) ACBB=180.0*CYCLE+ACBB
ACFF=ACF
IF (NPCWF.EQ.0 .AND. DEL3.EQ.0.) HRD=15.+115.*EQUIV
IF (NPCWF.EQ.0) ACFF=ACBB-180.*CYCLE+HRD
IF (ACFF.LT.180.0) ACFF=180.0*CYCLE+ACFF
IF (NPCWF.LT.0.0) HRD=ACFF-ACBB
C   CALCULATE TRAPPED VOLUME
DST=0.0
CALL STROK(XST,DST,ANGLA,XSTA,XCRA,REVENG,ZREF)
CALL CYLVOL(FCYL,XST,XSTA,CR,DST,VCYLA(1),DVCY)
FPISTE=1.0
VCYLE(1)=0.0
VCYLA(1)=VCYLA(1)*VREF
VCYLE(1)=VCYLE(1)*VREF
VCYLP(1)=VCYLA(1)+VCYLE(1)
WORKA=0.0
WORKE=0.0
HEATRF=0.0
DQCR=0.0
DQCR1=0.0
DQCR2=0.0
DQCR3=0.0
DQCR4=0.0
ICOMB=0
QHEAD1=0.
QSLEV1=0.
QPIST1=0.
QEXHV1=0.
QCV=0.
HC1=0.
HC2=0.
HC3=0.
HC4=0.
HCT1=0.
HCT2=0.
HCT3=0.
HCT4=0.
C *****
C   CALCULATE TRAPPED GAS COMPOSITION —NO.OF MOLS OF AIR (WNA) ,
C   NO. OF MOLS OF RESIDUALS (WNR) , INCREASE IN MOLS OF PRODUCTS (WNP)
C *****
VCYLT=VCYLP(1)
C CALCULATE TOTAL NUMBER OF MOLES OF GASES IN CYLINDER
WNTF=PCYLT*VCYLT*100.0/(8.3143*TCYLT)
IF (IPUR.EQ.0) GO TO 7
C CALCULATE MASS OF RESIDUAL
WRES=WCHG-WCA
C CALCULATE TOTAL MASS IN CYLINDER (AIR+RESIDUAL+FUEL)
WTOT=WCHG+WFUEL
C CALCULATE STOICHIOMETRIC MASS OF AIR REQUIRED TO BURN FUEL
WABU=32.*(CARBON/12.01+(1.-CARBON)/4.032)*WFUEL/.233
ZERO=0.0
WAIR=WCA+WRES*MAX1(WCA-WABU,ZERO)/(WTOT-WRES)
IF (WABU.GT.WCA) WRITE(4,8)

```

```

      8 FORMAT (17H *** WARNING *** ,32HBURNED AIR EXCEEDS AVAILABLE AIR)
      7 CONTINUE
C   CALCULATE NUMBER OF MOLES OF AIR IN CYLINDER
      WNA=PURITY*WNTF
C   CALCULATE NUMBER OF MOLES OF RESIDUAL IN CYLINDER
      WNR=WNTF-WNA
C   CALCULATE INCREASE IN NUMBER OF MOLES OF DUE TO COMBUSTION
C   LB FUEL * (MOLES OF PRODUCTS-MOLES OF AIR)/LB FUEL
      WNP=WFUEL*(1.0-CARBON)/4.032
C   CALCULATE NUMBER OF MOLS OF (1) NITROGEN, (2) OXYGEN,
C   (3) CARBON DIOXIDE, (4) WATER VAPOUR
      WNF(1)=0.79*WNA*(WNA+WNP+WNR)/(WNA+WNP)
      IF(WNF(1).LE.0.) WRITE(6,*) 'WNA,PURITY,WNTF,WNF(1)',WNA,PURITY,
1    WNTF,WNF(1)
      WNF(4)=2.0*WNP*WNR/(WNA+WNP)
      WNF(3)=2.016*CARBON*WNF(4)/(12.01*(1.0-CARBON))
      WNF(2)=0.21*WNF(1)/0.79-WNF(3)-0.5*WNF(4)
C   TRAPPED MASS IN CYLINDER
      WMF=0.0
      DO 10 I=1,4
10    WMF=WMF+WMW(I)*WNF(I)
      TRAF=28.85*WNA/WFUEL
      WAIR=WNF(2)*32./233
      PURE=WAIR/WNTF/28.85
      WRITE(4,499) PURE
499  FORMAT (14H TRUE PURITY =,F6.4)
      TRMF=WMF/WFUEL
      EAFR=32.*WNF(2)*100./(23.3*WFUEL)
      EQUIV=1./(STOIC*EAFR)
      WRITE(4,4) EQUIV
4    FORMAT (21H EQUIVALENCE RATIO =,F6.4)
      IF (EQUIVD.GT.0.) WFUEL=32.*WNF(2)*STOIC*EQUIVD/233
      PSUM=0.
      RSUM=0.
      FUELS=0.
      DUR=0.
C   STORE TRAPPED PRESSURE, TEMPERATURE
      PCF=PCYLT
      PCP(1)=PCF
      CALL UNITP(IUNITP,2,PCP(1),PBARAB)
      TF=TCYLT
      TCP(1)=TF
      CALL UNITT(IUNITT,2,TCP(1))
C *****
C   CALCULATE INTERNAL ENERGY OF TRAPPED CONTENTS IN KJ
C *****
      ETF=0.0
      DO 11 I=1,4
11    ETF=ETF+WNF(I)*(8.3143*((COEFFA(I)-1.0)*TF+COEFFB(I)*TF**2
1    +COEFFC(I)*TF**3+COEFFD(I)*TF**4)-COEFFE(I))
      UINITL=ETF
C *****
C   START NEXT STEP
C *****

```

```

23 K=K+1
   ANGLC=ANGLC+1.0
   ANGLA=ANGLA+1.0
   ANGLE=ANGLE+1.0
   PRANG(K)=ANGLA
   IF (PRANG(K).GE.(180.0*CYCLE)) PRANG(K)=PRANG(K)-180.0*CYCLE
   ETI=ETF
   PCI=PCF
   TI=TF
C   TEST IF COMBUSTION HAS STARTED
   IF (ANGLA.LE.ACBB) GO TO 12
C   COMBUSTION HAS STARTED —CALCULATE FUEL BURNT IN STEP
   IF (ICOMB.EQ.0) KC=K-1
   ICOMB=100
   CANG(1)=ANGLA-1.0
   CANG(2)=ANGLA
   DUR=ANGLA-ACBB
   ONE=1.000
   DA=AMIN1(DUR,ONE)
C
C   CALCULATE PER CENT FUEL BURNED AT START AND END OF TIME STEP
C
   DO 25 I=1,2
C   WRITE(6,*) 'CANG(I),ACBB',CANG(I),ACBB
   ANG=CANG(I)-ACBB
   IF (ANG) 26,26,27
26 PCFINT(I)=0.0
   GO TO 25
27 IF(NPCWF.LT.0) GO TO 290
   IF(NPCWF.EQ.2) CALL BURNRT(ANGLA,ACB,ACF,WFUEL,DWFUEL)
C   WRITE(6,*) ANGLA,DWFUEL
   IF(NPCWF.EQ.2) GO TO 250
   TAU=ANG/HRD
C *****
C   WIEBE COMBUSTION MODEL
C *****
29 IF(NPCWF.EQ.0) PCFINT(I)=100.*(1.-EXP(-DEL1*TAU**DEL2))
C *****
C   WATSON COMBUSTION MODEL
C *****
   BETA=1.-DEL1*EQUIV**DEL2/1.5E4**DEL3
   CP1=2.+1.25E-8*(1.5E4*REVREF*60.)**2.4
   CP2=5000.
   CD1=14.2/EQUIV**.644
   CD2=.79*CD1**.25
   IF (NPCWF.GT.0) PCFINT(I)=100.*(BETA*(1.-(1.-TAU**CP1)**CP2)+
+ (1.-BETA)*(1.-EXP(-CD1*TAU**CD2)))
   IF (NPCWF.GE.0) GO TO 25
C *****
C   WHITEHOUSE-WAY COMBUSTION MODEL
C *****
290 PO2=PCF*WNF(2)/WNTF
   ZERO=0.0
   PO2=AMAX1(PO2,ZERO)

```

```

DWFUEL=0.
C RAMP FUEL INJECTION SCHEDULE ASSUMED
  TAU=DUR/HRD
  AA2=2.-AAN(1)*AAN(2)
  IF(TAU.LE.AAN(2)) FINJ=WFUEL*(AAN(1)*TAU+
+ ((AA2-AAN(1))/(2.*AAN(2)))*TAU**2)
  IF(TAU.GE.1.) GO TO 295
  IF(TAU.GT.AAN(2)) FINJ=WFUEL*((AAN(1)+AA2)*AAN(2)/2.+
+ (AA2/(1.-AAN(2))*(TAU-TAU**2/2.+AAN(2)**2/2.-AAN(2))))
295 FINJ=AMIN1(FINJ,WFUEL)
  IF(DUR.GT.HRD) FINJ=WFUEL
  IF(FINJ.LE.PSUM) GO TO 250
  PREP=DEL1*FINJ*(1.-DEL2)*(FINJ-PSUM)**DEL2*PO2**DEL3
  PSUM=PSUM+PREP*DA
  PSUM=AMIN1(PSUM,FINJ)
  REACT=1.2E10*PO2*EXP(-1.5E4/TF)*(PSUM-RSUM)/(60.*REVREF*SQRT(TF))
  ZERO=0.0
  REACT=AMAX1(REACT,ZERO)
  RSUM=RSUM+REACT*DA
  IF(RSUM.LE.PSUM) DWFUEL=REACT*DA
  IF(RSUM.GT.PSUM) DWFUEL=PREP*DA
  IF(REACT.EQ.0.) DWFUEL=PSUM-FUELS
C MODIFIED BURNING RATE MODEL
  GO TO 250
C ACF1=ACF+360.
C ACB1=ACB+0.8*(ACF1-ACB)
C IF(ANGLA.LT.ACB) DWFUEL=0.
C IF(ANGLA.GT.ACB .AND. ANGLA.LE.ACB1) DWFUEL
C 1 =WFUEL*(2./(ACF1-ACB))*((ANGLA-ACB)/(ACB1-ACB))
C IF(ANGLA.GT.ACB1 .AND. ANGLA.LT.ACF1) DWFUEL
C 1 =WFUEL*(2./(ACF1-ACB))*((ACF1-ANGLA)/(ACF1-ACB1))
C IF(ANGLA.GE.ACF1) DWFUEL=0.
25 CONTINUE
C *****
C CALCULATE HEAT RELEASE DUE TO COMBUSTION OF FUEL
C *****
  DWFUEL=0.01*(PCFINT(2)-PCFINT(1))*WFUEL
250 DQF=DWFUEL*CALVAL
  FUELS=FUELS+DWFUEL
C *****
C CALCULATE NEW GAS COMPOSITION
C *****
C STORE OLD COMPOSITION
  WNTI=WNTF
  WMI=WMF
  DO 13 I=1,4
13 WNI(I)=WNF(I)
C
  X=DWFUEL*(1.0-CARBON)/4.032
  Y=DWFUEL*CARBON/12.01
  WNTF=WNTI+X
  WMF=WMI+DWFUEL
  WM=0.5*(WMI+WMF)
  WNF(2)=WNI(2)-X-Y

```

```

WNF(3)=WNI(3)+Y
WNF(4)=WNI(4)+2.0*X
DO 14 I=1,4
14 WN(I)=0.5*(WNF(I)+WNI(I))
GO TO 15
C *****
C COMBUSTION HAS NOT STARTED YET
C *****
12 DQF=0.0
DQCR=0.0
WNTI=WNIF
WMI=WMF
WM=WMF
DO 16 I=1,4
WNI(I)=WNF(I)
16 WN(I)=WNF(I)
C *****
C CALCULATE CYLINDER VOLUME AND SURFACE AREA
C *****
15 DST=0.0
CALL STROK(XST,DST,ANGLA,XSTA,XCRA,REVENG,ZREF)
CALL CYLVOL(FCYL,XST,XSTA,CR,DST,VCYLA(K),DVCY)
FPISTE=1.0
VCYLE(K)=0.0
17 VCYLP(K)=VCYLA(K)+VCYLE(K)
CALL SREA(SURFC,VCYLP(K),FCYL,DCYL,XREF,DREF,
1 FPISTA,FPISTE)
C CALCULATE SURFACE AREA OF CYLINDER EXPOSED TO COMBUSTION
SURFC=SURFC-(FPISTA+FPISTE)*FCYL
SURFC=SURFC*FREF
C CALCULATE SURFACE AREA OF PISTON (SQUARE METERS)
SURFP=FPISTA*FCYL*FREF
C CALCULATE SURFACE AREA OF EXHAUST VALVE(S)
SURFE=FLOAT(NEXHV)*0.7854*DEXHV**2/(39.37)**2
C CALCULATE SURFACE AREA OF HEAD EXPOSED TO COMBUSTION CHAMBER
SURFH=FPISTE*FCYL*FREF-SURFE
C
VCYLA(K)=VCYLA(K)*VREF
VCYLE(K)=VCYLE(K)*VREF
VCYLP(K)=VCYLP(K)*VREF
IF (VCYLP(K).LT.VCYLP(K-1)) VOLMIN=VCYLP(K)
C AVERAGE VOLUME AND DENSITY
VC=0.5*(VCYLP(K)+VCYLP(K-1))
RHO=WM/VC
C ESTIMATE GAS TEMPERATURE AT END OF STEP
TF=TI*(VCYLP(K-1)/VCYLP(K))**0.4+4.0*DQF/WM
C CALCULATE AVERAGE GAS TEMPERATURE
22 TM=0.5*(TI+TF)
C *****
C CALCULATE CONVECTIVE HEAT TRANSFER IN KJ
C USE ANNAND CORRELATION IF ANNC.GT.0
C USE WOSCHNI CORRELATION IF ANNC.EQ.0
C *****
C CALCULATE CP FOR GAS MIXTURE

```



```

CPT=0.0
DO 18 I=1,4
18 CPT=CPT+WN(I)*(COEFFA(I)+2.0*COEFFB(I)*TM+3.0*COEFFC(I)*TM**2
1 +4.0*COEFFD(I)*TM**3)
CPT=8.3143*CPT/WM
C CALCULATE VISCOSITY OF GAS MIXTURE
A=0.0
B=0.0
DO 19 I=1,4
C=WN(I)*SQRT(WMW(I))
A=A+COEFFZ(I)*C
19 B=B+C
VISCTY=(A*TM**0.645)/B
IF(VISCTY.LE.0.) WRITE(6,*) 'VISCTY,WN(I)S',VISCTY,WN
C CALCULATE THERMAL CONDUCTIVITY OF GAS MIXTURE (ASSUME PRANDTL = 0.7)
CONDY=CPT*VISCTY/0.7
REY=RHO*PVEL*DCYL*DREF/VISCTY
C IF(REY.LE.0.) WRITE(6,*) 'REY,RHO,PVEL,DCYL,DREF,VISCTY',
C 1 REY,RHO,PVEL,DCYL,DREF,VISCTY
PMOT=PCYLT*(VCYLT/VCYLP(K))**1.32
TERM1=2.28*PVEL
TERM2=0.
IF(ANGLA.GT.ACBB) TERM2=3.24E-3*.7854*DCYL**2*XSTA*TCYLT*
+ (PCF-PMOT)/(PCYLT*VCYLT)
IF(ANNC.EQ.0.) REY=REY*(TERM1+TERM2)/PVEL
H=(ANNA*CONDY*REY**ANNB)/(DCYL*DREF)
C
C UNITS: SURFC=SQUARE METERS
C TM = DEG KELVIN
C RPS = REV PER SECOND
C DQCY = KJ/DEG CA
HR1=0.
HR2=0.
HR3=0.
HR4=0.
IF (NHEAT.EQ.0) GO TO 777
TWALL=TWGC
TPIST=TWGP
THEAD=TWGH
TEXV=TWEV
777 DQCY=(SURFC*H*(TM-TWALL))/(360.0*RPS)
DQCY=DQCY+(SURFP*(TM-TPIST)+SURFH*(TM-THEAD)+SURFE*(TM-TEXV))*H/
+ (360.*RPS)
C
DQCY1=SURFC*H*(TM-TWALL)/(360.*RPS)
DQCY2=SURFP*H*(TM-TPIST)/(360.*RPS)
DQCY3=SURFH*H*(TM-THEAD)/(360.*RPS)
DQCY4=SURFE*H*(TM-TEXV)/(360.*RPS)
IF (ICOMB.EQ.0) GO TO 20
C *****
C RADIANT HEAT TRANSFER (AFTER START OF COMBUSTION ONLY)
C —ANNAND CORRELATION ONLY —
C *****
DQCR=SURFC*ANNC*(TM**4-TWALL**4)/(360.*RPS)

```

```

DQCR=DQCR+(SURFP*(TM**4-TPIST**4)+SURFH*(TM**4-THEAD**4)
1 +SURFE*(TM**4-TEXV**4))*ANNC/(360.*RPS)
C
HR1=ANNC*(TM**3+TM**2*TWALL+TM*TWALL**2+TWALL**3)
HR2=ANNC*(TM**3+TM**2*TPIST+TM*TPIST**2+TPIST**3)
HR3=ANNC*(TM**3+TM**2*THEAD+TM*THEAD**2+THEAD**3)
HR4=ANNC*(TM**3+TM**2*TEXV+TM*TEXV**2+TEXV**3)
C
DQCR1=SURFC*ANNC*(TM**4-TWALL**4)/(360.*RPS)
DQCR2=SURFP*ANNC*(TM**4-TPIST**4)/(360.*RPS)
DQCR3=SURFH*ANNC*(TM**4-THEAD**4)/(360.*RPS)
DQCR4=SURFE*ANNC*(TM**4-TEXV**4)/(360.*RPS)
20 CONTINUE
C *****
C PRESSURE AT END OF STEP
C *****
PCF=PCI*VCYLP(K-1)*TF*WNIF/(VCYLP(K)*WNTI*TI)
C *****
C WORK DONE BY GAS DURING TIME STEP IN KJ
C *****
DWORKA=0.5*(PCF+PCI)*(VCYLA(K)-VCYLA(K-1))*100.0
DWORKE=0.5*(PCF+PCI)*(VCYLE(K)-VCYLE(K-1))*100.0
C *****
C INTERNAL ENERGY AT END OF TIME STEP
C *****
ETF=0.0
DO 21 I=1,4
21 ETF=ETF+WNF(I)*(8.3143*((COEFFA(I)-1.0)*TF+COEFFB(I)*TF**2
1 +COEFFC(I)*TF**3+COEFFD(I)*TF**4)-COEFFE(I))
UFINAL=ETF
C
C ***** CALCULATE HEAT TRANSFER FROM CREVICE VOLUME *****
C
C CREVICE VOLUME GAS TEMPERATURE — DEG K
TCV=(ASS*TWGC+APP*TWGP+ARR*TWCR)/(ASS+APP+ARR)
C HEAT TRANSFER DUE TO INCOMING HOT GAS — KJ/CRANKANGLE
DQCV=GE/(GE-1.)*(TM/TCV-1.)*VCV*(PCF-PCI)*1.E2
IF(PCF.LT.PCI) DQCV=0.0
C +++++
C *****
C FIRST LAW OF THERMODYNAMICS. FOR BALANCE, ERROR=0
C *****
C +++++
ERROR=ETF-ETI-DQF+DQCY+DQCR+DWORKA+DWORKE+DQCV
DERIV=0.0
DO 24 I=1,4
24 DERIV=DERIV+WNF(I)*8.3143*(COEFFA(I)-1.0+2.0*COEFFB(I)*TF
1 +3.0*COEFFC(I)*TF**2+4.0*COEFFD(I)*TF**3)
C SET NEW VALUE OF FINAL TEMPERATURE
ERROR=ERROR/DERIV

```

```

      TF=TF-ERROR
C      TEST FOR ACCURACY OF ESTIMATE OF TF.  IF NOT ACCURATE ENOUGH
C      RETURN TO LABEL 22 WITH BETTER ESTIMATE OF TF AND REPEAT
C      CALCULATION
      IF (ABS (ERROR) .GT. 0.01) GOTO 22
C
      RGAS=8.3143*(WN(1)+WN(2)+WN(3)+WN(4))/WM
      GE=CPT/(CPT-RGAS)
      TEXH=TF
      PRESS=14.5*PCF
      TRANK=1.8*TEXH
      VOL=61032.7*VCYLA(K)
      PERCNT=100.*FUELS/WFUEL
      WRITE(3,1020) PRANG(K),PRESS,TRANK,GE,VOL
1020 FORMAT (5(1X,E11.5))
      XSTIN=XST*39.372
C      ANSWER
      WORKA=WORKA+DWORKA
      WORKE=WORKE+DWORKE
      HEATRF=HEATRF+DQCY+DQCR
C
      QSLEV1=QSLEV1+DQCY1+DQCR1
      QPIST1=QPIST1+DQCY2+DQCR2
      QHEAD1=QHEAD1+DQCY3+DQCR3
      QEXHV1=QEXHV1+DQCY4+DQCR4
      QTOT1=QSLEV1+QPIST1+QHEAD1+QEXHV1
C
C      SUM CREVICE VOLUME HEAT TRANSFER (KJ)
C
      QCV=QCV+DQCV
C
C      EVALUATE INTEGRALS USED IN CALCULATING EFFECTIVE GAS TEMPERATURES
C
      HC1=HC1+(H+HR1)*SURFC
      HC2=HC2+(H+HR2)*SURFP
      HC3=HC3+(H+HR3)*SURFH
      HC4=HC4+(H+HR4)*SURFE
      HCT1=HCT1+(H+HR1)*SURFC*TM
      HCT2=HCT2+(H+HR2)*SURFP*TM
      HCT3=HCT3+(H+HR3)*SURFH*TM
      HCT4=HCT4+(H+HR4)*SURFE*TM
C
      TCP(K)=TF
      CALL UNITT(IUNITT,2,TCP(K))
      PCP(K)=PCF
      CALL UNITP(IUNITP,2,PCP(K),PBARAB)
C *****
C      TEST IF POWER CYCLE IS COMPLETE.  IF NOT RETURN TO LABEL 23
C *****
      IF (ANGLC.LT. (ANGLP-0.1)) GO TO 23
C *****
C      FINISH POWER CYCLE.  STORE RELEASE PRESSURE AND TEMPERATURE
C      AND CALCULATE INDICATED POWER
C *****

```

```

PCR=PCF
TCR=TF
WORKP=WORKA+WORKE
WORKT=WORKP+WORKGA+WORKGE
HEATT=HEATRF-HEATG
CYCLES=RPS*2.0/CYCLE
POWERA=WORKA*CYCLES
POWEE=WORKE*CYCLES
POWEGA=WORKGA*CYCLES
POWEGE=WORKGE*CYCLES
POWER=WORKT*CYCLES
VSWEPT=XSTA*FCYL*VREF
PMIP=(WORKT/VSWEPT)*0.01
HEATFL=WFUEL*CALVAL
C
C CHECK OVERALL ENERGY BALANCE (FOR COMPRESSION, COMB, EXPANSION)
C
  BALNCE= UFINAL-UNITL+HEATRF+WORKA-HEATFL+QCV
  PCBAL=BALNCE/HEATFL*100.
  WRITE(6,30) PCBAL
30  FORMAT(2X,'COMP-EXP ENERGY BALANCE =',F8.4,' % OF FUEL ENERGY'/)
C
C   PRINT OUT ANSWERS
  WRITE(4,116) PRANG(1),PCP(1),TCP(1)
116  FORMAT (6H ANGLE,F6.1,23H   TRAPPED PRESSURE,F7.1,
1    26H   TRAPPED TEMPERATURE,F7.1)
  WRITE(4,117) PRANG(KC),PCP(KC),TCP(KC)
117  FORMAT (6H ANGLE,F6.1,23H   COMPRESSION PRESSURE,F7.1,
1    26H   COMPRESSION TEMPERATURE,F7.1)
C   I=0
C 33 I=I+1
C   IF (PCP(I)-PCP(I+1)) 33,33,34
C 34 WRITE(4,118) PRANG(I),PCP(I),TCP(I)
  TMAX=0.
  PMAX=0.
  DO 33 I=1,K
    PMAX=AMAX1(PMAX,PCP(I))
33  TMAX=AMAX1(TMAX,TCP(I))
  WRITE(4,118) PRANG(I),PMAX,TMAX
118  FORMAT (6H ANGLE,F6.1,23H   MAXIMUM PRESSURE,F7.1,
1    '   MAXIMUM TEMPERATURE',F7.1)
  WRITE(4,119) PRANG(K),PCP(K),TCP(K)
119  FORMAT (6H ANGLE,F6.1,23H   RELEASE PRESSURE,F7.1,
1    26H   RELEASE TEMPERATURE,F7.1)
  WRITE(4,105) TRAF,EAFF,ACBB
105  FORMAT (17H AIR-FUEL RATIO =,F6.2,
1    30H   EFFECTIVE AIR-FUEL RATIO =,F6.2,
1    24H   START OF COMBUSTION =,F7.2)
  X=VCYLT/VOLMIN
  XX=X
  Y=VCYLP(K)/VOLMIN
  WRITE(4,106) X,Y
106  FORMAT (30H EFFECTIVE COMPRESSION RATIO =,F6.2,

```

1 32H EFFECTIVE EXPANSION RATIO =,F6.2)

```

      IF (IUNITK.EQ.2) GO TO 38
      WRITE(4,107)
107 FORMAT (20H INDICATED POWER KW)
      X=POWERA+POWEGA
      WRITE(4,108) POWERA,POWEGA,X
108 FORMAT (20HAIR POWER CYCLE =,F8.2,17H GAS EXCHANGE =,F8.2,
1 10H TOTAL =,F8.2)
39 WRITE(4,111) POWERF,PMIP
111 FORMAT (16HCOMBINED POWER =,F8.2,
1 36H MEAN INDICATED PRESSURE (BARS) =,F8.2)
      GO TO 40
38 WRITE(4,112)
112 FORMAT (23H INDICATED HORSE POWER)
      A=POWERA*1.34
      B=POWEGA*1.34
      X=A+B
      WRITE(4,108) A,B,X
41 A=POWERF*1.34
      B=PMIP*14.5
      AMEP=B
      IF (ALPHAT.LE.540.) GO TO 50
C
C CALCULATE EXHAUST TEMPERATURE FROM ENERGY BALANCE
C
      FUELF=WFUEL*CYCLES*2.205
      FZA = FUELF/AIRFL
      YY = HEATT/HEATFL
      DELH=(FZA*CALVAL*(1.-YY-WORKT/HEATFL)+HAIR-HREF)/(1.+FZA)
      CALL BAL(CARBON,FZA,TREF,DELH,TEXHC,GAM,DUM)
      TEXHC=TEXHC*1.8
C
      YY = YY*100.
      SHP = A
      IF (ISTOP.NE.1) WRITE(2,1000) FUELF,SCASW,TREFF,SCAEFF,TEXHC,
+ SHP,PURE,AIRFL,EQUIV,PMAX,TMAX,YY
1000 FORMAT (F10.7,T13,F8.5,T25,F7.3,T37,F7.3,T47,F7.1,T56,F7.2,T65,
+ F7.4,T77,F8.5,T86,F7.4,T96,F7.1,T107,F7.1,T116,F7.2)
C
      WRITE(4,113) A,B
113 FORMAT (17H COMBINED POWER =,F8.2,
1 38H MEAN INDICATED PRESSURE (P.S.I.) =,F8.2)
C
40 A=100.0*HEATRF/HEATFL
      B=-100.0*HEATG/HEATFL
      X=100.0*HEATT/HEATFL
      WRITE(4,114) A,B,X
114 FORMAT (35H PERCENT HEAT LOSS POWER CYCLE =,F6.2,
1 17H GAS EXCHANGE =,F6.2,10H TOTAL =,F6.2)
C
      Y=100.0*WORKT/HEATFL
      WRITE(4,115) Y
115 FORMAT(31H INDICATED THERMAL EFFICIENCY = ,F6.2)
C
C

```

```

      CALL HTRANS
C
C
C ***** CONVERGENCE TEST *****
C
      IF (ABS(SHP-SHPS).GT.SHP*.001) GO TO 45
      IF (ABS(TEXHC-TEXHS).GT.TEXHC*.001) GO TO 45
      IF (EQUIVD.GT.0..AND.ABS(EQUIV-EQUIVD).GT..001) GO TO 45
C
      IF(ISTOP.EQ.1) RETURN
      ISTOP=1
C
      APIST=.7854*(3.281*DCYL*DREF)**2*144.
      AIRVMX = AIRVMX*1550.15*FREF
      EXHVMX = EXHVMX*1550.15*FREF
      EXHAP=EXHVMX/APIST
      AIRAP=AIRVMX/APIST
      WRITE(2,2900) XX,EXHAP,AIRAP,GAM
2900 FORMAT(1X,28HEFFECTIVE COMPRESSION RATIO ,F8.4,5X,
+16HEXHVMX/APISTON= ,F9.4,5X,16HAIRVMX/APISTON= ,F9.4,5X,4HGE= ,
+ F7.4/)
      WRITE(2,1010) AMEP,GA,BLBACK,Y
1010 FORMAT(1X,39HINDICATED MEAN EFFECTIVE PRESSURE (PSI) ,F11.4,4X,
+ 3HGA=,F8.5,4X,18HBLOWBACK FRACTION=,F9.5,4X,
+ 20HINDICATED THERM EFF=,F6.2)
C *****
C   ENGINE FRICTION CALCULATION
C *****
      VPSTN=PVEL*3.281*60.
      FMEP1=12.964
      FMEP2=0.0030476
      FMEP3=0.65476E-6
      FMEP=FMEP1+VPSTN*(FMEP2+VPSTN*FMEP3)
      FMEP=FMEP*FMEPM
      FHP=FMEP*XSTA*XREF*3.281*APIST*REVREF*2./(550.*CYCLE)
      BHP=SHP-FHP
      BSFC=3600.*FUELF/BHP
C
      WRITE(2,1012)VPSTN,FMEP,BHP,BSFC
1012 FORMAT(1X,'PISTON MEAN VELOCITY (FPM) ',F9.2,4X,
+ 'FRICTION MEAN EFFECTIVE PRESSURE (PSI) ',F9.4,4X,
+ 'BRAKE HP=',F7.2,4X,'BSFC=',F8.5/)
      45 CONTINUE
      SHPS = SHP
      TEXHS = TEXHC
      50 CONTINUE
      RETURN
      END
C
      SUBROUTINE MASSFL(FHOLE,RUP,RDP,A0,GR,G,WFLOW)
C   IMPLICIT REAL(A-H,O-Z) , INTEGER(I-N)
C   SUBROUTINE TO CALCULATE MASS FLOW RATE OF A COMPRESSIBLE
C   FLUID THROUGH A PASSAGE
C

```

```

C  FHOLE =
C  RUP = RATIO OF UPSTREAM PRESSURE TO REFERENCE PRESSURE
C  RDP = RATIO OF DOWNSTREAM PRESSURE TO REFERENCE PRESSURE
C  A0 = RATIO OF SPEED OF SOUND OF FLUID TO REFERENCE SPEED OF
C      SOUND
C  GR = REFERENCE VALUE OF GAMMA, THE RATIO OF SPECIFIC HEATS
C  G = GAMMA, THE RATIO OF SPECIFIC HEATS
C  WFLOW = MASS FLOW RATE OF FLUID THROUGH PASSAGE (NON-DIMENSIONALIZED)
C
C
C  CALCULATE MACH NUMBER OF FLOW THROUGH PASSAGE TO DETERMINE
C  WHETHER FLOW IS CHOKED
C
  UM=SQRT((2.0/(G-1.0))*(((RUP/RDP)**((G-1.0)/G))-1.0))
  IF(UM.LT.1.0) GO TO 1
C
C  FLOW IS CHOKED
C
  FM=G*SQRT((2.0/(G+1.0))*((G+1.0)/(G-1.0)))
  GO TO 2
C
C  FLOW IS NOT CHOKED
C
1  FM=G*UM/(1.0+((G-1.0)/2.0)*UM**2)**((G+1.0)/(2.0*(G-1.0)))
C
C  CALCULATE MASS FLOW RATE
C
2  WFLOW=FHOLE*RUP*FM/(GR*A0)
  RETURN
  END
C
SUBROUTINE HTRANS
C
C  HEAT TRANSFER CALCULATIONS
C
  COMMON/XXX/ EQUIVD, RPM, PEXH, PAIR, TAIR,
1    CR, BORE, STROKE, CONROD, FPISTE, FPISTA,
2    EVO, EVC, AVO, AVC,
3    TWALL, WFUEL,
4    ACB, ACF,
5    ANNA, FMEPM,
6    NPCWF, DEL1, DEL2, DEL3, AAN(2),
7    VALEXH, CDE, NTEXH, WIDTHE, ALPHEX(50), FEXH(50),
8    VALAIR, CDA, NTAIR, WIDTHA, ALPAIR(50), FAIR(50)
  COMMON/GEN/ALPHAT, ANGEND, ANGRES, AIRP0, EXHP0, IMOLS,
1    APAIR, APEXH, AREF, AP(2),
1    APN(2), CYCLE, DALPHA,
1    DREF, DZ, FREF,
1    IPOWER, IREV, GA, GE, GREF, IUNITL,
1    IUNITP, IUNITT, IUNITK, IUNITW, IUNITQ,
1    WAR, PBARAB,
1    PI, PREF, REVENG, REVREF, RPAIR, RPEXH, RP(2),
1    RPN(2), STEP2, TEXH, TREF, VREF, WREF, XREF,
1    Z, ZREF, HAIR, HREF, SCMULT, NC

```



```

COMMON/CYL/ACSB,ALPHA,ALPHAE,ANNB,ANNC,AC,
1      ACN,ACR,ALPHAC,
1      CALVAL,CARBON,
1      COEFFA(4),COEFFB(4),COEFFC(4),COEFFD(4),
1      COEFFE(4),COEFFZ(4),CRANK,DCYL,DHEAT,
1      DRC,DVCYL,DWCIN,DWCP(2),DWCYL,
1      FCYL,HEATG,
1      PURITY,PVEL,PCR,PCYLT,
1      PORTS,RC,RCN,RCR,SURFC,
1      TCR,TCYLT,VSWEPT,
1      VCYL,WCAIR,WCIN,
1      WCOUT,WCYL,WMW(4),WPCNT(4),WCYLR,
1      WN(4),WORKGA,WORKGE,XCRA,XSTA,
1      NCD,WCYLT,DWCINT,
1      TPIST,THEAD,TEXV,CID
COMMON/COMB/AIRFL,EQUTV,TEXHS,SHPS,FZA,HRD,SCASW,TREFF,SCAEFF,
+ AIRVMX,EXHVMX,PORTED,STOIC,WCO,BLBACK,FUELF,BHP
COMMON/TEMP/TWEV,TWGH,TWGP,TWGC,TWCR,TWPR,TWCP,TWCC,TWCH,TEXHP,
1 TWEVG,TC1,TC2,TC3
COMMON/HEAT1/ QF,QFPC,QC,QPCP,A1,A1PC,A2,A2PC,A3,A3PC,
1 A4,A4PC,QCYL,QCYLPC
COMMON/HEAT2/ QEVG,QEVGPC,QEXHP,QEXHPC,
1 QTC1,QTC1PC,QTC2,QTC2PC,QTC3,QTC3PC,QOUT,QOUTPC
COMMON/HEAT/ NHEAT,QSLEV1,QPIST1,QHEAD1,QEXHV1,QTOT1,
1 QSLEV2,QPIST2,QHEAD2,QEXHV2,QTOT2,
2 HC1,HC2,HC3,HC4,HC5,HC6,HC7,HC8,
3 HCT1,HCT2,HCT3,HCT4,HCT5,HCT6,HCT7,HCT8
COMMON/INPT2/
1 XXEVG,XXEVH,XXPSL,XXPIS,XXPRG,XXHED,XXPCR,XXRSL,XXSLV,
2 AEXVS,AEXV,AEXST,AHEAD,ASLEEV,APIST1,APIST2,APISTR,ARING1,ARING2,
3 CEXV,CHEAD,CSLEEV,CPIST,CRING,
4 HEXHP,HOILP,HCSL,HCHD,
5 D1,D2,D3,D4,D5,D6,VCV,APP,ARR,ASS
COMMON/CV/ QCV,QCV1,QCV2,QCV3
COMMON/FRIC/ QFRIC1,QFRIC2,QFRIC3
DIMENSION A(9,10),AFAHR(9)
RPS=REVENG*REVREF

```

C

C CALCULATE EFFECTIVE GAS TEMPERATURES

C

```

TEG1=HCT1/HC1
TEG2=HCT2/HC2
TEG3=HCT3/HC3
TEG4=HCT4/HC4
TEG5=HCT5/HC5
TEG6=HCT6/HC6
TEG7=HCT7/HC7
TEG8=HCT8/HC8

```

C

```

HTOT1=HC1+HC5
HTOT2=HC2+HC6
HTOT3=HC3+HC7
HTOT4=HC4+HC8
HTTT1=HCT1+HCT5

```

```

HITT2=HCT2+HCT6
HITT3=HCT3+HCT7
HITT4=HCT4+HCT8
C
TTEG1=HITT1/HTOT1
TTEG2=HITT2/HTOT2
TTEG3=HITT3/HTOT3
TTEG4=HITT4/HTOT4
C
C CALCULATE RESISTANCES FROM NETWORK MODEL
C
R1=XXEVG/(AEXVS*CEXV)
R2=1./(HEXHP*AEXV)
R3=XXEVH/(AEXST*CEXV)
R4=XXHED/(AHEAD*CHEAD)
R5=1./(HCHD*AHEAD)
R6=XXPIS/(APIST1*CPIST)
R7=1./(HOILP*APIST2)
R8=XXPSL/(ASLEEV*CPIST)
R9=XXPCR/(APISTR*CPIST)
R10=XXRSL/(ARING1*CRING)
R11=XXSLV/(ASLEEV*CSLEEV)
R12=XXPRG/(ARING2*CRING)
R13=1./(HCSL*ASLEEV)
C
C WRITE(6,*) 'R(S) ', R1, R2, R3, R4, R5, R6, R7, R8, R9, R10, R11, R12, R13
C
R14=360./HTOT1
R15=360./HTOT2
R16=360./HTOT3
R17=360./HTOT4
C
RX1=360.*RPS/HC1
RX2=360.*RPS/HC2
RX3=360.*RPS/HC3
RX4=360.*RPS/HC4
RY1=360.*RPS/HC5
RY2=360.*RPS/HC6
RY3=360.*RPS/HC7
RY4=360.*RPS/HC8
C
QX1=(TEG1-TWALL)/RX1
QX2=(TEG2-TPIST)/RX2
QX3=(TEG3-THEAD)/RX3
QX4=(TEG4-TEXV)/RX4
QY1=(TEG5-TWALL)/RY1
QY2=(TEG6-TPIST)/RY2
QY3=(TEG7-THEAD)/RY3
QY4=(TEG8-TEXV)/RY4
C
C WRITE(6,*) QX1,QY1,QSLEV1,QSLEV2
C WRITE(6,*) QX2,QY2,QPIST1,QPIST2
C WRITE(6,*) QX3,QY3,QHEAD1,QHEAD2
C WRITE(6,*) QX4,QY4,QEXHV1,QEXHV2

```

```

C
C
C HEAT TRANSFER IN KJ/CYCLE
C
  QCYL1=QSLEV1-QSLEV2
  QCYL2=QPIST1-QPIST2
  QCYL3=QHEAD1-QHEAD2
  QCYL4=QEXHV1-QEXHV2
C
  QTOT1=QSLEV1+QPIST1+QHEAD1+QEXHV1
  QTOT2=QSLEV2+QPIST2+QHEAD2+QEXHV2
C
C CHECK CALCULATIONS
C
  QC1=(TTEG1-TWALL)/R14/RPS
  QC2=(TTEG2-TPIST)/R15/RPS
  QC3=(TTEG3-THEAD)/R16/RPS
  QC4=(TTEG4-TEXV)/R17/RPS
C  WRITE(6,*) 'QCYL1,QC1',QCYL1,QC1
C  WRITE(6,*) 'QCYL2,QC2',QCYL2,QC2
C  WRITE(6,*) 'QCYL3,QC3',QCYL3,QC3
C  WRITE(6,*) 'QCYL4,QC4',QCYL4,QC4
  QTOT=QCYL1+QCYL2+QCYL3+QCYL4
  QCTOT=QC1+QC2+QC3+QC4
C  WRITE(6,*) 'QTOT,QCTOT',QTOT,QCTOT
  QPC=QCTOT/WFUEL/CALVAL*100.
  WRITE(6,*) 'HEAT LOSS AS A PERCENTAGE OF FUEL INPUT:',QPC
C
C **** CALCULATE HEAT GENERATION DUE TO FRICTION ****
C
C   PISTON/RING FMFP FROM BISHOP'S EQUATION
C   BISHOP, J.N. "EFFECTS OF DESIGN VARIABLES ON FRICTION AND
C   ECONOMY," SAE PAPER 812A, (1964)
C
C MEAN PISTON SPEED (M/S)
  STROKE=XSTA
  BORE=DCYL
  CM=2.*STROKE*RPS
C OIL DENSITY (KG/M**3)
  DENOIL=55.31*16.018
C OIL VISCOSITY (KG/M-SEC) AT 200 DEG F
  VISOIL=250.E-5*1.4878
C REYNOLDS NUMBER
  RE=CM*DENOIL*BORE/VISOIL
C FMFP, FROM BISHOP (PA)
  FMFPB=(6.2E4*CR**0.2/RE)*DENOIL*CM**2
C  WRITE(6,*) 'FMFPB,RE,CM',FMFPB,RE,CM
C FRICTION TORQUE (N-M)
  FRICT=FMFPB*BORE*BORE*STROKE/8.
C FRICTION POWER LOSS (KW)
  FRICP=FRICT*2.*3.1415926*RPS/1000.
  FRICHP=FRICP/0.7456
C  WRITE(6,*) 'PISTON/RING FRICTION HP',FRICHP
C FRICTION HEAT GENERATION TERMS (KW)

```

```

CFRIC1=0.5
CFRIC2=0.5
QFRIC1=CFRIC1*CFRIC2*FRICP
QFRIC2=(1.-CFRIC2)*FRICP
QFRIC3=(1.-CFRIC1)*CFRIC2*FRICP
C
C ***** CREVICE VOLUME CALCULATIONS *****
C
C CREVICE VOLUME HEAT TRANSFER IN KW
C
QCV1=QCV*ARR/(ARR+ASS+APP)*RPS
QCV2=QCV*ASS/(ARR+ASS+APP)*RPS
QCV3=QCV*APP/(ARR+ASS+APP)*RPS
C
C GENERATE COEFFICIENT MATRIX FOR SOLUTION OF SYSTEM OF EQUATIONS
C
DO 100 I=1,9
DO 100 J=1,10
100 A(I,J)=0.
C
A(1,1)=-1./R13-1./R11
A(1,8)=1./R11
A(1,10)=-TC2/R13
C
A(2,2)=-1./R7-1./R6
A(2,6)=1./R6
A(2,10)=-TC1/R7
C
A(3,3)=-1./R5-1./R4
A(3,5)=1./R4
A(3,10)=-TC3/R5
C
A(4,4)=-1./R1-1./R2-1./R3-1./R17
A(4,5)=1./R3
A(4,10)=-TWEVG/R1-TEXHP/R2-TTEG4/R17
C
A(5,5)=-1./R4-1./R3-1./R16
A(5,3)=1./R4
A(5,4)=1./R3
A(5,10)=-TTEG3/R16
C
A(6,6)=-1./R8-1./R9-1./R6-1./R15
A(6,8)=1./R8
A(6,7)=1./R9
A(6,2)=1./R6
A(6,10)=-QFRIC3-TTEG2/R15
C
A(7,7)=-1./R9-1./R12
A(7,6)=1./R9
A(7,9)=1./R12
A(7,10)=-QCV3
C
A(8,8)=-1./R11-1./R10-1./R8-1./R14
A(8,1)=1./R11

```

```

A(8,9)=1./R10
A(8,6)=1./R8
A(8,10)=-QCV2-QFRIC2-TTEG1/R14
C
A(9,9)=-1./R10-1./R12
A(9,8)=1./R10
A(9,7)=1./R12
A(9,10)=-QCV1-QFRIC1
C
C SOLVE SYSTEM OF EQUATIONS TO GET METAL TEMPERATURES
C SOLUTION VECTOR IS LOCATED IN COLUMN 10 OF COEFFICIENT MATRIX
C TEMPERATURES ARE IN KELVIN
C
CALL ELIM(A,9,10,9)
C
TWCC=A(1,10)
TWCP=A(2,10)
TWCH=A(3,10)
TWEV=A(4,10)
TWGH=A(5,10)
TWGP=A(6,10)
TWPR=A(7,10)
TWGC=A(8,10)
TWCR=A(9,10)
C
DO 200 I=1,9
200 AFAHR(I)=A(I,10)*1.8-460.
C WRITE(6,1000) (A(I,10),AFAHR(I),I=1,9)
1000 FORMAT(2X,'COOLANT SIDE SLEEVE TEMPERATURE',F9.1,' K',F11.1,' F'/
1 2X,'OIL SIDE PISTON TEMPERATURE',5X,F8.1,' K',F11.1,' F'/
2 2X,'COOLANT SIDE HEAD TEMPERATURE',3X,F8.1,' K',F11.1,' F'/
3 2X,'EXHAUST VALVE TEMPERATURE',7X,F8.1,' K',F11.1,' F'/
4 2X,'GAS SIDE HEAD TEMPERATURE',7X,F8.1,' K',F11.1,' F'/
5 2X,'GAS SIDE PISTON CROWN TEMPERATURE',F7.1,' K',F11.1,' F'/
6 2X,'PISTON RIM TEMPERATURE',10X,F8.1,' K',F11.1,' F'/
7 2X,'GAS SIDE SLEEVE TEMPERATURE',5X,F8.1,' K',F11.1,' F'/
8 2X,'COMPRESSION RING TEMPERATURE',4X,F8.1,' K',F11.1,' F'/)
C
C CHECK ENERGY BALANCE ON HEAT TRANSFER NETWORK
C
C — ENERGY IN —
QF=QFRIC1+QFRIC2+QFRIC3
QC=QCV1+QCV2+QCV3
A1=(TTEG1-TWGC)/R14
A2=(TTEG2-TWGP)/R15
A3=(TTEG3-TWGH)/R16
A4=(TTEG4-TWEV)/R17
QCYL=QF+QC+A1+A2+A3+A4
QFPC=QF/QCYL*100.
QCPC=QC/QCYL*100.
A1PC=A1/QCYL*100.
A2PC=A2/QCYL*100.
A3PC=A3/QCYL*100.
A4PC=A4/QCYL*100.

```

```

      QCYLPC=100.
C  — ENERGY OUT —
      QEVG=(TWEV-TWEVG)/R1
      QEXHP=(TWEV-TEXHP)/R2
      QTC1=(TWCP-TC1)/R7
      QTC2=(TWCC-TC2)/R13
      QTC3=(TWCH-TC3)/R5
      QOUT=QEVG+QEXHP+QTC1+QTC2+QTC3
      QEVGPC=QEVG/QOUT*100.
      QEXHPC=QEXHP/QOUT*100.
      QTC1PC=QTC1/QOUT*100.
      QTC2PC=QTC2/QOUT*100.
      QTC3PC=QTC3/QOUT*100.
      QOUTPC=100.
C  PRINT OUT HEAT TRANSFER SUMMARY
C
C  WRITE(6,*) '      HEAT TRANSFER SUMMARY —KW'
C  WRITE(6,1001) QF,QFPC,QC,QCPC,
C  1  A1,A1PC,A2,A2PC,A3,A3PC,A4,A4PC,QCYL,QCYLPC
1001 FORMAT(2X,'FRICTION GENERATED HEAT TRANSFER',3X,F10.3,F11.2,' %'/
1  2X,'CREVICE VOLUME HEAT TRANSFER',F17.3,F11.2,' %'/
2  2X,'HEAT TRANSFER TO CYLINDER WALL',F15.3,F11.2,' %'/
3  2X,'HEAT TRANSFER TO PISTON',4X,F18.3,F11.2,' %'/
4  2X,'HEAT TRANSFER TO HEAD',6X,F18.3,F11.2,' %'/
5  2X,'HEAT TRANSFER TO EXHAUST VALVE',F15.3,F11.2,' %'/
6  2X,'TOTAL HEAT INPUT TO NETWORK',3X,F15.3,F11.2,' %'/)
C  WRITE(6,1002) QEVG,QEVGPC,QEXHP,QEXHPC,
C  1  QTC1,QTC1PC,QTC2,QTC2PC,QTC3,QTC3PC,QOUT,QOUTPC
1002 FORMAT(2X,'HEAT TRANSFER TO EXH VALVE GUIDE',3X,F10.3,F11.2,' %'/
1  2X,'HEAT TRANSFER TO EXHAUST PORT GASES',F10.3,F11.2,' %'/
2  2X,'HEAT TRANSFER TO PISTON COOLING OIL',F10.3,F11.2,' %'/
3  2X,'HEAT TRANSFER TO SLEEVE COOLING OIL',F10.3,F11.2,' %'/
4  2X,'HEAT TRANSFER TO HEAD COOLING OIL ',F10.3,F11.2,' %'/
5  2X,'TOTAL HEAT TRANSFER FROM NETWORK ',F10.3,F11.2,' %'/)
C
      RETURN
      END
C
      SUBROUTINE INPUT2
      COMMON/INPT2/
      1 XXEVG,XXEVH,XXPSL,XXPIS,XXPRG,XXHED,XXPCR,XXRSL,XXSLV,
      2 AEXVS,AEXV,AEXST,AHEAD,ASLEEV,APIST1,APIST2,APISTR,ARING1,ARING2,
      3 CEXV,CHEAD,CSLEEV,CPIST,CRING,
      4 HEXHP,HOILP,HCSL,HCHD,NEXHV,DEXHV,
      5 D1,D2,D3,D4,D5,D6,VCV,APP,ARR,ASS
      COMMON/XXX/ EQUIVD,RPM,PEXH,PAIR,TAIR,
      1      CR,BORE,STROKE,CONROD,FPISTE,FPISTA,
      2      EVO,EVC,AVO,AVC,
      3      TWALL,WFUEL,
      4      ACB,ACF,
      5      ANNA,FMEPM,
      6      NPCWF,DEL1,DEL2,DEL3,AAN(2),
      7      VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),
      8      VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)

```

```

COMMON/GEN/ALPHAT,ANGEND,ANGRES,AIRPO,EXHPO,IMOLS,
1  APAIR,APEXH,AREF,AP(2),
1  APN(2),CYCLE,DALPHA,
1  DREF,DZ,FREF,
1  IPOWER,IREV,GA,GE,GREF,IUNITL,
1  IUNITP,IUNITT,IUNITK,IUNITW,IUNITQ,
1  WAR,PBARAB,
1  PI,PREF,REVENG,REVREF,RPAIR,RPEXH,RP(2),
1  RPN(2),STEP2,TEXH,TREF,VREF,WREF,XREF,
1  Z,ZREF,HAIR,HREF,SCMULT,NC
COMMON/CYL/ACSB,ALPHA,ALPHAE,ANNB,ANNC,AC,
1  ACN,ACR,ALPHAC,
1  CALVAL,CARBON,
1  COEFFA(4),COEFFB(4),COEFFC(4),COEFFD(4),
1  COEFFE(4),COEFFZ(4),CRANK,DCYL,DHEAT,
1  DRC,DVCYL,DWCIN,DWCP(2),DWCYL,
1  FCYL,HEATG,
1  PURITY,PVEL,PCR,PCYLT,
1  PORTS,RC,RCN,RCR,SURFC,
1  TCR,TCYLT,VSWEPT,
1  VCYL,WCAIR,WCIN,
1  WCOUT,WCYL,WMW(4),WPCNT(4),WCYLR,
1  WN(4),WORKGA,WORKGE,XCRA,XSTA,
1  NCD,WCYLT,DWCINT,
1  TPIST,THEAD,TEXV,CID
COMMON/COMB/AIRFL,EQUIV,TEXHS,SHPS,FZA,HRD,SCASW,TREFF,SCAEFF,
+ AIRVMX,EXHVMX,PORTED,STOIC,WCO,BLBACK,FUELF,BHP
COMMON/TEMP/TWEV,TWGH,TWGP,TWGC,TWCR,TWPR,TWCP,TWCC,TWCH,TEXHP,
1  TWEVG,TC1,TC2,TC3
PI=3.141592654
C BORE AND STROKE IN FEET
  BORE=DCYL
  STROKE=XSTA
C
C OPEN DATA FILE FOR HEAT TRANSFER INPUT
C
  OPEN (10, FILE='DIESEL10.INP', STATUS='OLD')
C
C READ IN INITIAL ESTIMATES OF METAL TEMPERATURES (DEG F)
C
C
  READ(10,*) TWEV,TWGH,TWGP,TWGC,TWEVG
  TWEV=1000.
  TWGH=1000.
  TWGP=1000.
  TWGC=1000.
  TWEVG=1000.
C
C READ IN OIL AND COOLANT TEMPERATURES (DEG F)
C
C
  READ(10,*) TC1,TC2,TC3
  TC1=200.
  TC2=200.
  TC3=200.
C

```

```

C  CONVERT FROM FAHRENHEIT TO KELVIN
C
  TWEV=(TWEV+460.)/1.8
  TWGH=(TWGH+460.)/1.8
  TWGP=(TWGP+460.)/1.8
  TWGC=(TWGC+460.)/1.8
  TWEVG=(TWEVG+460.)/1.8
  TC1=(TC1+460.)/1.8
  TC2=(TC2+460.)/1.8
  TC3=(TC3+460.)/1.8
C
C  READ IN EXHAUST VALVE PARAMETERS AND CALCULATE EXHAUST VALVE AREA
C    DEXHV IN INCHES, AEXV IN SQUARE INCHES
C  READ(10,*) NEXHV,DEXHV
  NEXHV=4
  DEXHV=1.
  AEXV=FLOAT(NEXHV)*0.785398*DEXHV**2
C
C  READ IN PISTON RING/GROOVE DIMENSIONS (INCHES)
C
C  READ(10,*) D1,D2,D3,D4,D5,D6
  D1=0.375
  D2=0.130
  D3=0.130
  D4=0.005
  D5=0.125
  D6=0.125
C
C  READ IN CONDUCTION PATH LENGTHS (INCHES)
C
C  READ(10,*) XXEVG,XXEVH,XXPSL
C  READ(10,*) XXPIS,XXPRG,XXHED
C  READ(10,*) XXPCR,XXRSL,XXSLV
  XXEVG=0.
  XXEVH=0.
  XXPSL=0.
  XXPIS=0.
  XXPRG=0.
  XXHED=0.
  XXPCR=0.
  XXRSL=0.
  XXSLV=0.2
C
C  XXEVH=0.93
C  XXPIS=2.00
C  XXHED=0.800
C  XXSLV=0.750
C
C  CHECK FOR ZEROS, IF SO, USE DEFAULTS
C
  IF(XXEVG.LE.1.E-6) XXEVG=3.
  IF(XXEVH.LE.1.E-6) XXEVH=DEXHV/3.
  IF(XXPSL.LE.1.E-6) XXPSL=(BORE*12.)/3.
  IF(XXPIS.LE.1.E-6) XXPIS=0.5

```



```

IF (XXPRG.LE.1.E-6) XXPRG=D5
IF (XXHED.LE.1.E-6) XXHED=0.25
IF (XXPCR.LE.1.E-6) XXPCR=0.25
IF (XXRSL.LE.1.E-6) XXRSL=D6
IF (XXSLV.LE.1.E-6) XXSLV=0.25
C
C CONVERT FROM INCHES TO METERS
C
XXEVG=XXEVG/39.372
XXEVH=XXEVH/39.372
XXPSL=XXPSL/39.372
XXPIS=XXPIS/39.372
XXPRG=XXPRG/39.372
XXHED=XXHED/39.372
XXPCR=XXPCR/39.372
XXRSL=XXRSL/39.372
XXSLV=XXSLV/39.372
C
C READ IN HEAT TRANSFER AREAS (SQUARE INCHES)
C
C READ(10,*) AEXVS,AEXST
C READ(10,*) ASLEEV,APIST2
C READ(10,*) APISTR,ARING1,ARING2
AEXVS=0.
AEXST=0.
ASLEEV=0.
APIST2=0.
APISTR=0.
ARING1=0.
ARING2=0.
APIST1=FPISTA*PI/4.*BORE**2 * 144.
AHEAD=PI/4.*BORE**2*144. -AEXV
C
C CHECK FOR ZEROS, IF SO, USE DEFAULTS
C
IF (AEXVS.LE.1.E-9) AEXVS=FLOAT(NEXHV)*PI/4.*(0.25)**2
IF (AEXST.LE.1.E-9) AEXST=FLOAT(NEXHV)*PI*DEXHV*0.050
IF (ASLEEV.LE.1.E-9) ASLEEV=PI*BORE*(STROKE/4.)*144.
IF (APIST2.LE.1.E-9) APIST2=APIST1
IF (APISTR.LE.1.E-9) APISTR=PI*BORE*12.*0.5
IF (ARING1.LE.1.E-9) ARING1=PI*BORE*12.*D5
IF (ARING2.LE.1.E-9) ARING2=PI/4.*((BORE*12.-2.*D4)**2
1 - (BORE*12.-2.*D6)**2)
C
C CONVERT FROM SQUARE INCHES TO SQUARE METERS
C
AEXVS =AEXVS /39.372**2
AEXV =AEXV /39.372**2
AEXST =AEXST /39.372**2
ASLEEV=ASLEEV/39.372**2
APIST1=APIST1/39.372**2
APIST2=APIST2/39.372**2
APISTR=APISTR/39.372**2
ARING1=ARING1/39.372**2

```

```

    ARING2=ARING2/39.372**2
    AHEAD = AHEAD/39.372**2
C
C READ IN THERMAL CONDUCTIVITIES — BTU/(HR-FT-R)
C
C READ(10,*) CEXV,CHEAD,CSLEEV,CPIST,CRING
    CEXV=24.
    CHEAD=22.
    CSLEEV=22.
    CPIST=60.
    CRING=24.8
C
C CONVERT FROM BTU/(HR-FT-R) TO KW/(M-K)
C
    TT=1.054*3.281*1.8/3600.
    CEXV=CEXV*TT
    CHEAD=CHEAD*TT
    CSLEEV=CSLEEV*TT
    CPIST=CPIST*TT
    CRING=CRING*TT
C
C READ IN CONVECTIVE COEFFICIENTS — BTU/(HR-FT**2-R)
C
C READ(10,*) HEXHP,HOILP,HCSL,HCHD
C
C CONVERT FROM BTU/(HR-FT**2-R) TO KW/(M**2-K)
C
    HEXHP=10.
    HOILP=900.
    HCSL=200.
    HCHD=200.
C
C HOILP=900.
C
C HCSL=2000.
C
C HCHD=2000.
C
C HOILP=900.
C
C HCSL=1600.
C
C HCHD=1600.
    TT=1.054*3.281**2*1.8/3600.
    HEXHP=HEXHP*TT
    HOILP=HOILP*TT
    HCSL=HCSL*TT
    HCHD=HCHD*TT
C
C CONVERT FROM INCHES TO METERS
C
    D1=D1/39.372
    D2=D2/39.372
    D3=D3/39.372
    D4=D4/39.372
    D5=D5/39.372
    D6=D6/39.372
C
C CALCULATE CREVICE VOLUME CHARACTERISTICS
C

```

```

BORE=DCYL/3.281
VCV=PI/4.*(BORE**2-(BORE-2.*D4)**2)*D1
1 + PI/4.*(BORE**2-(BORE-2.*D4-2.*D2)**2)*(D3-D5)
2 + PI/4.*((BORE-2.*D6)**2-(BORE-2.*D4-2.*D2)**2)*D5
APP=PI*(BORE-2.*D4)*D1
1 + PI/4.*((BORE-2.*D4)**2-(BORE-2.*D4-2.*D2)**2)
ARR=PI/4.*(BORE**2-(BORE-2.*D6)**2)+PI*(BORE-2.*D6)*D5
ASS=PI*BORE*(D1+D3-D5)
C
CLOSE (10,STATUS='KEEP')
C
RETURN
END
C
SUBROUTINE BURNRT(ANGLA,ACB,ACF,WFUEL,DWFUEL)
C MODIFIED BURNING RATE MODEL —SAWTOOTH SHAPE
ACF1=ACF+360.
ACB1=ACB+0.8*(ACF1-ACB)
IF(ANGLA.LT.ACB) DWFUEL=0.
IF(ANGLA.GT.ACB .AND. ANGLA.LE.ACB1) DWFUEL
1 =WFUEL*(2./(ACF1-ACB))*((ANGLA-ACB)/(ACB1-ACB))
IF(ANGLA.GT.ACB1 .AND. ANGLA.LT.ACF1) DWFUEL
1 =WFUEL*(2./(ACF1-ACB))*((ACF1-ANGLA)/(ACF1-ACB1))
IF(ANGLA.GE.ACF1) DWFUEL=0.
RETURN
END

SUBROUTINE SPLFIT(JJ,IJ,NP,OPT,ANGROT,XKX,IXLGR,FY,IYLGR,X,Y,ITRP)
C
C——SUBROUTINE SPLFIT IS A GENERALIZED SPLINE CURVE FIT PROGRAM
C
C——THE INPUT PARAMETERS ARE
C JJ —OVERALL FLOW ITERATION NUMBER
C IJ —INTERVAL NUMBER
C NP —THE NUMBER OF POINTS DESCRIBING THE CURVE
C (A MINIMUM OF 3 POINTS ARE REQUIRED)
C OPT —OPTION FOR COORDINATE SYSTEM ROTATION (INTEGER)
C (USE ONLY FOR REGULAR CARTESIAN COORDINATE SYSTEM)
C 0 —NO ROTATION
C 1 —ROTATION (MUST SPECIFY ANGROT)
C ANGROT —COORDINATE ROTATION ANGLE (DEGREES)
C (DUMMY VALUE IF OPT=0)
C XKX(I) —THE NP X-VALUES DEFINING THE CURVE (25 MAX)
C (MUST BE IN ASCENDING ORDER)
C IXLGR —LOGARITHMIC X-AXIS INDICATOR
C 0 —CARTESIAN COORDINATE AXIS
C 1 —LOGARITHMIC COORDINATE AXIS
C FY(I) —THE NP Y-VALUES DEFINING THE CURVE
C (CORRESPONDING TO THE X-VALUES)
C IYLGR —LOGARITHMIC Y-AXIS INDICATOR
C 0 —CARTESIAN COORDINATE AXIS
C 1 —LOGARITHMIC COORDINATE AXIS
C——NOTE : THE FUNCTION SLOPES AT THE END POINTS ARE EVALUATED FROM THE FIRST
C TWO AND LAST TWO DATA INPUT POINTS. THESE POINTS MUST THUS BE

```

```

C      SELECTED TO GIVE A GOOD SLOPE REPRESENTATION
C      X —THE X VALUE WHERE THE FUNCTION VALUE IS DESIRED
C
C      —THE OUTPUT PARAMETERS ARE
C      Y —THE FUNCTION VALUE AT THE DESIRED X-VALUE
C      ITRP —TRAP FOR NON-CONVERGENCE
C
C      REAL MAT(25,51), L(25), FCT(25), MKM1, MK, LK, LR(25)
C      DIMENSION XKX(25), XK(25), FY(25), F(25)
C      DIMENSION XKR(25), FR(25)
C      INTEGER OPT
C
C      ITRP=0
C      N=NP-1
C      NP1=N+1
C      NP2=N+2
C      NP3=N+3
C      NM1=N-1
C      NTOT=(NP1+NP2)
C      DO 5 I=1, NP
C      XK(I)=XKX(I)
C      F(I)=FY(I)
C      5 CONTINUE
C      —CHANGE COORDINATES FOR LOGARITHMIC AXES
C      IF (IXLGR .EQ. 0) GOTO 210
C      DO 200 I=1, NP
C      IF (XK(I) .GT. 0.0) GOTO 198
C      ITRP=1
C      WRITE(6,606)
C      GO TO 1010
C      198 CONTINUE
C      XK(I)=ALOG10(XK(I))
C      200 CONTINUE
C      IF (X .LE. 0.0) X=1.E-5
C      X=ALOG10(X)
C      210 CONTINUE
C      IF (IYLGR .EQ. 0) GOTO 230
C      DO 220 I=1, NP
C      IF (F(I) .GT. 0.0) GOTO 202
C      ITRP=1
C      WRITE(6,608)
C      GO TO 1010
C      202 CONTINUE
C      F(I)=ALOG10(F(I))
C      220 CONTINUE
C      230 CONTINUE
C
C      IF (OPT .EQ. 0) GO TO 15
C      ANGROT=ANGROT*3.141593/180.
C      CAN=COS(ANGROT)
C      SAN=SIN(ANGROT)
C
C      DO 10 I=1, NP1
C      XKR(I)=XK(I)*CAN + F(I)*SAN

```

```

    FR(I)=F(I)*CAN -XK(I)*SAN
10 CONTINUE
15 CONTINUE
C
    DO 20 I=1,N
    IF(OPT .EQ. 0) GO TO 20
    LR(I)=XKR(I+1)-XKR(I)
20 L(I)=XK(I+1)-XK(I)
C-----GET SLOPES AT THE END POINTS
    YPFST=(F(2)-F(1))/(XK(2)-XK(1))
    YPLST=(F(NP1)-F(N))/(XK(NP1)-XK(N))
    IF(OPT .EQ. 1) YPFSTR=(FR(2)-FR(1))/(XKR(2)-XKR(1))
    IF(OPT .EQ. 1) YPLSTR=(FR(NP1)-FR(N))/(XKR(NP1)-XKR(N))
C-----INITIALIZE THE MATRIX TO ZERO
    DO 30 I=1,NP1
    DO 30 J=1,NP2
30 MAT(I,J)=0.
C-----ADD THE IDENTITY MATRIX TO GET THE OVERALL MATRIX
    DO 40 J=NP3,NTOT
    DO 40 I=1,NP1
    MAT(I,J)=0.
    IF((J-I) .EQ. (NP1 + 1)) GOTO 35
    GO TO 40
35 MAT(I,J)=1.
40 CONTINUE
C
    MAT(1,1)=L(1)/3.
    MAT(1,2)=L(1)/6.
    MAT(1,NP2)=(F(2)-F(1))/L(1)-YPFST
    MAT(NP1,N)=L(N)/6.
    MAT(NP1,NP1)=L(N)/3.
    MAT(NP1,NP2)=YPLST-(F(NP1)-F(N))/L(N)
    IF(OPT .EQ. 1) MAT(1,1)=LR(1)/3.
    IF(OPT .EQ. 1) MAT(1,2)=LR(1)/6.
    IF(OPT .EQ. 1) MAT(1,NP2)=(FR(2)-FR(1))/LR(1)-YPFSTR
    IF(OPT .EQ. 1) MAT(NP1,N)=LR(N)/6.
    IF(OPT .EQ. 1) MAT(NP1,NP1)=LR(N)/3.
    IF(OPT .EQ. 1) MAT(NP1,NP2)=YPLSTR-(FR(NP1)-FR(N))/LR(N)
C
    DO 50 I=2,N
    IM1=I-1
    IM2=I-2
    IP1=I+1
    MAT(I,IM1)=L(IM1)/6.
    MAT(I,I)=(L(IM1)+L(I))/3.
    MAT(I,IP1)=L(I)/6.
    MAT(I,NP2)=(F(IP1)-F(I))/L(I) - (F(I)-F(IM1))/L(IM1)
    IF(OPT .EQ. 1) MAT(I,IM1)=LR(IM1)/6.
    IF(OPT .EQ. 1) MAT(I,I)=(LR(IM1)+LR(I))/3.
    IF(OPT .EQ. 1) MAT(I,IP1)=LR(I)/6.
50 IF(OPT .EQ. 1) MAT(I,NP2)=(FR(IP1)-FR(I))/LR(I) -(FR(I)-FR(IM1))/LR(-
    *IM1)
C-----MAKE THE PIVOT ELEMENT THE LARGEST ELEMENT
    NSW=0

```

```

DO 70 J=1,NP1
IF(J .EQ. NP1)GO TO 75
DO 70 I=J,N
IP=I+1
IF(ABS(MAT(IP,J)) .LT. ABS(MAT(J,J)))GO TO 70
NSW=NSW+1
DO 60 JS=1,NTOT
STOR=MAT(J,JS)
MAT(J,JS)=MAT(IP,JS)
MAT(IP,JS)=STOR
60 CONTINUE
70 CONTINUE
75 CONTINUE
C-----REDUCE ELEMENTS IN PIVOT COLUMN TO ZERO, EXCEPT PIVOT
DO 110 J=1,NP1
DO 80 IR=1,NP1
80 FCT(IR)=MAT(IR,J)/MAT(J,J)
FCT(J)=0.
DO 100 IZER=1,NP1
DO 90 JZER=J,NTOT
MAT(IZER,JZER)=MAT(IZER,JZER)-FCT(IZER)*MAT(J,JZER)
90 CONTINUE
100 CONTINUE
110 CONTINUE
C-----GET THE DETERMINANT
DET=1.0
DO 120 K=1,NP1
120 DET=DET*MAT(K,K)
DET=DET*((-1.)**NSW)
C-----TRAP SINGULARITY
IF(ABS(MAT(NP1,NP1)) .LT. 1.E-7 .AND. ABS(DET) .LT. 1.E-7)GOTO 122
GO TO 125
122 WRITE(6,602) IJ,JJ
ITRP=1
GO TO 1010
125 CONTINUE
C-----DIVIDE EACH ROW BY IT'S PIVOT
DO 130 IPIV=1,NP1
DIV=MAT(IPIV,IPIV)
DO 130 JPIV=1,NTOT
MAT(IPIV,JPIV)=MAT(IPIV,JPIV)/DIV
130 CONTINUE
C-----FOR A GIVEN X, FIND THE XK THAT BRACKET IT AND CALCULATE GENERATED F
IND=0
IF(X .LE. XK(1))IND=1
IF(IND .EQ. 1)Y=F(1)
IF(IND .EQ. 1)GO TO 1000
IF(X .GE. XK(NP1))IND=2
IF(IND .EQ. 2)Y=F(NP1)
IF(IND .EQ. 2)GO TO 1000
C
DO 140 I=2,NP1
IND=0
IF(X .EQ. XK(I))Y=F(I)

```

```

      IF(X .EQ. XK(I))GO TO 1000
      IF(XK(I-1) .LT. X .AND. XK(I) .GT. X)GO TO 135
      GO TO 140
135 CONTINUE
      IM1=I-1
      MKM1=MAT(IM1,NP2)
      MK=MAT(I,NP2)
      XXM=XK(I-1)
      XX=XK(I)
      FK=F(I)
      FKM1=F(I-1)
      LK=XK(I)-XK(I-1)
      IF(OPT .EQ. 1)XXM=XKR(I-1)
      IF(OPT .EQ. 1)XX=XKR(I)
      IF(OPT .EQ. 1)FK=FR(I)
      IF(OPT .EQ. 1)FKM1=FR(I-1)
      IF(OPT .EQ. 1)LK=XKR(I)-XKR(I-1)
      GO TO 142
140 CONTINUE
142 CONTINUE
C
      IF(OPT .EQ. 0)GO TO 160
      ANGRT1=ANGROT
      ANGRT2=ANGROT
      ANGRT3=ANGROT
      ANGRT4=ANGROT
      Y1L=(MKM1*(XX-XXM)**3)/(6.*LK)+(FKM1/LK-LK*MKM1/6.)*(XX-XXM)
      Y2L=(1.0/TAN(ANGRT1))*XXM-X/SIN(ANGRT2)
      IF(Y1L .GT. Y2L) INDC=1
      IF(Y2L .GT. Y1L) INDC=-1
      INDCP=INDC
      INDCPI=-INDCP
      DELXR=(XX-XXM)/10.
      XR=XXM
C
      DO 150 I=1,30
      XR=XR+DELXR
      IF(XR .GT. XX)GO TO 152
      TERM1=(MKM1*(XX-XR)**3)/(6.*LK)
      TERM2=(MK*(XR-XXM)**3)/(6.*LK)
      TERM3=(FK/LK-MK*LK/6.)*(XR-XXM)
      TERM4=(FKM1/LK-LK*MKM1/6.)*(XX-XR)
      Y1=TERM1+TERM2+TERM3+TERM4
      Y2=(1.0/TAN(ANGRT3))*XR-X/SIN(ANGRT4)
      IF(Y1 .GT. Y2) INDC=1
      IF(Y2 .GT. Y1) INDC=-1
      CRIT=ABS(Y1-Y2)/ABS(Y1)
      IF(CRIT .LE. 1.E-4)GO TO 155
      IF(INDC .EQ. INDCPI)DELXR=-DELXR/10.
      IF(INDC .EQ. INDCPI) INDCP=INDCPI
      IF(INDC .EQ. INDCPI) INDCPI=-INDCP
150 CONTINUE
C
      GO TO 155

```

```

152 WRITE(6,604) I, LJ, JJ
    ITRP=1
    GO TO 1010
155 CONTINUE
    ANGINV=-ANGROT
    SANI=SIN(ANGINV)
    CANI=COS(ANGINV)
    Y=Y1*CANI -XR*SANI
C-----X=XR*CANI + Y1*SANI
    GO TO 1000
160 CONTINUE
    TERM1=(MKM1*(XX-X)**3)/(6.*LK)
    TERM2=(MK*(X-XXM)**3)/(6.*LK)
    TERM3=(FK/LK-MK*LK/6.)*(X-XXM)
    TERM4=(FKM1/LK-LK*MKM1/6.)*(XX-X)
    Y=TERM1+TERM2+TERM3+TERM4
C-----FORMAT STATEMENTS
602 FORMAT(/,1X,44HABORT -SINGULAR MATRIX IN SUBROUTINE SPLFIT,/, -
    *1X,11HIN INTERVAL,I3,24H, OVERALL FLOW ITERATION,I3,/)
604 FORMAT(/,1X,62HABORT -COORDINATE ROTATION CALCULATIONS HAVE NOT C-
    *ONVERGED IN,I4,1X,31HITERATIONS IN SUBROUTINE SPLFIT,/, -
    *1X,11HIN INTERVAL,I3,24H, OVERALL FLOW ITERATION,I3,/)
606 FORMAT(/,1X,61HABORT -NEGATIVE NUMBER SPECIFIED IN LOGARITHMIC X-
    *AXIS ARRAY,/)
608 FORMAT(/,1X,61HABORT -NEGATIVE NUMBER SPECIFIED IN LOGARITHMIC Y-
    *AXIS ARRAY,/)
1000 CONTINUE
    IF(IXLGR.EQ.1)X=(10.0)**(X)
    IF(IYLGR.EQ.1)Y=(10.0)**(Y)
1010 CONTINUE
    RETURN
    END

C
    SUBROUTINE UNITP(IA,IB,PP,PPB)
C    IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)
    IF(IB.EQ.2) GO TO 1
    IF(IA.EQ.1) GO TO 2
    IF(IA.EQ.2) GO TO 3
    PP=(PP+PPB)/14.5
    GO TO 2
3 PP=PP/14.5
2 RETURN
1 IF(IA.EQ.1) GO TO 4
    IF(IA.EQ.2) GO TO 5
    PP=(PP+PPB)*14.5
    GO TO 4
5 PP=PP*14.5
4 RETURN
    END

C
    SUBROUTINE UNITT(IA,IB,TT)
C    IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)
    IF(IB.EQ.2) GO TO 1
    IF(IA.EQ.1) GO TO 2

```



```

      IF (IA.EQ.2) GO TO 3
      IF (IA.EQ.3) GO TO 4
      TT=(TT+460.0)/1.8
      GO TO 2
3    TT=TT+273.0
      GO TO 2
4    TT=TT/1.8
2    RETURN
1    IF (IA.EQ.1) GO TO 5
      IF (IA.EQ.2) GO TO 6
      IF (IA.EQ.3) GO TO 7
      TT=1.8*TT-460.0
      GO TO 5
6    TT=TT-273.0
      GO TO 5
7    TT=1.8*TT
5    RETURN
      END
C
      SUBROUTINE UNITW(IA,IB,WW)
C    IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)
      IF (IB.EQ.2) GO TO 1
      IF (IA.EQ.1) GO TO 2
      WW=WW/2.205
2    RETURN
1    IF (IA.EQ.1) GO TO 3
      WW=WW*2.205
3    RETURN
      END
C
      SUBROUTINE STROK(XSTROK,DSTROK,THETA,STROKE,CONROD,RPS,ZR)
C    IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)
      CONRAT=2.0*CONROD/STROKE
      PI=3.14159
      THETA=THETA*PI/180.0
      FNN=SQRT(CONRAT**2-SIN(THETA)**2)
      IF (DSTROK.EQ.0.0) GO TO 1
      DSTROK=(PI/360.0)*ZR*RPS*STROKE*(SIN(THETA)+SIN(2.0*THETA)/
1      (2.0*FNN))
1    XSTROK=0.5*STROKE*(1.0+CONRAT-COS(THETA)-FNN)
      RETURN
      END
C
      SUBROUTINE CYLVOL(FCYLG,XSTROK,STROKE,CRR,DSTROK,VCYLG,DVCYLG)
C    IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)
      VCYLG=FCYLG*(XSTROK+STROKE/(CRR-1.0))
      DVCYLG=FCYLG*DSTROK
      RETURN
      END
C
      SUBROUTINE SREA(SAREA,VCYLL,FCYLL,DCYLL,XR,DR,F1,F2)
C    IMPLICIT REAL(A-H,O-Z), INTEGER(I-N)
      SAREA=4.0*VCYLL*XR/(DCYLL*DR)+(F1+F2)*FCYLL
      RETURN

```

```

END
C
SUBROUTINE BAL(CARBON,FZA,T1,DELH,T2,GAM,H3)
C OVERALL ENERGY BALANCE
C FZA=OVERALL FUEL/AIR RATIO
C T=TEMPERATURE, K
C DELH=ENTHALPY CHANGE, KJ/KG
DIMENSION X(4)
C IMPLICIT REAL(A-H,O-Z), INTEGER (I-N)
COMMON/JANAF/ A(4),B(4),C(4),D(4)
X(1)=.79
X(3)=FZA*CARBON*28.85/12.01
X(4)=FZA*(1.-CARBON)*28.85/2.016
X(2)=.21-X(3)-.5*X(4)
SUM=X(1)+X(2)+X(3)+X(4)
X(1)=X(1)/SUM
X(2)=X(2)/SUM
X(3)=X(3)/SUM
X(4)=X(4)/SUM
IF (DELH.EQ.0.) GO TO 15
H1=0.
DO 5 I=1,4
5 H1=H1+X(I)*8.3143*(A(I)*T1+B(I)*T1**2+C(I)*T1**3+D(I)*T1**4)
H2=H1+DELH*(FZA+1.)*28.85/SUM
T2=T1+100.
15 H2C=0.
DO 10 I=1,4
10 H2C=H2C+X(I)*8.3143*(A(I)*T2+B(I)*T2**2+C(I)*T2**3+D(I)*T2**4)
H3=H2C*SUM/(28.85*(1.+FZA))
CP=0.
DO 20 I=1,4
20 CP=CP+X(I)*8.3143*(A(I)+2.*B(I)*T2+3.*C(I)*T2**2+4.*D(I)*T2**3)
GAM=CP/(CP-8.3143)
IF (DELH.EQ.0.) RETURN
IF (ABS(H2C-H2).LE.H2*.0001) GO TO 25
T2=T2+(H2-H2C)/CP
GO TO 15
25 RETURN
END
C
SUBROUTINE FOPEN
CHARACTER*16 FNAME1,FNAME2,FNAME3,FNAME4
COMMON/OPEN/ FNAME1,FNAME2,FNAME3,FNAME4
OPEN (1, FILE='DIESEL1.INP', STATUS='OLD')
OPEN (2, FILE=FNAME1, STATUS='NEW')
OPEN (3, FILE=FNAME2, STATUS='NEW')
OPEN (4, FILE=FNAME3, STATUS='NEW')
RETURN
END
C
SUBROUTINE FCLOSE
CLOSE (1, STATUS='KEEP')
CLOSE (2, STATUS='KEEP')
CLOSE (3, STATUS='KEEP')

```

```

CLOSE (4,STATUS='KEEP')
RETURN
END
C
SUBROUTINE INPUT
C  IMPLICIT REAL(A-H,O-Z) , INTEGER(I-N)
  DIMENSION TITLE(20)
  COMMON/XXX/ EQUIVD,RPM,PEXH,PAIR,TAIR,
1    CR,BORE,STROKE,CONROD,FPISTE,FPISTA,
2    EVO,EVC,AVO,AVC,
3    TWALL,WFUEL,
4    ACB,ACF,
5    ANNA,FMEPM,
6    NPCWF,DEL1,DEL2,DEL3,AAN(2) ,
7    VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50) ,FEXH(50) ,
8    VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50) ,FAIR(50)
  COMMON/GEN/ALPHAT,ANGEND,ANGRES,AIRP0,EXHP0,IMOLS,
1    APAIR,APEXH,AREF,AP(2) ,
1    APN(2) ,CYCLE,DALPHA,
1    DREF,DZ,FREF,
1    IPOWER,IREV,GA,GE,GREF,IUNITL,
1    IUNITP,IUNITT,IUNITK,IUNITW,IUNITQ,
1    WAR,PBARAB,
1    PI,PREF,REVENG,REVREF,RPAIR,RPEXH,RP(2) ,
1    RPN(2) ,STEP2,TEXH,TREF,VREF,WREF,XREF,
1    Z,ZREF,HAIR,HREF,SMULT,NC
  COMMON/CYL/ACSB,ALPHA,ALPHAE,ANNB,ANNC,AC,
1    ACN,ACR,ALPHAC,
1    CALVAL,CARBON,
1    COEFFA(4) ,COEFFB(4) ,COEFFC(4) ,COEFFD(4) ,
1    COEFFE(4) ,COEFFZ(4) ,CRANK,DCYL,DHEAT,
1    DRC,DVCYL,DWCIN,DWCP(2) ,DWCYL,
1    FCYL,HEATG,
1    PURITY,PVEL,PCR,PCYLT,
1    PORTS,RC,RCN,RCR,SURFC,
1    TCR,TCYLT,VSWEPT,
1    VCYL,WCAIR,WCIN,
1    WCOU,WCYL,WMW(4) ,WPCNT(4) ,WCYLR,
1    WN(4) ,WORKGA,WORKGE,XCRA,XSTA,
1    NCD,WCYLT,DWCINT,
1    TPIST,THEAD,TEXV,CID
  COMMON/COMB/AIRFL,EQUIV,TEXHS,SHPS,FZA,HRD,SCASW,TREFF,SCAEFF,
+ AIRVMX,EXHVMX,PORTED,STOIC,WCO,BLBACK,FUELF,BHP
  COMMON/CPURE/WCA,WCHG,IMIX
  WRITE(4,10)
  WRITE(2,10)
10 FORMAT ('BENSON DIESEL ENGINE MODEL'/)
C  READ(1,20) TITLE
C  WRITE(4,21) TITLE
C  WRITE(2,21) TITLE
C 20 FORMAT(20A4)
C 21 FORMAT(1X,20A4)
C
  IPOWER=10

```

```

CYCLE=2.
ANGEND=7200.
PORTED=2.
COOLED=2.
IF (PORTED.EQ.0.) PORTED = 1.
C
IUNITP=2
IUNITT=3
IUNITL=2
IUNITW=2
IUNITK=2
IUNITQ=3
C
C READ(1,*) EQUIVD,RPM,PEXH,PAIR,TAIR
C WRITE(2,*) EQUIVD,RPM,PEXH,PAIR,TAIR
REVENG=RPM/60.
PBARAB=14.7
PREF=14.7
TREF=518.7
GREF=1.4
REVREF=REVENG
C
TEXH=2100.
GE=1.33
GA=1.4
WAR=0.
C
STEP2=2.
C
C READ(1,*) CR,BORE,STROKE,CONROD,FPISTA
C WRITE(2,*) CR,BORE,STROKE,CONROD,FPISTA
DCYL=BORE/12.
XSTA=STROKE/12.
XCRA=CONROD/12.
C
C READ(1,*) EVO,EVC,AVO,AVC
C WRITE(2,*) EVO,EVC,AVO,AVC
ACSB=EVC
IF(AVC.GT.EVC) ACSB=AVC
C
C READ(1,*) TWALL,WFUEL
C WRITE(2,*) TWALL,WFUEL
PURITY=0.9
PCYLT=185.
TCYLT=1290.
CRANK=0.
NCD=0
C
C READ(1,*) ACB,ACF
C WRITE(2,*) ACB,ACF
TPIST=TWALL
THEAD=TWALL
TEXV=TWALL
C

```

```

      CALVAL=42515.
C   READ(1,*) ANNA,FMEPM
C   WRITE(2,*) ANNA,FMEPM
      SCMULT=1.1
      ANNB=0.7
      ANNC=0.327E-10
C   WOSCHNI HEAT LOSS MODEL ASSUMED WHEN ANNB=0.8 AND ANNC=0.
      IF(SCMULT.EQ.0.) SCMULT=1.
      IF(FMEPM.EQ.0.) FMEPM=1.
C
      CARBON=0.85561
C   READ(1,*) NPCWF,DEL1,DEL2,DEL3,AAN(1),AAN(2)
C   WRITE(2,*) NPCWF,DEL1,DEL2,DEL3,AAN(1),AAN(2)
C   AAN(1),ANN(2) FUEL INJECTION CONSTANTS FOR WHITEHOUSE-WAY MODEL
      IF(AAN(1).EQ.0.) AAN(1)=1.
      IF(AAN(2).EQ.0.) AAN(2)=1.
      IF(DEL1.EQ.0.) DEL1=6.9
      IF(DEL2.EQ.0.) DEL2=2.1
      STOIC=1./((CARBON/12.01+(1.-CARBON)/(1.008*4.))*(32.0+3.76*28.0))
C   AVL HEAT RELEASE MODEL USED WHEN NPCWF = 0, DEL3=0.
C   WIEBE HEAT RELEASE MODEL USED WHEN NPCWF=0, DEL3 .GT. 0.
C   WHITEHOUSE-WAY MODEL USED WHEN NPCWF .LT. 0
C   WATSON MODEL USED WHEN NPCWF.GT.0
      IF (NPCWF.GT.0) HRD=125.0
      IF (NPCWF.EQ.0) HRD=DEL3
C
C   READ(1,*) VALEXH
C   WRITE(2,*) VALEXH
      IF(VALEXH.EQ.0.0) GO TO 8
C
C   READ(1,*) CDE,NTEXH
C   WRITE(2,*) CDE,NTEXH
C
C   READ(1,*) (ALPHEX(N),FEXH(N),N=1,NTEXH)
C   WRITE(2,191) (ALPHEX(N),FEXH(N),N=1,NTEXH)
191  FORMAT(1X,2E10.3)
      DO 192 N=1,NTEXH
192  ALPHEX(N)=ALPHEX(N)+EVO
      GO TO 9
C
      8 CONTINUE
C   READ(1,*) CDE,WIDTHE
C   WRITE(2,*) CDE,WIDTHE
C
      9 CONTINUE
C   READ(1,*) VALAIR
C   WRITE(2,*) VALAIR
      IF(VALAIR.EQ.0.0) GO TO 200
C
C   READ(1,*) CDA,NTAIR
C   WRITE(2,*) CDA,NTAIR
C
C   READ(1,*) (ALPAIR(N),FAIR(N),N=1,NTAIR)
C   WRITE(2,*) (ALPAIR(N),FAIR(N),N=1,NTAIR)

```

```

DO 193 N=1,NTAIR
193 ALPAIR(N)=ALPAIR(N)+AVO
GO TO 201

```

```

C
200 CONTINUE
C READ(1,*) CDA,WIDTHA
C WRITE(2,*) CDA,WIDTHA
C
201 RETURN
END

```

```

C
SUBROUTINE HEADER
COMMON/XXX/ EQUIVD,RPM,PEXH,PAIR,TAIR,
1 CR,BORE,STROKE,CONROD,FPISTE,FPISTA,
2 EVO,EVC,AVO,AVC,
3 TWALL,WFUEL,
4 ACB,ACF,
5 ANNA,FMEPM,
6 NPCWF,DEL1,DEL2,DEL3,AAN(2),
7 VALEXH,CDE,NTEXH,WIDTHE,ALPHEX(50),FEXH(50),
8 VALAIR,CDA,NTAIR,WIDTHA,ALPAIR(50),FAIR(50)
COMMON/GEN/ALPHAT,ANGEND,ANGRES,AIRPO,EXHPO,IMOLS,
1 APAIR,APEXH,AREF,AP(2),
1 APN(2),CYCLE,DALPHA,
1 DREF,DZ,FREF,
1 IPOWVER,IREV,GA,GE,GREF,IUNITL,
1 IUNITP,IUNITT,IUNITK,IUNITW,IUNITQ,
1 WAR,PBARAB,
1 PI,PREF,REVENG,REVREF,RPAIR,RPEXH,RP(2),
1 RPN(2),STEP2,TEXH,TREF,VREF,WREF,XREF,
1 Z,ZREF,HAIR,HREF,SCMULT,NC
COMMON/CYL/ACSB,ALPHA,ALPHAE,ANNB,ANNC,AC,
1 ACN,ACR,ALPHAC,
1 CALVAL,CARBON,
1 COEFFA(4),COEFFB(4),COEFFC(4),COEFFD(4),
1 COEFFE(4),COEFFZ(4),CRANK,DCYL,DHEAT,
1 DRC,DVCYL,DWCIN,DWCP(2),DWCYL,
1 FCYL,HEATG,
1 PURITY,PVEL,PCR,PCYLT,
1 PORTS,RC,RCN,RCR,SURFC,
1 TCR,TCYLT,VSWEPT,
1 VCYL,WCAIR,WCIN,
1 WCOUT,WCYL,WMW(4),WPCNT(4),WCYLR,
1 WN(4),WORKGA,WORKGE,XCRA,XSTA,
1 NCD,WCYLT,DWCINT,
1 TPIST,THEAD,TEXV,CID
COMMON/COMB/AIRFL,EQUIV,TEXHS,SHPS,FZA,HRD,SCASW,TREFF,SCAEFF,
+ AIRVMX,EXHVMX,PORTED,STOIC,WCO,BLBACK,FUELF,BHP
COMMON/CPURE/WCA,WCHG,IMIX
WRITE(3,2048)
2048 FORMAT(4X,'ANGLE',5X,'PRESSURE',3X,'TEMPERATURE',4X,
1 'GAMMA',5X,'VOLUME',5X,'MEAN TEMP'/)

```

```

C
NC=1

```

```

WRITE(2,1027)
WRITE(2,1028) TWALL,WFUEL,ACB,ACF,TPIST,THEAD,WAR
1027 FORMAT(43X,'WALL',7X,'FUEL',8X,'COMBUSTION',5X,'PISTON',4X,
+ 'CHAMB'/11X,13X,13X,6X,'TEMP',5X,
+ 'PER CYCLE',4X,'START FINISH',5X,'TEMP    TEMP',5X,'WAR'/)
1028 FORMAT(39X,      F9.1,E13.3,F9.1,F7.1,F10.1,F9.1,3X,F6.4)
1035 FORMAT(14H CYLINDER BORE,F8.4/7H STROKE,F9.4/
1      50H SURFACE AREA PISTON / CYLINDER CROSS SECTION AREA,F8.4
2      /22H CONNECTING ROD LENGTH,F9.4)
DCYL12=DCYL*12
XSTA12=XSTA*12
XCRA12=XCRA*12
CID=.7854*DCYL12**2*XSTA12
WRITE(2,1035) DCYL12,XSTA12,FPISTA,XCRA12
WRITE(2,1038) CR,CID
1038 FORMAT(26H NOMINAL COMPRESSION RATIO,F8.4,5X,'SWEPT VOLUME (IN3) '
+,F8.3)
WRITE(2,1040) EVO,EVC,AVO,AVC,ACSB,AAN(1),AAN(2)
1040 FORMAT(/12H PORT TIMING//4H EVO,F7.1/4H EVC,F7.1/4H AVO,F7.1/
1      4H AVC,F7.1/32H ANGLE COMPRESSION STROKE BEGINS,F7.1,5X,
1'AAN(1)= ',F6.3,5X,'AAN(2)= ',F6.3)
IF (VALEXH.GT.5.) GO TO 85
WRITE(2,1042) WIDTHE
1042 FORMAT(28H PERCENTAGE PORT WIDTH (EXH),F9.4)
GO TO 86
85 WRITE(2,1043) CDE
1043 FORMAT(26H COEFFICIENT CD (EXH) VALVE,F7.4)
86 IF (VALAIR.GT.5.) GO TO 87
WRITE(2,1044) WIDTHA
1044 FORMAT(27H PERCENTAGE PORT WIDTH (AIR),F9.4)
GO TO 88
87 WRITE(2,1045) CDA
1045 FORMAT(25H COEFFICIENT CD (AIR) PORT,F7.4)
88 SPEED=REVEN*60.
WRITE(2,2047) SPEED,PAIR,TAIR,PEXH
2047 FORMAT(11H SPEED (RPM),F10.2,5X,26H SUPPLY AIR PRESSURE (PSIA),
+ F8.2,5X,19H SUPPLY AIR TEMP (R),F8.2,5X,23H EXHAUST PRESSURE (PSIA)
+,F8.2/)
WRITE(2,1049) CALVAL,CARBON,DEL1,DEL2,DEL3
1049 FORMAT(22H CALORIFIC VALUE (KJ/KG),F10.2,4X,
1      15H CARBON FRACTION,F8.5,4X,5H DEL1 ,F6.4,4X,5H DEL2 ,F6.4,
+4X,5H DEL3 ,F6.4)
WRITE(2,1051) ANNA,FMEPM,ANNB
1051 FORMAT(1H ,8H ANNAND A,F7.4,49X,
+      5X,'FMEPM= ',F5.3,/9H ANNAND B,F7.4)
WRITE(2,1052) ANNC
WRITE(2,3000)
3000 FORMAT(/1X, 9H FUEL FLOW,2X, 9H SCAV RAT.,3X, 8H TRAPPING,3X,
+ 8H SCAVENGE,2X, 8H TEMP OUT,3X, 5H POWER,5X, 4H TRUE,5X, 8H AIR FLOW,
+ 3X, 5H EQUIV,5X, 5H P MAX,6X, 5H T MAX,4X, 7H PERCENT)
WRITE(2,3010)
3010 FORMAT(2X, 6H LB/SEC,5X, 6H SW VOL,7X, 3H EFF,8X, 3H EFF,9X, 1H R,8X,
+ 2H HP,5X, 6H PURITY,5X, 6H LB/SEC,15X, 4H PSIA,8X, 1H R,5X,
+ 9H HEAT LOSS/)

```

```

1052 FORMAT(1H , 8HANNAND C, E12.4, 2X, 16H KW/(M**2) (K**4))
      RETURN
      END
C
      BLOCK DATA
C      FOURTH ORDER POLYNOMIAL CURVE FIT TO JANAF TABLE DATA
C      IN THE RANGE 400 K TO 2400 K
C      THIS DATA CAN BE USED TO FIND ENTHALPY, INTERNAL ENERGY, AND
C      SPECIFIC HEAT USING THE FOLLOWING EQUATIONS
C       $H(I) = R (A(I) * T + B(I) * T^{**2} + C(I) * T^{**3} + D(I) * T^{**4})$ 
C       $U(I) = R ( (A(I) - 1.) * T + B(I) * T^{**2} + C(I) * T^{**3} + D(I) * T^{**4})$ 
C       $CP(I) = R (A(I) + 2 * B(I) * T + 3 * C(I) * T^{**2} + 4 * D(I) * T^{**3})$ 
C
C      WHERE H(I) IS THE SENSIBLE MOLAR ENTHALPY OF SPECIES I, J/GMOL
C      U(I) IS THE SENSIBLE MOLAR ENTHALPY OF SPECIES I, J/GMOL
C      CP(I) IS THE MOLAR SPECIFIC HEAT AT CONSTANT PRESSURE, J/GMOL-K
C
      COMMON/JANAF/ A(4), B(4), C(4), D(4)
      DATA A/3.00845, 2.94628, 3.29003, 3.50953/
      DATA B/6.15041E-4, 1.03617E-3, 2.69417E-3, 6.54488E-4/
      DATA C/-1.09800E-7, -3.39775E-7, -8.66074E-7, 9.41722E-8/
      DATA D/5.68186E-12, 4.75627E-11, 1.11529E-10, -3.43661E-11/
      END

```



# Report Documentation Page

1. Report No. NASA TM-100940 AVSCOM TR-88-C-025		2. Government Accession No.		3. Recipient's Catalog No.	
4. Title and Subtitle Documentation of the Benson Diesel Engine Simulation Program				5. Report Date August 1988	
				6. Performing Organization Code	
7. Author(s) Jon Van Gerpen				8. Performing Organization Report No. E-4221	
				10. Work Unit No. IL161102AH45 505-62-OK	
9. Performing Organization Name and Address NASA Lewis Research Center Cleveland, Ohio 44135-3191 and Propulsion Directorate U.S. Army Aviation Research and Technology Activity—AVSCOM Cleveland, Ohio 44135-3127				11. Contract or Grant No.	
				13. Type of Report and Period Covered Technical Memorandum	
12. Sponsoring Agency Name and Address National Aeronautics and Space Administration Washington, D.C. 20546-0001 and U.S. Army Aviation Systems Command St. Louis, Mo. 63120-1798				14. Sponsoring Agency Code	
15. Supplementary Notes Jon Van Gerpen, Iowa State University, Mechanical Engineering Dept., Ames, Iowa 50010 and Summer Faculty Fellow at Lewis Research Center.					
16. Abstract This report documents the Benson Diesel Engine Simulation Program and explains how it can be used to predict the performance of diesel engines. This program was obtained from the Garrett Turbine Engine Company but has been extensively modified since that time. The program is a thermodynamic simulation of the diesel engine cycle which uses a single zone combustion model. It can be used to predict the effect of changes in engine design and operating parameters such as valve timing, speed and boost pressure. The most significant change made to this program is the addition of a more detailed heat transfer model to predict metal part temperatures. This report contains a description of the sub-models used in the Benson program, a description of the input parameters and sample program runs.					
17. Key Words (Suggested by Author(s)) Diesel; Cycle; Simulation; Parameters; Efficiency			18. Distribution Statement Unclassified—Unlimited Subject Category 07		
19. Security Classif. (of this report) Unclassified		20. Security Classif. (of this page) Unclassified		21. No of pages 77	
				22. Price* A05	

